

Honeywell EC350



EC350 User Manual

FD-583 | V1.5 | 2022

Honeywell Process Solutions

Mercury Instruments, 2101 Citywest Boulevard Houston, TX 77042 USA

855 251-7065 – United States & Canada

302 669-4253 – Outside the United States

<https://process.honeywell.com>

Copyright 2022 . Honeywell Process Solutions. All rights reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of those agreements. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use without the written permission of Honeywell Process Solutions.

Mercury Instruments, 2101 Citywest Boulevard Houston, TX 77042 USA

About this document

This document is for operators and technicians working in the natural gas industry. This document provides an overview of EC350 and instructions to install EC350 on any meter equipped with an instrument drive capability (common to diaphragm and turbine meters) using a Universal Mounting Bracket (UMB) or a rotary mount. To be able to perform the tasks in this document, you must have knowledge about the physical properties of gas (volume, pressure, temperature, and supercompressibility).

Terms and definitions

The following table lists some special terms that are used across this document and provides their definitions.

Term	Definition
Meter gasket	It is used as an environmental seal for mounting EC350 on a meter.
Opto-isolators	Devices that prevent unwanted current flow or possible damage from high voltage or/and from external devices connected to the instrument.
Rivets	Used to install the slides on the index.
Slide	A small piece of plastic used for covering the digits on the index.
Spline wrench.	Used to loosen and tighten set screw in order to move the Thimble gear assembly UP or clock- wise (CW) direction or DOWN for counter clock-wise (CCW) direction.
Thimble gear assembly	Rotates the digits on the index in CW direction when it is set UP or CCW when it is set DOWN .

CONTENTS

1 About EC350	1
1.1 EC350 specifications	2
1.1.1 Certifications	2
1.1.2 Power	2
1.1.3 Environmental	3
1.1.4 Temperature measurement	3
1.1.5 Pressure measurement	4
1.1.6 API 21.1 compliance	4
1.2 Safety instructions	5
1.2.1 Things to remember	6
1.2.1.1 Usage of EC350 in hazardous areas	6
1.2.1.2 Service, maintenance, and troubleshooting EC350	6
1.3 Theory of Operation	7
1.3.1 Correction Factors to Metered Volume	7
1.3.2 Pressure Factor F_p	8
1.3.3 Temperature Factor F_t	8
1.3.4 Supercompressibility Factor F_{pv}	8
1.4 Main interfaces of EC350	10
1.4.1 LCD	10
1.4.2 Keypad	11
1.4.3 External connections	12
2 EC350 installation	14
2.1 EC350 contents verification	15
2.2 Overview of installation	16
2.3 Model number interpretation	17
2.4 Prerequisites	17
2.5 Installing EC350 on conventional diaphragm, rotary or turbine gas meters	18
2.5.1 Installing the index slide and label	18
2.5.1.1 Next steps	19
2.5.2 Changing the drive rotation	20
2.5.3 Mounting EC350 on the meter	21
2.5.4 Connecting a pressure line to EC350	22
2.6 Installing EC350 on a rotary mount	23
2.6.1 Selecting the mounting orientation	23
2.6.2 Installing the temperature probe	24
2.6.3 Connecting a pressure line to the EC350	25
2.6.4 Installing EC350 on rotary mounts	26
2.7 Power Supply Options	33
2.7.1 External Power Supply	33
2.7.2 Battery Powered	34
2.8 General Wiring connections	35
2.8.1 Pulse output communication	35

CONTENTS

2.8.2 Pulse output specification	38
2.8.3 Pulse outputs via the case connector option	40
2.9 Installation Drawings	41
3 Securing the device	45
3.1 Case	46
3.2 Metrological protection modes	46
3.2.1 Item classifications	46
3.2.2 Access restriction Item 139 configuration options	47
3.2.3 Event log full note	47
3.2.4 Changing item 139	48
3.2.5 Using MasterLink Software Application SQL to change item 139	49
3.3 Defining access privileges	50
3.3.1 Default User Table	50
3.3.2 Creating a user table file	52
3.3.3 Sending a user table file	54
3.4 Metrological configuration mode	55
3.5 Validating setup configuration	56
4 Key features	57
4.1 Volume measurement	58
4.1.1 Corrected volume	58
4.1.2 Uncorrected volume	59
4.1.3 Energy	59
4.1.4 Volume statistics	59
4.1.5 Volume Input Modes	59
4.1.5.1 UMB, Instrument Drive & Remote input	59
4.1.5.2 Direct Rotary mount input	60
4.1.5.3 Bidirectional volume or Reverse flow	60
4.1.6 Volume switch filtering	62
4.1.7 Digital switch inputs	62
4.2 P-T-Z Measurement	63
4.2.1 Gas Pressure	63
4.2.1.1 Gas Pressure statistics	63
4.2.1.2 Fixed Gas pressure	65
4.2.2 Gas Temperature	66
4.2.2.1 Temperature statistics	66
4.2.2.2 Fixed Gas temperature	67
4.2.3 Supercompressibility	67
4.2.3.1 Supercompressibility Factor	67
4.2.3.2 Item Description for Supercompressibility factors	69
4.3 Meter proving	71
4.3.1 Connecting the USB cable to the prover dongle	72
4.3.1.1 Cable adapter for the SNAP prover system	72
4.3.2 Proving dongle indicators	73

CONTENTS

4.3.2.1 Proving dongle	73
4.3.3 Starting Pushbutton proving	74
4.3.3.1 Entering Pushbutton Proving mode	74
4.3.4 Volume per proving output pulse	76
4.4 Alarms	79
4.5 Logging	83
4.5.1 Audit Trail Logging Configuration	83
4.5.2 Reading Audit Trail from the EC350	87
4.5.2.1 Displaying/Viewing Audit Trail reports	88
4.5.3 Event logger	88
4.5.3.1 Supported Event Codes	89
4.5.3.2 Clearing Event Log	89
4.5.4 Log record integrity verification	90
4.6 Battery Life/ Usage Tracking	91
4.7 Display ON/OFF	92
5 User Access	93
5.1 Getting started with the keypad	94
5.1.1 Unlocking the keypad	94
5.1.2 Human Machine Interface (HMI)	94
5.1.2.1 Level 0 mode	95
5.1.2.2 Level 1 mode	96
5.1.2.3 Level 2 mode	113
5.1.2.4 Level 3 mode	126
5.2 Working with HMI	135
5.2.1 Choosing the meter type	135
5.2.2 Verifying pressure	137
5.2.3 Verifying temperature	139
5.2.4 Testing the pulse input	141
5.2.5 Entering the site ID	142
5.2.6 Setting the date and time	143
5.2.6.1 Setting the date	143
5.2.6.2 Setting the time	144
5.2.6.3 Auto set date and time	145
5.2.7 Selecting the unit of measure	146
5.2.7.1 Selecting the unit of measurement for volume	147
5.2.7.2 Selecting the unit of measurement for energy	149
5.2.7.3 Selecting the unit of measurement for pressure	151
5.2.7.4 Selecting the unit of measurement for temperature	153
5.2.8 Single point temperature and pressure calibration	155
5.2.8.1 Calibrating temperature	155
5.2.8.2 Calibrating pressure	156
5.3 Connecting to EC350 via MasterLink Software Application SQL	158
5.3.1 About MasterLink Software Application SQL software	158

CONTENTS

5.3.2	Connecting the IrDA communication USB dongle to the computer	158
5.3.3	Connecting the IrDA communication USB dongle to EC350	158
5.3.4	Signing on to the EC350	159
5.3.5	Updating EC350 firmware	159
5.3.6	Force schedule Call-In Time After FW Update	162
5.4	Working with MasterLink Software Application SQL	163
5.4.1	Items by function	163
5.4.2	Setting time and date	164
5.4.3	Item files	164
5.4.3.1	Reading/Creating item files	165
5.4.3.2	Displaying/Viewing item files	166
5.4.4	Calibrating pressure	166
5.4.5	Calibrating PLog pressure	168
5.4.6	Calibrating temperature	170
5.4.7	Configuring the Meter reader list	172
5.4.8	Configuring Call in feature	174
5.5	Working with PowerSpring	178
5.5.1	Adding EC350 to PowerSpring	178
5.6	Connecting EC350 with PowerSpring using a Messenger Modem	180
5.6.1	Configure EC350 using MasterLink Software Application	180
5.6.2	Configure EC350 in PowerSpring	184
6	Remote Communications	207
6.1	Use of RS232/ 485	208
6.2	Call in and call out	210
6.2.1	Call in	210
6.2.1.1	Call in	210
6.2.1.2	Scheduled Call In	211
6.2.1.3	Alarm Call In	212
6.2.1.4	Force schedule Call	212
6.2.1.5	Management of Multiple Phone Numbers	212
6.2.1.6	Retry Timing	213
6.2.1.7	LCD indications	213
6.2.1.8	Forcing a Test Call	213
6.2.2	Call out	214
6.2.2.1	Set Call Out time	214
6.2.2.2	Set a call out stop time	215

CONTENTS

6.3 Modbus Communication	216
7 Maintenance	218
7.1 Temperature Probe Measurement Kits	218
7.2 Transducer Replacement Kits	219
7.3 Redundant Uncorrected Switch	221
7.4 Metrological Sealing Cover (MC)	221
7.5 Removing and Re-Installing Human Factor (HF) Cover	223
7.6 Replacing the Battery Pack	224
7.6.1 Replacing the battery in a hazardous DIV-1/ZONE-0 environment	224
7.6.2 Replacing the battery in a non-hazardous environment	224
7.7 Low battery/ External Power shutdown mode	226
7.8 User Shelf/ Shutdown mode	228
7.8.1 To enter user shutdown mode using HMI mode 2 or 3	228
7.8.2 To enter user shutdown mode using MasterLink Software Application SQL	228

CHAPTER 1

1 About EC350

This section provides information about the main interfaces of EC350 - LCD, Keypad, and External connections. It also lists the safety instructions that must be followed while installing and commissioning EC350.

- [Safety instructions](#)
- [Theory of Operation](#)
- [Main interfaces of EC350](#)

1.1 EC350 specifications

This section provides the specifications and certifications for EC350.

- [Certifications](#)
- [Power](#)
- [Environmental](#)
- [Temperature measurement](#)
- [Pressure measurement](#)
- [API 21.1 compliance](#)

1.1.1 Certifications

- Electrostatic Discharge Immunity Test (EN61000-4-2)
- Radiated, Radio-Frequency Electromagnetic Field Immunity Test (EN61000-4-3)
- Electrical Fast Transient/Burst Immunity Test (EN61000-4-4)
- Conducted Radio-Frequency Electromagnetic Field Immunity Test (EN61000-4-6)
- Radiated Emissions (EN 61000-6-4)
- FCC Part 15
- Measurement Canada
- CSA C/US--- Class I, Div 1/Zone 0 (pending)
- CSA C/US Class I, Division 2, Groups C and D, T3C
- IECEx --- Class I, Zone 0 (pending)
- IECEx --- Class I, Zone 2 (pending)
- IEC-Ex ec [ia Ga] ic nC IIB T4 Gc

1.1.2 Power

- Battery
 - 7 Volt 2 cell lithium battery pack
 - 6 Volt 4 cell alkaline battery pack
- External DC supply 5 - 15 Volts DC
- Battery can optionally serve as back-up for external DC voltage

1.1.3 Environmental

- Operating Temperature Range: -40 °F to +158 °F (-40 °C to +70 °C).
 - If you are using an EC350 device with a modem, then it is recommended to consider the operational temperature range of the modem. The temperature system will continue providing accurate measurements even if the modem is unable to operate because of environmental conditions.
 - -22 °F to +158 °F (-30 °C to +70 °C) when used with CNI2
 - -13 °F to +158 °F (-25 °C to +70 °C) when used with Cloud Link 4G modem
- Humidity: 0-95% non-condensing

1.1.4 Temperature measurement

- Highly stable, solid state temperature sensor (thermistor)
- Range: -40 °F to +158 °F (-40 °C to +70 °C).

1.1.5 Pressure measurement

Ambient temperature range: -40°F to 158°F (-40° to 70°C)

Min/Max pressures per pressure transducer type and range:

Type	Pmin	Pmax	Units
Gauge	-4.6	6	psig
Gauge	-3.1	30	psig
Gauge	-2.5	60	psig
Gauge	8.2	100	psig
Gauge	48	300	psig
Gauge	110	600	psig
Gauge	190	1000	psig
Gauge	290	1500	psig
Absolute	10	30	psia
Absolute	20	100	psia
Absolute	60	300	psia
Absolute	120	600	psia
Absolute	200	1000	psia
Absolute	300	1500	psia

1.1.6 API 21.1 compliance

- The "Flow Time" item (i1690) is added. It shows the number of seconds the instrument is not in a "no flow" state.

For example, under continuous flow, the no of seconds are equal to the log, and if there is no flow during the interval, the value becomes zero.

- The "No Flow Cutoff" item (i1691) is added. Item Units are the same as the Flow Rate item.

If the flow is equal to or above the threshold, the Flow Time value advances.

If the flow is less than the threshold, the Flow Time stops.

1.2 Safety instructions

EC350 complies with the general safety standards and regulations. However, failure to operate EC350 as per the safety instructions available in this document may lead to hazards.

EC350 is approved for use in hazardous areas (Class I Division 1 or Class I Division 2). Different versions of EC350 are available depending on the operating conditions. The permitted operating conditions are marked on each EC350. Check the operating condition limits of EC350 before installing. You must be familiar with the currently applicable electrical installation standards and regulations before installing and operating EC350 in hazardous areas.

Warning: Denotes an explosion hazard. Ensure you follow all instructions described in the warning notification.

To avoid explosion hazard, ensure to note the following:

- Install EC350 depending on the operating conditions permitted for that particular EC350 unit.
- EC350 device for Class I Division 1 is intrinsically safe and must be connected to other circuits as per the installation drawing specified on each EC350.
- EC350 device for Class I Division 2 must be connected to other circuits as per the installation drawing specified on each EC350.
- Substitution of components may impair suitability for use in a hazardous location.

Caution: The caution warns you of possible damage to property and provides instructions to avoid damage to EC350.

Honeywell recommends you to observe the warning information described in this document and other generally applicable safety rules.

No warranty claims can be asserted if there is an unauthorized interference with the device.

1.2.1 Things to remember

1.2.1.1 Usage of EC350 in hazardous areas

You are allowed to use EC350 in hazardous areas, under some permitted operating conditions. Ensure to comply with the applicable laws and regulations, and company policies for the usage of EC350.

Installation and commission EC350 in hazardous areas

EC350 must be installed and commissioned only by specially trained and qualified staff. The device is designed in accordance with the IP 65 degree of protection as per EN 60529. The installation of the intrinsically safe circuits must comply with the applicable local laws or regulations. Operate EC350 only if the instrument is completely intact.

1.2.1.2 Service, maintenance, and troubleshooting EC350

The service, maintenance and troubleshooting of EC350 device operating in hazardous areas must be performed only by specially trained and qualified staff.

Replacement of EC350 battery pack

To maintain acceptability of use in hazardous locations, you must use replacement batteries supplied by Honeywell. For further information about changing the EC350 battery pack, refer to the section, [“Replacing the Battery Pack”](#)

1.3 Theory of Operation

- [Correction Factors to Metered Volume](#)
- [Pressure Factor Fp](#)
- [Temperature Factor Ft](#)
- [Supercompressibility Factor Fpv](#)

1.3.1 Correction Factors to Metered Volume

Ideal or perfect gases follow the relationship of Boyle's Law for pressure effect and Charles' Law for temperature effect, which can be stated: The volume of any definite weight of a perfect gas varies inversely with change in absolute pressure and directly with change in absolute temperature. The equation for this relationship of the two laws is expressed as follows:

$$\frac{V1 * P1}{T1} = \frac{V2 * P2}{T2}$$

The Symbols V1, P1 and T1 refer to the original volume, pressure and temperature while V2, P2 and T2 refer to the volume, pressure and temperature of the new or changed conditions. Rearranging the equation and rewriting subscripts, we can express it as follows:

$$Vb = Vm * \frac{(Pm * Tb)}{(Pb * Tm)}$$

Where:

Vb = gas volume (cu. Ft.) at base condition corrected

Pb = absolute base pressure (psia)

Tb = absolute base temperature (deg. R)

Vm = gas volume metered (cu. Ft.) uncorrected

Pm = absolute meter pressure (psia)

Tm = absolute meter temperature (deg. R)

1.3.2 Pressure Factor Fp

The pressure factor (Fp) to apply to metered volume is expressed by the Boyle's Law relationship as follows:

$$F_p = \frac{P_m}{P_b} = \frac{\text{Meter Pressure (PSIG)} + \text{Atmospheric Pressure (PSIA)}}{\text{Base Pressure (PSIA)}}$$

Each increment of meter pressure represents a different pressure factor. As the flowing gas pressure (Pm) changes, the EC350 automatically applies the pressure factor (Fp) to the metered volume (Vm).

1.3.3 Temperature Factor Ft

The temperature factor (Ft) to apply to metered volume is expressed by the Charles' Law relationship as follows:

$$F_t = \frac{T_b}{T_m} = \frac{\text{Base Temperature, deg F} + 459.67}{\text{Meter Temperature, deg F} + 459.67}$$

Each increment of meter temperature represents a different temperature factor. Therefore, as the flowing gas temperature changes, the EC350 automatically applies the temperature factor (Ft) to the metered volume.

1.3.4 Supercompressibility Factor Fpv

Gases actually behave slightly different than what the ideal gas laws indicate. This deviation depends on the molecular composition of the gas and the specific gravity as well as the pressure and temperature. Natural gas, for instance, compresses by a greater amount than that computed by Boyle's law and hence the term "supercompressibility" is used for this deviation. It is small at very low pressure, but becomes substantial as the pressure increases. The EC350 automatically applies the supercompressibility factor and therefore the equation for total volume correction that the EC350 applies to metered volume, is expressed as:

$$V_b = V_m * F_p * F_t * (F_{pv})^2$$

Where:

Vb = gas volume (cu. Ft.) at base condition corrected

Vm = metered volume read from meter index

Fp = pressure factor

Ft = temperature factor

Fpv = supercompressibility determined from NX-19 or AGA-8

The EC350 automatically squares the supercompressibility factor displayed, which is based on the pressure and temperature sensed at the meter. The resulting volume readout is corrected for pressure, temperature, and supercompressibility.


1.4 Main interfaces of EC350

The main interfaces of the EC350 are:

- [LCD](#)
- [Keypad](#)
- [External connections](#)


1.4.1 LCD

EC350 provides a ten character, configurable, alphanumeric LCD display with icons to display the status information and alarm conditions. The LCD display can be configured to on or off at different times of day. During normal operation (Correction mode), the corrected volume is displayed on the LCD. Following is an LCD display illustration, showing all segments ON.




The following table lists the icons on the LCD display.

Icon	Description
	Heart Beat : flashes every 3 seconds to indicate normal operation (Correction mode).
	Lock : Indicates that the instrument is in a metrologically protected mode
	Unlock : Indicates that the instrument is not in a metrologically protected mode
	Battery : indicates a low battery condition. Refer to the section Replacing the Battery Pack . Battery alarm is also indicated by this icon.

Icon	Description
	Alarm : indicates the alarm for low pressure, volume sensor, system, temperature, flow rate, pressure limit, and daily corrected volume limit.
	IrDA : indicates that communication with the device via the front panel IR port is enabled.
	Navigation key function indicator : as you navigate through the options in each operating mode, this icon indicates the keys that are active for the selected option.
	Pulse output channel indicator : indicates which of the 4 pulse output channels are enabled, and flashes when a pulse is transmitted.
	Smile : indicates the HMI is unlocked. The navigation keys are functional.
	Star : The Star icon turns on during pressure and temperature measurement, which typically occurs every 30 seconds.

1.4.2 Keypad

The keypad is used for scrolling through the menu options. The following table lists the keys.

Option	Description
	Use these keys for unlocking the keypad and activating the display. To unlock the keypad, press and hold ESC and UP arrow at the same time until display text appears.
	Use these keys for scrolling up and down in a menu. You can also use to enter input by increasing and decreasing a value at the current position.
	Use these keys for navigating to the next and/or previous digit. Use these keys to move the cursor one character at a time, in forward or backward directions.
	Use this key to access the main menu or display the submenu of the current menu. It is also used for accepting an input value.
	Use this key to display the Home screen, cancel an entry, or go back to the previous menu.


To conserve battery power, after each processing cycle the EC350 keypad is locked, if there is no input received within the time out period (1 to 10 minutes).

1.4.3 External connections

The external connections from EC350 are:

- Pulse outputs
- Serial port
- Alarm outputs
- External supply voltage (TB1)
- Battery pack (P5)

The figure below illustrates the purpose of different jumpers and other connections on an EC350 IO board:



CHAPTER 2

2 EC350 installation

This chapter deals with the installation of EC350 on conventional gas meters (such as rotary, diaphragm, and turbine). This chapter also provides procedures for installing and replacing the battery and output wire connections to obtain pulse output from EC350.

- [EC350 contents verification](#)
- [Overview of installation](#)
- [Model number interpretation](#)
- [Prerequisites](#)
- [Installing EC350 on conventional diaphragm, rotary or turbine gas meters](#)
- [Installing EC350 on a rotary mount](#)
- [Power Supply Options](#)
- [General Wiring connections](#)
- [Installation Drawings](#)

2.1 EC350 contents verification

The following components are installed and connected inside EC350 when shipped.

- Pressure transducers (upto 2 transducers, if ordered)
- Temperature probe (if ordered)

After you receive EC350:

- Remove the contents from the box and from the mounting kit bag.
- Check the shipment against the invoice to ensure that the components ordered are installed in EC350.
- Report any shortage or shipping damages to your nearest Honeywell Account Manager.

2.2 Overview of installation

The EC350 installation consists of mounting and wiring EC350 according to the instructions given in this section. Before proceeding, read the installation information provided in this section and refer to the section “[Model number interpretation](#)”, to familiarize yourself with the EC350 model you have selected.

Based on the mounting selected, refer to one of the following two methods for installing EC350 on a meter.

- Installing EC350 on conventional diaphragm, rotary or turbine gas meters. The following image illustrates with a UMB.



- Installing EC350 on a rotary mount. The following image illustrates EC350 configured for a rotary mount. (Adapter plate, which varies by meter model, not shown.)



2.3 Model number interpretation

EC350 is available in different models. Refer to the Model Selection Guide (MSG), available from your Mercury sales representative, for details.

2.4 Prerequisites

Ensure that the following components are installed and connected inside EC350, before installing EC350 on meters.

- Battery pack
- Pressure transducer (if ordered)
- Temperature probe (if ordered)

2.5 Installing EC350 on conventional diaphragm, rotary or turbine gas meters

This section describes the procedures to install EC350 on conventional diaphragm, rotary or turbine gas meters, equipped with instrument drive capability.


- [Installing the index slide and label](#)
- [Changing the drive rotation](#)
- [Mounting EC350 on the meter](#)
- [Connecting a pressure line to EC350](#)

2.5.1 Installing the index slide and label


The UMB has a digital index for indicating uncorrected volume. You can move the slide on the mechanical counter to cover the digits that are not used, based on customer configuration.

To install the index slide and label

- Based on your application, apply **labels** to the UMB. Refer to the following image for applying the labels.



The following image illustrates the labels applied to the UMB, slides, and rivets.



2.5.1.1 Next steps

Verify if the digital index reading rotates in the proper direction. If not, perform the tasks described in the following section, “[Changing the drive rotation](#)”, to position the bevel-gear thimble of EC350 to ensure the reading rotates in the proper direction.

2.5.2 Changing the drive rotation

The bevel-gear Thimble assembly or the Thimble gear assembly in the UMB permits either clockwise (CW) or counterclockwise (CCW) rotation. Before installing EC350, note whether the output shaft of the meter rotates CW or CCW. You can change the driver rotation by positioning the Thimble gear assembly of EC350 to match the meter rotation.

To change the driver rotation to match the meter rotation

- Remove the supplied **Spline wrench** from the front plate storage.

The following image illustrates the Spline wrench in the front plate storage.



- Loosen the **Set screw** on the Thimble gear assembly.
The Thimble gear assembly position can be adjusted without removing the front plate of the UMB assembly.
- Shift the Thimble gear assembly **Up** to set the drive rotation in the CW direction or **Down** to set the drive rotation in the CCW direction.
- Tighten the set screw after the Thimble gear assembly is properly positioned and fully meshed with the Vertical miter gear on the horizontal shaft.
- Replace the transparent index cover and the three Phillips-head screws after stowing the Spline wrench.


2.5.3 Mounting EC350 on the meter

Ensure that you have the right mounting kit. Refer to the MSG or the image provided along with EC350 to ensure it is the right mounting kit.

Use the base plate to rotate EC350 about 360 degrees in any four directions. To rotate EC350, remove all four screws, which attach the base plate to the bracket housing.

To mount EC350 on the meter:


- Place the meter gasket against the meter end and attach EC350 with the UMB to the meter mounting plate.
- Install the four meter mounting bolts (provided with the kit) and tighten the bolts after you have positioned the UMB.
- Thread the slip-along fitting into the thermowell and place the temperature probe into the slip-along fitting, sliding the probe down until it bottoms out from the thermowell before tightening the slip-along nut.



2.5.4 Connecting a pressure line to EC350

Use a pressure connection kit, and connect the pressure line to the ¼ inch NPT fitting.

Hold wrench on flats when installing pressure line on Pressure transducer to ensure proper seal and avoid loads on composite case.



Warning: To avoid explosion, it is extremely important to ensure the pressure transducer is capable of handling the pressure in the gas line. Check item entry 137 (user units) or item entry 25(Psi) on the EC350 for maximum pressure transducer information before applying live gas pressure to the EC350.

2.6 Installing EC350 on a rotary mount

This section describes the procedures to install EC350 on a rotary mount.


- [Selecting the mounting orientation](#)
- [Installing the temperature probe](#)
- [Connecting a pressure line to the EC350](#)
- [Installing EC350 on rotary mounts](#)

2.6.1 Selecting the mounting orientation

EC350 supports four orientations for instruments and mounting plates. The EC350 can be rotated about 90 degrees increments based on your meter configuration.

To select the mounting orientation:

- Loosen and remove the four mounting screws holding the mounting plate.
- Rotate the mounting plate to the required orientation.
- Reinstall and tighten the four mounting screws to 18–20 inch LBS. The following image illustrates the mounting orientation of EC350.



2.6.2 Installing the temperature probe


Insert the temperature probe into the meter thermowell before mounting the EC350 on the meter.

To mount the temperature probe into the meter base:

- Pull the temperature probe out of the mounting plate as illustrated in the following image.



EC 350 as
received



Probe extended

- Use the temperature probe as a measuring device, and insert the probe until it bottoms out from the thermowell of the meter as illustrated in the following image.



- Mark the temperature probe cable at the point where the cable comes out from the meter body as illustrated in the following image.



- The temperature probe is held in place with a rubber gland in the mounting plate. Push the probe into EC350 until the mark is one inch from the mounting plate, as illustrated in the following image.




The one inch additional length ensures that the probe bottoms out at the end of the thermowell.

- Insert the temperature probe into the thermowell as illustrated in the following image.

The temperature probe is mounted into the meter base.







2.6.3 Connecting a pressure line to the EC350







Use a pressure connection kit and connect the pressure line to the ¼ inch NPT fitting. The following images illustrates a pressure transducer connected to a pressure line using the pressure connection kit.













2.6.4 Installing EC350 on rotary mounts



This section describes the various types of rotary meter mounting kits. The following table illustrates the mounting of EC350 on each type of rotary mounts.







Rotary meter mounting kit	Rotary mount illustration		Part Number
LMMA 1.5m to 5m and 23m to 102m mounting kit with snap seals.			22-2089
LMMA 1.5m to 5m and 23m to 102m mounting kit with cross-drilled screws.			22-2089-1
LMMA 1.5m to 5m and 23m to 102m mounting kit with McGARD screw, PG and E Key			22-2089-2




Rotary meter mounting kit	Rotary mount illustration		Part Number
LMMA 7m to 16m mounting kit with snap seals.			22-2090
LMMA 7m to 16m mounting kit with cross-drilled screws			22-2090-1
LMMA 7m to 16m mounting kit with McGARD screw, PG and E key			22-2090-2

Rotary meter mounting kit	Rotary mount illustration		Part Number
Romet RM1000 to RM5000 mounting kit with snap seals.			22-2104
Romet RM1000 to RM5000 mounting kit with cross-drilled screws			22-2104-1
Romet RM1000 to RM5000 mounting kit with McGARD screw, PG and E key			22-2104-2

Rotary meter mounting kit	Rotary mount illustration		Part Number
Romet 7000 to 23000 mounting kit with snap seals.			22-2105
Romet 7000 to 23000 mounting kit with cross-drilled screws			22-2105-1
Romet 7000 to 23000 mounting kit with McGARD screw, PG and E key			22-2105-2

Rotary meter mounting kit	Rotary mount illustration		Part Number
AMCO C-type mounting kit with snap seals			22-2106
AMCO C-type mounting kit with cross-drilled screws.			22-2106-1
AMCO C-type mounting kit with McGARD screw, PG and E key			22-2106-2

Rotary meter mounting kit	Rotary mount illustration		Part Number
Romet external temperature mounting kit with snap seals.			22-2107
Romet external temperature mounting kit with cross-drilled screws			22-2107-1
Romet external temperature mounting kit with McGARD screw, PG and E key			22-2107-2

Rotary meter mounting kit	Rotary mount illustration		Part Number
<p>B3 or TQM mounting kit with snap seals.</p>			<p>22-2108</p>
<p>B3 or TQM mounting kit with cross-drilled screws.</p>			<p>22-2108-1</p>
<p>B3 or TQM mounting kit with McGARD screw, PG and E key</p>			<p>22-2108-2</p>

2.7 Power Supply Options

The EC350 has flexible power supply options. The unit can operate from an externally supplied DC power source or from a 4-cell Alkaline, a 2-cell Lithium, or dual 2-cell Lithium Battery Packs.

- [External Power Supply](#)
- [Battery Powered](#)
- [Battery Life/ Usage Tracking](#)
- [Replacing the Battery Pack](#)
- [Low battery/ External Power shutdown mode](#)
- [User Shelf/ Shutdown mode](#)

2.7.1 External Power Supply

The input voltage range for using an externally supplied **DC power source** is **+5.0 VDC to +15.0 VDC**. The Honeywell power 9 VDC pack p/n: **40-2291** can be used as an external voltage source.

Connections for the external supply are made at the **TB1** connector on the EC350 IO Board. Terminal-1 nearest the top of the IO Board is GND and Terminal-3 is the positive (+) input. When operating from an externally supplied DC power source, a backup battery pack may also be installed with the intent of powering the instrument in situations where the external (remote) power is interrupted.

Installations requiring CLASS 1 - DIV 2 approval, the following Battery Packs are approved: 40-6048 (2-cell Lithium), 40-6050 (4-cell Alkaline), and 40-6064 (4-cell Alkaline with 47 ohm Res). These Battery Packs can be connected to the P5 Battery connector using cable p/n: 40-6045.

Installations requiring CLASS 1 - DIV 1 approval, only the Battery Pack 40-6064 is approved.

When operating from an externally supplied DC power source, configure the External Supply Low Alarm Limit (**Item 795**) to be a value greater than 5.0 and generally less than 7.0 V. The default value of Item 795 is -1.0 to effectively disable the Alarm Item 796. The External Supply voltage is measured on a 10 minute interval. Three consecutively low readings are required to trip the Low Voltage Alarm (Item 796) – this is done to help guard against falsely setting alarm due to a power supply glitch.

2.7.2 Battery Powered

Connections for the Battery pack are made at the P5 connector on the EC350 IO Board. There are three Battery choices for operating the EC350 from battery power:

- 40-6050 (4-cell Alkaline) – 5 year operating life under specified conditions
- 40-6048 (2-cell Lithium)
- Dual set of 40-6048 (2-cell Lithium) – extended life or heavy usage / comms applications.
- Use the Battery Type (Item 1061) to select the type of Battery pack that is being used to power the instrument.
 - 0= 4 Cell Alkaline (default type)
 - 1= 2 Cell Lithium
 - 2= 4 Cell Lithium (dual set of p/n 40-6048)

The Battery voltage is measured on a 10 minute interval. Three consecutively low readings are required to trip the Low Voltage Alarm (Item 99) – this is done to help guard against falsely setting alarm due to a supply glitch.

Note: The Low Battery Voltage Alarm (Item 99) will not set if an External Supply voltage is present at TB1 with a voltage level greater than the Battery voltage by over 1.0 VDC. When a Low Battery Voltage Alarm is tripped (set), an Alarm Log record entry is generated along with updates to time stamp Items 462 and 463.

2.8 General Wiring connections

This section describes the pulse outputs from EC350.

- Three Form-A volume pulse outputs
- One Form-B alarm output

These outputs are electronic switches. The first three pulse outputs are configured as either corrected volume or uncorrected volume. The fourth pulse output is used only for alarm output.

Note: Outputs are conventionally called “pulse outputs”, but it should be understood that they are actually solid state (transistor) switches and do not produce any voltage. The external device to which they are connected must provide wetting voltage with current limiting, and be able to respond to the contact closures.

- [Pulse output communication](#)
- [Pulse output specification](#)
- [Pulse outputs via the case connector option](#)

2.8.1 Pulse output communication

EC350 provides four pulse outputs, three (channels A, B, and C) normally-open Form A type, and one (channel D) normally closed Form B type. The pulse outputs are typically used for connection to an AMR (Automatic Meter Reader) device.

These outputs are electronic switches that operate like an isolated bidirectional switch. Channels A, B, and C (normally open type) can be configured as corrected volume or uncorrected volume. Channel C can alternatively be configured as a (normally open) alarm output. Channel D (normally-closed type) is only for alarm output use. All the pulse outputs of the EC350, including the alarm pulse output, use opto-isolators for isolating the EC350 circuitry from the devices receiving the pulses. Opto-isolators are devices that prevent unwanted current flow or possible damage from high voltage.

Alarm pulse outputs

An alarm pulse (on channel C or D) is generated when EC350 enters an alarm condition. Use channel C (NO or Normally Open) or channel D (NC or Normally Closed) depending on the AMR device accepting the alarm pulse. Use of channel D (NC) allows for a cut wire to be interpreted as an alarm condition to the AMR device.

Volume pulse outputs

EC350 provides three Form-A pulse outputs (channels A, B, and C) for volume output pulses.

Volume pulses can correspond to either uncorrected volume (as counted in item 2) or corrected volume (as counted in item 0). The type of volume pulse (and whether the channel is enabled) is configured through items 93-95.

The "weight" of each pulse (e.g. whether a pulse corresponds to 10 cubic feet or 1 cubic meter) is configured via items 1193-1195.

Note: In prior Mercury products the pulse weight was configured differently through items 93-95. These are now read-only values provided for reference.

Pulse output timing is configurable via items 1014, 1015, and 1024. Various pulse ON and OFF times can be chosen. Default is a pulse ON time of 62.5 milliseconds and a pulse OFF time of at least 62.5 milliseconds, for a minimum pulse period of 125 milliseconds.

Pulse Output Configuration Summary

Channel	Item function	Item number	Parameters	Description
A	Enable/Type	93	0 = CorVol pulses 2 = UncVol pulses 3 = Off	Channel A pulse output selection. Select the type of information to be transmitted out of Channel A.
	Weight	1193	100 CF (Default)	Volume associated with a single pulse on channel A.
	Timing	1014	50/250 ms	Channel A pulse output timing. Select the On and Off timing requirements for Channel A output.
	Queue	5	0 (Default)	Channel A pulses waiting. Provides the number of pulses waiting to be sent to the remote device. Pulse queue = 2 x the number of Channel A output pulse remaining from the previous wakeup period.

Channel	Item function	Item number	Parameters	Description
B	Enable/Type	94	0 = CorVol pulses 2 = UncVol pulses 3 = Off	Channel B pulse output selection. Select the type of information to be transmitted out of Channel B.
	Weight	1194	100 CF (Default)	Volume associated with a single pulse on channel B.
	Timing	1015	50/250 ms	Channel B pulse output timing. Select the On and Off timing requirements for Channel B output.
	Queue	6	0 (Default)	Channel B pulses waiting. Provides the number of pulses waiting to be sent to the remote device. Pulse queue = 2 x the number of Channel B output pulse remaining from the previous wakeup period.


Channel	Item function	Item number	Parameters	Description
C	Enable/Type	95	0 = CorVol pulses 2 = UncVol pulses 3 = Off 4 = Alarm	Channel C pulse output selection. Select the type of information to be transmitted out of Channel C.
	Weight	1195	100 CF (Default)	Volume associated with a single pulse on channel C.
	Timing*	1024	50/250 ms	Channel C pulse output timing. Select the On and Off timing requirements for Channel C output.
	Queue	7	0 (Default)	Channel C pulses waiting. Provides the number of pulses waiting to be sent to the remote device. Pulse queue = 2 x the number of Channel C output pulse remaining from the previous wakeup period.
D	Alarm Channel On time	1016	Default = 10 seconds	Alarm pulse width. Since this channel is Normally Closed, the channel goes open for this duration on an alarm event.

Note: If channel C is used as an alarm output, the pulse width is fixed at 100 milliseconds.

2.8.2 Pulse output specification

Following are the specifications for pulse output.

- All outputs are isolated from ground and each other.
- Outputs are rated for DC values from 0 to 30.0 volts, non polarized in non-hazardous locations.
- In Division 1 or Zones 1 & 2 hazardous locations, voltage rating is reduced to 8 volts maximum.
- Each circuit includes 100 ohms of current limiting resistance.
- Maximum load current 20 mA.



Channel A output terminals

Channel B output terminals

Channel C output terminals


Alarm output terminals

2.8.3 Pulse outputs via the case connector option


A 6 pin Amphenol case connector can be ordered to provide for the connection of two of the three pulse outputs plus the alarm from outside the instrument. The connector as shown below is viewed from outside the instrument. Pins A – F are labeled clockwise with pin A at the top. The table below shows the connections.

Note: Note that since the outputs are non-polarized, wires can be connected in either polarity to each output.

<u>PIN</u>	<u>COLOR</u>	<u>PIN FUNCTION</u>
A	WHITE	OUTPUT A
B	RED	OUTPUT A
C	BLUE	OUTPUT B
D	BLUE	OUTPUT B
E	BLACK	ALARM
F	BLACK	ALARM



2.9 Installation Drawings



DIMENSIONS ARE IN INCHES (METRIC mm)
BREAK ALL SHARP EDGES
UNLESS OTHERWISE SPECIFIED TOLERANCES ARE:
FRACTIONAL ±.010 DECIMAL ±.005 ANGLE ±1/2°

MERCURY INSTRUMENTS
SERVING THE GAS INDUSTRY WORLDWIDE

THIS DOCUMENT CONTAINS CONFIDENTIAL AND PROPRIETARY INFORMATION OF MERCURY INSTRUMENTS AND NEITHER IT NOR THE INFORMATION CONTAINED THEREIN SHALL BE DISCLOSED TO OTHERS OR DUPLICATED OR USED FOR OTHERS WITHOUT THE EXPRESS WRITTEN CONSENT OF MERCURY INSTRUMENTS.

INSTALLATION DRAWING
CLASS I, Div 2
EC350

MATERIAL	DRAWN BY SBB	DATE 04/27/2015	CHANGE NOTICE 2015-1924
RELEASE	DWG. # 40-6062	SCALE	REV. A
	DWG SIZE A		

3. P4 IS A METROLOGICAL JUMPER THAT HAS BEEN EVALUATED AS NON-INCENDIVE AND CAN BE REMOVED AND/OR REPLACED IN Div 2 HAZARDOUS LOCATION.

4. P7 IS A TAMPER DETECTION REED SWITCH WHICH IS MOUNTED TO CASE AND ACTIVATED BY A MAGNET IN THE DOOR. THIS CONNECTION HAS BEEN EVALUATED AS NON-INCENDIVE.

5. P12 IS A THERMISTOR TEMPERATURE SENSOR AND THE CONNECTION AT P12 HAS BEEN EVALUATED AS NON-INCENDIVE. TEMPERATURE SENSOR OPTIONS INCLUDE 40-5814, 40-600B, 40-6007, 40-6006, 40-6005, 40-6004, 40-6003, 40-6002.

6. P10 AND P11 ARE PRESSURE TRANSDUCERS, UP TO TWO PRESSURE TRANSDUCERS CAN BE USED IN CLASS I, Div 2. PART NUMBERS FOR TRANSDUCERS INCLUDE 40-5316.

7. P8 AND P9 ARE ROTARY METER SENSOR INPUTS AND OPTIONS INCLUDE 40-4567, 40-3572-1 AND 40-3407-1.

8. TB2 AND TB3 ARE FOR DIGITAL PULSE INPUTS; Div 2 PULSE GENERATOR OPTIONS: PASSIVE, RESISTIVE, NON-ENERGY STORING DEVICE OR DEVICES HAVING ENTITY PARAMETERS CONFORMING TO TABLE 1. THESE PULSE GENERATORS CAN BE LOCATED IN Div 2 OR NON HAZARDOUS LOCATION. MAXIMUM CABLE LENGTH 200 FEET. ANY COMBINATION OF THE OPTIONS FOR PULSE GENERATORS ARE NOT TO BE CONNECTED SIMULTANEOUSLY.

9. TB4 IS FOR CONNECTION TO SERIAL DEVICE RS-232 OR RS-485. SELECTED AT JP1 AND JP2. JP1 AND JP2 SHUNTS SHOULD BOTH BE PLACED ON A AND B TO SELECT RS485 AND B AND C TO SELECT RS-232. THE CONNECTION AT JP1 AND JP2 HAS BEEN EVALUATED AS NON INCENDIVE AND CAN BE CHANGED IN A CLASS I, Div 2 LOCATION. CONNECTIONS TO TB4 CAN BE MADE VIA CONDUIT PER NOTE 1 OR WITHOUT CONDUIT TO A CLASS I, Div 2 OR CLASS I, Div 2 APPROVED PRODUCT WITH ENTITY PARAMETERS MATCHING THE FOLLOWING OPTIONS:

OPTION 1:
1. AS AN OPTION TO THE CONNECTION SHOWN ON PAGE 1 FOR THE SERIAL PORT CONNECTION AT TB4, TXD AND RXD CONNECTIONS CAN BE MADE FROM SERIAL PORT TB4 TO A SERIAL DEVICE HAVING ENTITY PARAMETERS CONFORMING TO TABLE 1 AND 2 BELOW. THESE SERIAL DEVICES CAN BE LOCATED IN Div.1/ZONE 0, Div. 2/ZONE 2, OR NON-HAZARDOUS LOCATIONS.

10. TB5 IS FOR CONNECTION TO PULSE OUTPUTS FROM THE EC 350. CONNECTION TO TB5 CAN BE MADE VIA CONDUIT WITH MAX 12 VDC PER NOTE 1, OR WITHOUT CONDUIT TO A CLASS I, Div 1 OR Div 2 APPROVED BARRIER WITH FOLLOWING SPECIFICATIONS OR PRODUCT WITH ENTITY PARAMETERS MATCHING THE FOLLOWING PARAMETERS.

OPTION 1:
AS A FIRST OPTION CONNECTION TO TB5 PULSE OUTPUT CAN BE CONNECTED WITHOUT CONDUIT VIA CSA CERTIFIED BARRIER HAVING PARAMETERS OF EITHER
a) 18V 100 ohms, SUCH AS MTL 7715+
b) 28V 300 ohms, SUCH AS MTL 7728+

OPTION 2:
AS A SECOND OPTION EACH CHANNEL (CHANNELS IDENTIFIED BELOW) CAN BE CONNECTED TO A CLASS I, Div 2 APPROVED PRODUCT WITH ENTITY PARAMETERS. THESE PULSE RECEIVERS CAN BE LOCATED IN CLASS I, Div 1/Div 2 OR NON HAZARDOUS LOCATION.

TABLE 1.
Input parameters For Mercury Instruments 40-5702 TB2, TB3

Electrical Parameters	Div Marking	Zone Marking	Value
Maximum Input Voltage	V _{max}	UI	10V
Maximum Input Current	I _{max}	II	50mA
Maximum Input Power	PI	PI	125mW
Maximum Internal Capacitance	CI	CI	4700pF
Maximum Internal Inductance	LI	LI	0

THE PARAMETERS OF THE CONNECTED IS APPARATUS MUST MEET THE FOLLOWING CONDITIONS:
 $V_{oc}/U_o \leq V_{max}/U_i$
 $I_{sc}/I_o \leq I_{max}/I_i$
 $C_a/C_o \geq C_i + C_{cable}$
 $L_a/L_o \geq L_i + L_{cable}$

TABLE 1.
Input parameters For Mercury Instruments 40-5702 TB4

Electrical Parameters	Div Marking	Zone Marking	Value
Maximum Input Voltage	V _{max}	UI	30V
Maximum Input Current	I _{max}	II	35mA
Maximum Input Power	PI	PI	1W
Maximum Internal Capacitance	CI	CI	0
Maximum Internal Inductance	LI	LI	0

TABLE 2.
Output parameters For Mercury Instruments 40-5702 TB4

Open Circuit Voltage	Voc	Uo	5.88V
Short Circuit Current	Isc	Io	32.67mA
Power Output	PO	PO	48.03mW
Maximum allowable Capacitance	Ca	Co	1uF
Maximum allowable Inductance	La	Lo	70mH

OPTION 2:
AS A SECOND OPTION THE TXD AND RXD LINES CAN BE CONNECTED WITHOUT CONDUIT VIA CSA CERTIFIED BARRIER HAVING PARAMETERS OF 9V MAX AND 90 ohms MIN SUCH AS MTL 7761 AC

11. USE OF THE MESSENGER MODEM 40-3000 HAS BEEN EVALUATED AND IS APPROVED FOR CLASS I, Div 2 HAZARDOUS LOCATIONS. POWER IS CONNECTED AS DISCUSSED IN NOTE 2. SERIAL CONNECTION IS BETWEEN EC 350 TB4 AND MESSENGER MODEM TB1, LAND LINE TELEPHONE LINE TO BE INSTALLED PER NOTE 1.

12. USE OF THE CN22e 22-2473 HAS BEEN EVALUATED AND IS APPROVED FOR CLASS I, Div 2 HAZARDOUS LOCATIONS. POWER IS CONNECTED AS DISCUSSED IN NOTE 2. SERIAL CONNECTION IS BETWEEN EC 350 TB5 AND CH22e TB2.

TABLE 1.
Input parameters For Mercury Instruments 40-5702 TB5

Electrical Parameters	Div Marking	Zone Marking	Value
Maximum Input Voltage	V _{max}	UI	10V
Maximum Input Current	I _{max}	II	50mA
Maximum Input Power	PI	PI	125mW
Maximum Internal Capacitance	CI	CI	4700pF
Maximum Internal Inductance	LI	LI	0

THE PARAMETERS OF THE CONNECTED IS APPARATUS MUST MEET THE FOLLOWING CONDITIONS:
 $V_{oc}/U_o \leq V_{max}/U_i$
 $I_{sc}/I_o \leq I_{max}/I_i$
 $C_a/C_o \geq C_i + C_{cable}$
 $L_a/L_o \geq L_i + L_{cable}$

CHA 1
 CHB 2
 CHC 3
 CHD 4
 CHD 5
 CHD 6
 CHD 7
 CHD 8


THIS DOCUMENT CONTAINS CONFIDENTIAL AND PROPRIETARY INFORMATION OF MERCURY INSTRUMENTS AND NEITHER IT NOR THE INFORMATION CONTAINED THEREIN SHALL BE DISCLOSED TO OTHERS OR DUPLICATED OR USED FOR OTHERS WITHOUT THE EXPRESS WRITTEN CONSENT OF MERCURY INSTRUMENTS

INSTALLATION DRAWING
CLASS I, Div 2
EC 350

MATERIAL: SBB
DATE: 04/27/2015
CHANGE NOTICE: 2015-1924

RELEASE: A
SBB
04/27/2015
2015-1924

SCALE: DWG SIZE: A
REV: A



CHAPTER 3

3 Securing the device

This chapter describes the different safety and security features of a EC350 device.

- [Case](#)
- [Metrological protection modes](#)
- [Defining access privileges](#)
- [Metrological configuration mode](#)
- [Validating setup configuration](#)

3.1 Case

The case can be locked or tamper sealed with a padlock or seal on the door hasp.

3.2 Metrological protection modes

Item classifications

- [Item classifications](#)
- [Access restriction Item 139 configuration options](#)
- [Event log full note](#)
- [Changing item 139](#)
- [Using MasterLink Software Application SQL to change item 139](#)

3.2.1 Item classifications

Each item has a fixed classification – one of those below. Contact Honeywell for classification of each item. These classifications pertain to the access restriction modes below.

Type	ICB Dump Terminology	When Writable	Changes Logged	Example
Always Writable	OPEN	Unless item 139 = 1 (Full Read Only)	If and only if item 139 = 0 or 3	Display list configuration
Read-Only	READONLY	Never (implicitly, per their function)	Never	Battery voltage
Change only if Event Logged	EVENT LOG	If not in Metrological Protection mode OR if event log not full	Always	Gas composition (item 53)
Change only if no restrictions	SEALED	Only if not in metrological protection mode	Always (if changed, but not possible unless 139=0)	Calibration

3.2.2 Access restriction Item 139 configuration options

Item 139	Type	Item Change Restrictions	Event Logging	Firmware Upgradable	Lock Icon
0	Unrestricted	All items (that are not Implicitly Read-Only) can be written.	All item changes are event logged.	Yes	Open
1	Full Read Only	No items may be written.	NA	No	Closed
2	Metrological Event Protection	OPEN items may be modified. SEALED items may not be modified. EVENT items may be modified only if the event log is not full of unread records. (Only log records that have been read can be overwritten.) (This mode corresponds to a Measurement Canada Type B Event Log.)	Only changes to EVENT items are logged. Changes to OPEN items are NOT logged.	No	Closed
3	Metrological Sealed	Only OPEN items may be modified.	All item changes are event logged.	No	Closed
4	Metrological Event Locked	OPEN items may be modified. SEALED items may not be modified. EVENT items may be modified only if the event log is not full of changes since put in protected mode. Reading Event Log has NO affect on allowing write access. Once event log is full of changes since it was put in protected mode (with item 139 change) no more changes to protected items are allowed until item 139 is set back to zero. (This mode corresponds to a Measurement Canada Type A Event Log.)	Only changes to EVENT items are logged. Changes to OPEN items are NOT logged.	No	Closed

3.2.3 Event log full note

In modes 2 and 4 (Metrological Event Protection and Metrological Event Locked), changes to EVENT items are blocked *before* overwriting the record that shows the item 139 write putting it into a protected mode. This allows verification that you are seeing *all* of the changes since it was put into a protected mode. In mode 2 it assures that the item 139 change is uploaded, and in mode 4 it assures that the item


139 change is visible in event log in the device.

3.2.4 Changing item 139

If item 139 is set to any value other than 0 (unrestricted) - it may not be changed unless the METROLOGICAL ACCESS JUMPER is OFF.


Attention: Firmware can be upgraded if either the override jumper is off OR if item 139 is set to unrestricted.

The METROLOGICAL ACCESS JUMPER is located in the lower right corner of the IO Board at the back of the case (labeled “METR JMPR”). If a sealing plate is in place that must first be removed.




3.2.5 Using MasterLink Software Application SQL to change item 139

- Establish a serial communication between EC350 and MasterLink Software Application SQL (4.41 or above). Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the MasterLink Software Application SQL window, click **Find Item by Number**  icon. The **Find Item** dialog box appears.
- Type **139** and click **OK**.
- The **Site Information** dialog box appears. The following image illustrates that the **Access Restriction** is set to **Metrological Protection**.



- Click **Change**. The **Change Item** dialog box appears.
- From the list, select **Unrestricted** and then click **Save**.



The Access Restriction is changed from Metrological Protection to Unrestricted.

- Disconnect the serial communication between the MasterLink Software Application SQL and EC350.
- Restore the METROLOGICAL ACCESS JUMPER.

3.3 Defining access privileges

Access to the EC350 can be controlled by defining users and assigning them passcodes and privileges. Use MasterLink Software Application SQL (4.41 and above) to set up a User Table and to download it to the device.

- [Default User Table](#)
- [Creating a user table file](#)
- [Sending a user table file](#)


3.3.1 Default User Table

User	Enabled	Passcode	Privileges
0	Yes	33333	All, HMI L3
1	Yes	33333	All, HMI L3
2	Yes	20000	All, HMI L2
3	Yes	30000	All, HMI L3
4-99	No		

Event log records reference this user ID, to identify who made configuration changes.

Full use of multi-user features requires host software supporting the SS protocol command. For backwards compatibility with host software that only supports the older SN sign on command (which does not support multiple users), the user 0 passcode is required for sign on via the SN command. In that case all configuration changes made through an SN sign on are attributed to user 0 in the event log records. The legacy item 196 (event log user ID) is not supported.

The screenshot below shows a typical User Table.



Valid user IDs are 0 through 99 (decimal numeric). Valid passcodes are 0 through 99999 (decimal numeric).

The following privileges can be granted or denied users:

- MODIFY OPEN ITEMS
- MODIFY EVENT ITEMS
- MODIFY SEALED ITEMS
- READ EVENT LOG
- USER TABLE DOWNLOAD
- HMI LEVEL 2 ACCESS
- HMI LEVEL 3 ACCESS


OPEN, EVENT, and SEALED are three classifications of items (the other classification is READONLY, which cannot be modified with any privilege).

A user granted level 3 HMI access will enter level 3 HMI menus after entering their user ID and password into the HMI (regardless of whether they are granted level 2 access). To allow a user to enter level 2, they must not be granted level 3 access. A single user can either have level 2 HMI access or level 3 HMI access or neither, but may not access both level 2 and 3.


3.3.2 Creating a user table file

To create a user table file:


- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Instrument > Edit User Table**.



- In the **User Table** dialog box, click **New**.



- Enter **User ID** and **Password** and select the privileges to want to grant to the user under **Privileges**.




- Click **Apply** to save the privileges for the newly created user.
- Click **Save**.
The **Save User Table File As** dialog box appears.
- Enter a filename and click **OK**.
The **Choose Password** dialog box appears.
- Enter a password and click **OK**. This password is required when you want to send the user table file.

3.3.3 Sending a user table file

To send a user table file:

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Transfer > Send User Table**.



The EC350 ships in unsecure mode with default passwords. Change the default passcodes at least to secure the device.

Note: For convenient device access by users choosing not to secure their devices, MasterLink Software Application SQL will attempt to access user 0 with the default passcode and will only prompt the user if that fails.

3.4 Metrological configuration mode

A special operational mode is available which may be useful when making configuration changes to an instrument already in service. Most changes would not require this, but if multiple changes are being made and there could be dependencies between those changes (in particular if the instrument would measure incorrectly if it received a volume pulse from the meter while the changes are still in progress – only partially completed). The mode is called Metrological Configuration Mode. In this mode, input volume pulses are queued but not processed, and Pressure and Temperature measurements are deferred. Processing continues normally after you exit the mode, with the queued input volume pulses handled per the new configuration.

You enter and exit the mode either through the HMI (L2.9 and L3.11 MET CONFIG), or through MasterLink Software Application by setting/clearing item 1239.

Note: The mode will also be exited automatically on an exit from HMI mode (either explicitly or by inactivity time-out) and likewise on a serial comm (MasterLink Software Application) disconnect from the instrument (either explicit or by inactivity time-out). (It will exit the mode on either HMI or Serial exit, regardless of which was used to activate the mode.)

3.5 Validating setup configuration

After installing EC350 on the meter and updating its configuration settings, ensure to perform the following final checkout tasks:

- Verify the pulse input. Refer to the section "[Testing the pulse input](#)".
- Verify corrected and uncorrected volume. Refer to the section "[Selecting the unit of measure](#)".
- Verify pressure/temperature factors. Refer to the section "[Verifying pressure](#)" or "[Verifying temperature](#)".

CHAPTER 4

4 Key features

This chapter describes the key features of an EC350 device.

- [Volume Measurement](#)
- [P-T-Z Measurement](#)
- [Meter Proving](#)
- [Alarms](#)
- [Logging](#)
- [Battery Life/Usage Tracking](#)
- [Display ON/OFF](#)

4.1 Volume measurement

EC350 generally operates in the Corrector mode. In this mode, EC350 receives and processes uncorrected volume, pressure, and temperature inputs to produce corrected volume information.

The following image illustrates a typical Corrector mode display.



- Top line of LCD display indicates the totalized corrected volume value.
- Second line indicates the corrected volume unit of measure (e.g. MCF).
- Third line indicates the item's name (e.g. CORVOL, which is corrected volume).
- Bottom line shows active icons to indicate various system status information.

4.1.1 Corrected volume

EC350 accurately measures and maintains the total uncorrected volume passing through the meter on which it is installed. In addition to the uncorrected volume, EC350 also computes the corrected volume.

The corrected volume is computed by multiplying a *total correction factor* by the uncorrected volume input from the meter.

EC350 maintains items called *Hi-Res* (High Resolution) volumes for indicating a fractional part of the corrected and uncorrected volumes that are not visible in the primary items (0 and 2).

Total Correction Factor = Temperature Factor X Pressure Factor X Auxiliary Factor (normally 1.0) X Squared Supercompressibility Factor.

EC350 supports a large range of units for measuring volume; some of them are as follows:

CF, CFx10, CFx100, CCF, CFx1000, MCF, CFx10000, m3x0.1, m3, m3x10, m3x100, and m3x1000.

You can independently configure corrected and uncorrected volume items.

4.1.2 Uncorrected volume

The gas flowing through rotary meter is measured by multiplying the input signals supplied by the two redundant volume sensors with the appropriate scaling factor (in item 114) for a particular rotary meter (selected in item 432). Generally, 114 value is set automatically when the meter model is selected, but 114 can also be set manually for other meters models.

Currently, EC350 supports over 140 meter models explicitly. Others can be supported with manual configuration.

4.1.3 Energy

In addition to the corrected and uncorrected volume, EC350 also calculates the energy (in item 140) corresponding to the corrected volume, based on a fixed user-configurable conversion factor (item 142).

EC350 supports a large range of units for measuring energy; some of them are as follows: Therms, Decatherms, Mega Joules, Giga Joules, Kilo Calories, and Kilo Watts.

Refer to the *Item Reference Guide* for information about *Energy (item 140)*, *Energy units (item 141)*, and *Gas energy value (item 142)*.

4.1.4 Volume statistics

The EC350 supports numerous gas volume statistical related items (Mins, Maxs, Peaks, Avgs) for Cor-Vol, Unc-Vol, Flow rate, and Dial rate.

Refer to “*Item Reference Guide*” for information about the gas volume statistical Items.

4.1.5 Volume Input Modes

Refer to the “*Item Reference Guide*” for information about Input volume mode (item 433) and Rotary Integral mount (item 432).

4.1.5.1 UMB, Instrument Drive & Remote input

EC350 supports gas volume measurement from UMB (Universal Mounting Bracket) and Instrument Drive interfaces. Select the meter model from the list provided from item 432. If the meter is not in the list, use item 433 to set selection: LF-UMB/Instrument Drive and configure meter index rate (item 98) and meter scaling (item 114) to match the application. Note that item 114 is typically set to value 1.000.

Note that two switch inputs are normally used in these applications to provide for switch input redundancy (one switch can backup the other).

4.1.5.2 Direct Rotary mount input

EC350 supports gas volume measurement from directly mounted Rotary meters. Select the meter model from the list provided from item 432. In doing so, the EC350 will automatically set items 114 to its proper value based on item 439. Note that item 98 is not used in Direct mount rotary and is assumed to be value 1.0 CF or 1.0 m3 depending on Volume units. Item 433 will also be set automatically to low resolution mode for rotary input. Low resolution rotary mode uses a pulse input divider to increase battery life while still providing adequate volume measurement resolution.

For direct-mount Rotary configurations only, EC350 also supports an option called high resolution mode for obtaining a higher degree of gas volume measurement resolution. Use the Input volume mode (item 433) for selecting the high resolution mode option. In this mode, EC350 measures the gas volume using a very low divider ratio for the input signals supplied by the two volume input sensors. In low resolution rotary mode, the divider ratio is much higher for making a sensible trade-off between the measurement resolution and the instrument battery life. High resolution mode is a useful test and verification tool for obtaining accurate volume measurement within a shorter period of time (less gas passing through the meter) – but consumes more battery power.

Note: EC350 battery life specifications are based on using the low resolution mode (not high resolution).

4.1.5.3 Bidirectional volume or Reverse flow

EC350 supports another volume input option called Bidirectional volume input mode (Reverse flow) for obtaining gas volume measurement in applications where flow direction is desired. Two configuration options are possible for Bidirectional volume modes: Forward direction = Clockwise rotation, and Forward direction = Counter-clockwise direction. Use the Input volume mode (item 433) for selecting either of these two input mode options.

Listed here are the main volume items used for Bidirectional mode:


- CorVol (item 000) – always counts up regardless of rotation direction
- UncVol (item 002) – always counts up regardless of rotation direction
- Forward CorVol (item 896) – counts up based solely on forward rotation direction per item 433 configuration
- Forward UncVol (item 898) – counts up based solely on forward rotation direction per item 433 configuration
- Reverse CorVol (item 902) – counts up based solely on reverse rotation direction per item 433 configuration


- Reverse UncVol (item 906) – counts up based solely on reverse rotation direction per item 433 configuration
- Net CorVol (item 900) – is the difference between Forward and Reverse Cor-Vol (item 896 – item 902)
- Net UncVol (item 904) – is the difference between Forward and Reverse Cor-Vol (item 898 – item 906)

Four switch sensors are utilized in Bidirectional volume mode to allow for direction detection as well as redundancy protection. If one of the four switch sensors is not detected after completing a full revolution, the EC350 will trigger a switch Alarm for that particular ‘missing’ switch sensor. For example: switch sensor input sequence of: 1-2-4-1-2... will trigger a Switch-3 sensor Alarm.

Attention: Three switch sensors are required to count volume input. If two switch sensors fail the EC350 will trigger a switch Alarm for the second ‘missing’ switch sensor and will then stop counting Volume input as it can no longer distinguish between back and forth partial rotations and full rotations. Example: switch sensor input sequence of: 1-3-1-3-1 can either be partial rotation or full rotation

Bidirectional volume mode has four switch sensors installed on the switch plate where standard UMB/ID input has only two switch sensors installed. Shown below is wiring and switch plate diagram for Bidirectional Volume. Also see: ‘section, “ [Changing the drive rotation](#) ”, to position the bevel-gear thimble of EC350 to ensure the reading rotates in the desired direction of rotation.






4.1.6 Volume switch filtering

After a long period of operation, some units experience a large number of unexpected spikes at volume inputs. To avoid this, enable the filtering feature by writing the value '1' (enable) to item i449.

4.1.7 Digital switch inputs

In EC350, Switch 3 (SW3) and Switch 4 (SW4) are primarily used for the reverse flow. If the reverse flow is not used, SW3 and SW4 can be configured as digital input alarm 1 and alarm 2. These digital input switch alarms can be configured using items i762 and i763.



Note: If the user wants to use SW3 and SW4 for reverse flow, the digital switch input alarms (i762 & i763) must be disabled.

4.2 P-T-Z Measurement

4.2.1 Gas Pressure

Gas pressure is measured on a time-based approach (every 30 seconds), as opposed to being based on volume input. With each 30 second measurement, the gas pressure correction factor is computed and high and low Pressure alarms are checked (regardless of flow rate conditions).

The EC350 uses a high resolution analog to digital conversion process to produce a very accurate final reading.

Up to two Pressure Transducer can be used with the EC350. The Pressure Transducer connected to the P1 input is used for computing the Gas pressure correction factor (item 044). If a second Pressure transducer is connected at P2 input, this serves to monitor pressure but is not used for correction. Gas pressure measurement can be disabled for either transducer by use of items 1052 (P1 Enable) or 1053 (P2 Enable).

The P4 is a virtual sensor connected to all pressure sensors. It calculates the pressure differences between any two pressure sensors.

See *Item Reference Guide* for information about the following pressure items and several other additional pressure Items.

- Gas Pressure (item 008)
- Gas Pressure units (item 087)
- Gas Pressure no. of decimal points (item 088)
- Pressure correction factor (item 044)
- Base Pressure (item 013)
- Atmospheric Pressure (item 014)
- Pressure Low alarm (item 143)
- Pressure Low alarm limit (item 011)
- Pressure High alarm (item 145)
- Pressure High alarm limit (item 010)

4.2.1.1 Gas Pressure statistics

EC350 supports various pressure statistical items.

Following are several of the P1 pressure statistical items:

- P1 Max pressure (item 285)
- P1 Max pressure date (item 287)
- P1 Max pressure time (item 286)
- P1 Min pressure (item 289)
- P1 Min pressure date (item 291)
- P1 Min pressure time (item 290)
- Prev day average P1 pressure (item 185)
- P1 Interval average pressure (item 206)
- P1 Interval high pressure (item 214)
- P1 Interval low pressure (item 215)
- P1 Daily average pressure (item 256)

Following are several of the P2 pressure statistical items:

- P2 Interval average pressure (item 421)
- P2 Interval high pressure (item 422)
- P2 Interval low pressure (item 423)
- P2 Daily average pressure (item 424)
- P2 Previous daily average pressure (item 425)
- P2 Max pressure (item 426)
- P2 Max pressure time (item 427)
- P2 Max pressure date (item 428)
- P2 Min pressure (item 429)
- P2 Min pressure time (item 430)
- P2 Min pressure date (item 431)

Note: The P3 pressure sensor is not applicable for the EC350 device.

Following are several of the P4 pressure statistical items:

- P4 RBX Deadband Pressure (item 1640)
- P4 Interval Average Pressure (item 1641)
- P4 Daily Average Pressure (item 1642)
- P4 Previous Daily Avg Pressure (item 1643)

- P4 Max Pressure (item 1644)
- P4 Max Pressure Time (item 1645)
- P4 Max Pressure Date (item 1646)
- P4 Min Pressure (item 1647)
- P4 Min Pressure Time (item 1648)
- P4 Min Pressure Date (item 1649)
- P4 Interval High Pressure (item 1650)
- P4 Interval High Pressure Time (item 1651)
- P4 Interval High Pressure Date (item 1652)
- P4 Interval Low Pressure (item 1653)
- P4 Interval Low Pressure Time (item 1654)
- P4 Interval Low Pressure Date (item 1655)
- P4 Day High Pressure (item 1656)
- P4 Day High Pressure Time (item 1657)
- P4 Day High Pressure Date (item 1658)
- P4 Day Low Pressure (item 1659)
- P4 Day Low Pressure Time (item 1660)
- P4 Day Low Pressure Date (item 1661)
- P4 Previous Day High Pressure (item 1662)
- P4 Previous Day High Pressure Time (item 1663)
- P4 Previous Day High Pressure Date (item 1664)
- P4 Previous Day Low Pressure (item 1665)
- P4 Previous Day Low Pressure Time (item 1666)
- P4 Previous Day Low Pressure Date (item 1667)

Note: P4 value shows an error code (9999) if any one of the sensor is disconnected.

4.2.1.2 Fixed Gas pressure

The EC350 can be configured to function as a fixed pressure device by setting item 109 to fixed pressure. In this mode, the pressure value configured in item 1161–Fixed pressure value (instead of the live pressure at item 8) is used for pressure correction.

Refer to *Item Reference Guide*” for information about the gas temperature statistical items.

4.2.2 Gas Temperature

EC350 Gas temperature is measured on a time-based approach (every 30 seconds), as opposed to being based on volume input. With each 30 second measurement, the gas temperature correction factor is computed and high and low Temperature alarms are checked (regardless of flow rate conditions).

The EC350 uses a high resolution analog to digital conversion process to produce a very accurate final reading.

Only one Temperature probe can be used with the EC350. The Temperature probe is used for computing the Gas temperature correction factor (item 045). Gas temperature measurement can be disabled for either transducer by use of item 1055 (T1 Enable).

Refer to “*Item Reference Guide*” for information about the following temperature items and several other additional temperature Items.

- Gas temperature (item 026)
- Gas temperature units (item 089)
- Temperature correction factor (item 045)
- Base temperature (item 034)
- Temperature low alarm (item 144)
- Temperature low alarm limit (item 027)
- Temperature high alarm (item 146)
- Temperature high alarm limit (item 028)

4.2.2.1 Temperature statistics

EC350 supports various gas temperature statistical items. Following are the supported gas temperature statistical items:

- Interval high gas temperature (item 216)
- Interval low gas temperature (item 216)
- Daily average gas temperature (item 257)
- Previous day gas temperature (item 186)
- Max gas temperature (item 293)
- Max gas temperature date/time (item 294/295)

- Min gas temperature (item 297)
- Min gas temperature date/time (item 298/299)

4.2.2.2 Fixed Gas temperature

The EC350 can be configured to function as a fixed temperature device by setting item 111 to fixed temperature. In that mode, the temperature value configured in item 1162–Fixed temperature value (instead of the live temperature at item 26) is used for temperature correction.

4.2.3 Supercompressibility

Gases actually behave in a manner slightly different from what the ideal gas laws indicate. This deviation depends on the molecular composition of the gas as well as the pressure and temperature. Natural gas, for instance, compresses by a greater amount than that computed by Boyle’s law and hence the term “supercompressibility” is used for this deviation. It is small at very low pressure, but becomes substantial as the pressure increases.

4.2.3.1 Supercompressibility Factor

Gases actually behave in a manner slightly different from what the ideal gas laws indicate. This deviation depends on the molecular composition of the gas as well as the pressure and temperature. Natural gas, for instance, compresses by a greater amount than that computed by Boyle’s law and hence the term “supercompressibility” is used for this deviation. It is small at very low pressure, but becomes substantial as the pressure increases. The EC350 automatically applies the supercompressibility factor and therefore the equation for total volume correction that EC350 applies to metered volume is expressed as:

$$V_b = V_m * F_p * F_t * (F_{pv})^2$$

Where:

- V_b (item 0) = volume corrected to base conditions
- V_m (item 2) = volume from the meter (at measured conditions)
- F_p (item 44) = pressure factor
- F_t (item 45) = temperature factor
- F_{pv} (item 47) = supercompressibility factor per NX-19 or AGA-8 standard (derived for orifice meters)
- $(F_{pv})^2$ (item 116) = supercompressibility factor used for diaphragm, rotary, and turbine meters

The EC350 can calculate the supercompressibility factor according to the following standards:

- AGA-8
 - Gross method 1
 - Gross method 2
 - Detail method
- NX-19

4.2.3.2 Item Description for Supercompressibility factors

Item Number	Item Description	NX-19	AGA-8 Gross Method1	AGA-Gross Method2	AGA-8 Detail
147	SuperCompress Tbl Used	✓	✓	✓	✓
53	Specific Gravity	✓	✓	✓	
142	Gas Energy Value		✓		
141	Gas Energy Units		✓		
54	% Nitrogen	✓		✓	✓
55	% Carbon Dioxide	✓	✓	✓	✓
373	% Methane				✓
374	% Ethane				✓
375	% Propane				✓
376	% Iso-Butane				✓
377	% N-Butane				✓
378	% Iso-Pentane				✓
379	% N-Pentane				✓
380	% N-Hexane				✓
381	% N-Heptane				✓
382	% N-Octane				✓
383	% N-Nonane				✓
384	% Hydrogen Sulfide				✓
385	% Hydrogen				✓
386	% Helium				✓
387	% Oxygen				✓
388	% Carbon Monoxide				✓
389	% Argon				✓

Item Number	Item Description	NX-19	AGA-8 Gross Method1	AGA-Gross Method2	AGA-8 Detail
390	% N-Decane				✓
391	% Water				✓
34	Base Temperature	✓	✓	✓	✓
13	Base Pressure	✓	✓	✓	✓
26	Flow Temperature*	✓	✓	✓	✓
8	Flow Pressure*	✓	✓	✓	✓
1161	Fixed Pressure Value*	✓	✓	✓	✓
1162	Fixed Temperature Value*	✓	✓	✓	✓

Note: (*) Items 8 and 26 are live readings (not user configurable). They are used for supercompressibility calculations when pressure and/or temperature calculations are “live” per items 109 and 111, respectively. If pressure and/or temperature is fixed, items 1161 and/or 1162 (user configurable fixed pressure and fixed temperature values, respectively) are used instead of items 8 and/or 26 in supercompressibility calculations.

4.3 Meter proving

The public utility commissions or various governmental regulations may require you to check the accuracy of the actual volume of gas flowing through a gas meter. Prover devices such as the Dresser Model 5 Prover and the Elster/American Meter SNAP Sonic Nozzle Prover are used for verifying the accuracy of the volume of gas flowing through a gas meter. Prover devices pass a known volume and temperature of gas through the meter being tested. They compare their own standard volume to the volume reported by EC350, which is mechanically connected to the rotary gas meter.

EC350 uses switch closure pulse counts for providing volume data to the Prover device. The meter bodies and EC350 are tested at various rates such as 10%, 50%, and 100% of rated capacity. You can connect EC350 to a prover to test both uncorrected and temperature corrected volumes.

EC350 has a special operating mode that makes meter proving process very easy and fast. This mode is called *Pushbutton Proving*. No special configuration settings are required to use the *Pushbutton Proving* feature of EC350.

- [Connecting the USB cable to the prover dongle](#)
- [Proving dongle indicators](#)
- [Starting Pushbutton proving](#)
- [Volume per proving output pulse](#)

4.3.1 Connecting the USB cable to the prover dongle

The following image illustrates a proving kit.



The proving kit includes the following components for connecting the EC350 to a Dresser Model 5 Prover:

- EC350 prover dongle
- Cable assembly (USB and Model 5 connectors)
- Magnetic coupler

4.3.1.1 Cable adapter for the SNAP prover system

The cable adapter assembly is used with an Elster/American Meter SNAP prover system. This cable adapter is included in the 40-4913-1 prover kit along with all of the components in the 40-4913 base prover kit. The following image illustrates the cable adapter for the SNAP prover system.



4.3.2 Proving dongle indicators

4.3.2.1 Proving dongle

The infrared prover dongle is a device that can be connected to the IrDA data port on EC350. It receives IR LED pulses from EC350 and converts the appropriate pulses into electronic switch contacts. This allows a rotary meter with the EC350 to be tested as a unit without breaking the meter seal. The following image illustrates an IR proving dongle.



Prover dongle indicators

The following image illustrates a prover dongle indicators.



- PULSE: A red light appears to indicate that the electronic switch to the Model-5 prover is closed.
- LINKED: A green light appears to indicate that EC350 and the prover dongle are synchronized. This must be ON when you are in the *Pushbutton Proving* mode.
- CPU OK: A yellow light appears to indicate that the prover dongle is powered and is operational. Ensure that the yellow light is always ON during operation. If the light goes off, it indicates that the prover dongle does not receive the 5V power supplied by the computer.

4.3.3 Starting Pushbutton proving

The basic operation of the *Pushbutton Proving* mode is as follows:

- The prover dongle receives uncorrected or temperature corrected volume in the form of infrared light pulses from EC350.
- The prover dongle converts the received infrared light pulses to electronic switch closure pulses that can be handled directly by the supplied prover.
- These electronic switch closure pulses are sent to the prover. Each electronic switch closure pulses represents either one (1), ten (10), or one hundred (100) cubic feet of gas volume, depending upon the model of the rotary meter.
- When EC350 is in *Meter Proving* mode, the volume pulse inputs from the meter are read at a much higher resolution than what is normally processed. This allows the most rapid proving cycle time for a given accuracy. Most proving runs can be accomplished within 60 seconds.
Attention: When EC350 is in *Pushbutton Proving* mode, the IrDA Serial communications are disabled. Before you enter the *Pushbutton Proving* mode, ensure that the prover dongle is connected to EC350.
 - [Entering Pushbutton Proving mode](#)

4.3.3.1 Entering Pushbutton Proving mode

To enter Pushbutton Proving mode:

- Unlock the keypad and type the **PASSCODE** to enter level 3 mode. Refer to the section “[level 3 mode](#)” for accessing level 3 mode. By default, in level 3 mode the following appears on the display.
MAIN MENU

ALARMS
- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 3 mode until **MTR PROVER** appears.
- Press **OK**. The following appears on the display.
UC

DIAL RATE

This represents the current meter Dial Rate for uncorrected volume.
- Press and hold **OK** for five seconds. The following message appears on the LCD.
PROVE

UC

This indicates that EC350 is in *Pushbutton Proving* mode.

- To exit uncorrected proving and proceed on with temperature corrected proving, press **OK**. The following message appears on the display.

UC

IDIAL RATE

- Press the **DOWN arrow**, the following appears on the display.

TC

IDIAL RATE

This represents the current meter Dial Rate for temperature corrected volume.

- Press and hold **OK** for five seconds. The following message appears on the LCD.

PROVE

TC

This indicates that EC350 is in *Pushbutton Proving* mode.

4.3.4 Volume per proving output pulse

In *Pushbutton Proving* mode, EC350 writes electronic switch closure pulses to the prover system with a predefined volume scaling factor of: one (1), ten (10), or one hundred (100) cubic feet (CF) of gas volume, depending upon the rotary meter model *Rotary integral mount (item 432)* . The following table represents the predefined volume scaling factor for the rotary meter models.

	Output Pulse Amount		
	1.0 CF	10.0 CF	100.0 CF
Dresser B3 Meters	B3 8C175 200	B3 23M175	
	B3 11C175 200	B3 23M232	
	B3 15C175 200	B3 38M175	
	B3 1M300	B3 56M175	
	B3 2M175 200		
	B3 3M175 300		
	B3 5M175		
	B3 7M175		
	B3 11M175		
	B3 16M175		
Dresser LMMA Meters	LMMA 1dot5M	LMMA 23M	LMMA 102M
	LMMA 2M	LMMA 38M	
	LMMA 3M	LMMA 56M	
	LMMA 5M		
	LMMA 7M		
	LMMA 11M		
	LMMA 16M		

	Output Pulse Amount		
	1.0 CF	10.0 CF	100.0 CF
Elster RPM Meters:	RPM 9C		
	RPM 1dot5M		
	RPM 2M		
	RPM 3dot5M		
	RPM 5dot5M		
	RPM 7M		
	RPM 11M		
	RPM 16M		
Romet RM Imperial Meters	RM600	RM38000	
	RM1000	RM56000	
	RM1500		
	RM2000		
	RM3000		
	RM5000		
	RM7000		
	RM11000		
	RM16000 24		
	RM16000 20		
	RM23000		
	RM25000		

	Output Pulse Amount		
	1.0 CF	10.0 CF	100.0 CF
Romet RM Metric Meters	RM16	RM700	
	RM30	RM1100	
	RM40	RM1600	
	RM55		
	RM85		
	RM140		
	RM200		
	RM300		
	RM450		
	RM650		
Romet G series Metric Meters:	G10	G400	
	G16	G400 150	
	G25	G650	
	G40	G1000	
	G65		
	G100		
	G160		
	G250		

4.4 Alarms

EC350 monitors a list of parameters and compares their measured values to configurable limits to determine if a fault condition has occurred. When any of these measured parameters has exceeded their respective limit, EC350 will create an Alarm.

EC350 currently supports monitoring eight (8) parameters and supplies an Alarm Item for each. Shown below are the eight Alarm Items.

Alarm Item	Alarm Item No.	Alarm Limit Item	Alarm Limit Item No.	Basic Operational Description
Battery Low	99	Battery Low Limit	49	Battery life remaining < set limit
Battery Cycles Alarm	100	Battery Months Remaining	1001	Battery life months remaining < set limit
Volume Sensor 1	102	n/a	n/a	Internal tests
Volume Sensor 2	103	n/a	n/a	Internal tests
System Alarm	104	n/a	n/a	Internal tests
Pressure Low	143	Pressure low limit	11	Gas pressure < set low limit
Pressure High	145	Pressure high limit	10	Gas pressure > set high limit
Temperature Low	144	Temperature low limit	027	Gas temperature < set low limit
Temperature High	146	Temperature high limit	028	Gas temperature > set high limit
Flow Rate high	163	Flow rate high limit	164	Flow rate > set high limit
Daily Cor volume	222	Daily cor volume limit	221	Daily CorVol > set limit
P2 Press High Alarm	451	P2 Press High Alarm Limit	455	Alarm is raised when P2 goes above its high limit
P2 Press Low Alarm	452	P2 Press Low Alarm Limit	456	Alarm is raised when P2 goes below its low limit
Extern Supply Low Alarm	796	External Supply Low Limit	795	Alarm is raised when external supply voltage goes below its low limit

Alarm Item	Alarm Item No.	Alarm Limit Item	Alarm Limit Item No.	Basic Operational Description
Super Compress Alarm	1025	n/a - internal error	n/a - internal error	Any one of several errors in super comp calculation process
Metro Cnfg Chng Alarm	1035	n/a - internal error	n/a - internal error	An attempt was made to change an item not appropriate for current metrological state / jumper
P1 Transducer Alarm	1058	n/a - internal error	n/a - internal error	Any one of several internal failures of pressure transducer
P2 Transducer Alarm	1059	n/a - internal error	n/a - internal error	Any one of several internal failures of pressure transducer
Temp Probe Alarm	1335	n/a - internal error	n/a - internal error	Any of several internal failures of probe itself
Comms Login Alarm	1388	n/a - internal error	n/a - internal error	Attempt to login serially with invalid credentials
HMI Login Alarm	1392	n/a - internal error	n/a - internal error	Attempt to login to HMI with invalid credentials
Alarm Log Record CRC Alarm	1409	n/a - internal error	n/a - internal error	if > 0, some number of corrupt records were encountered during record search/read
Event Log Record CRC Alarm	1410	n/a - internal error	n/a - internal error	if > 0, some number of corrupt records were encountered during record search/read
Audit Log Record CRC Alarm	1411	n/a - internal error	n/a - internal error	if > 0, some number of corrupt records were encountered during record search/read
Vol Sensor-3 Alarm	1424	n/a - internal error	n/a - internal error	malfunction indicated by volume sensor 3
Vol Sensor-4 Alarm	1425	n/a - internal error	n/a - internal error	malfunction indicated by volume sensor 4
P4 High Alarm Limit	1634	P4 Low Alarm Limit	1635	Alarm is raised when P4 goes above its high limit

Alarm Item	Alarm Item No.	Alarm Limit Item	Alarm Limit Item No.	Basic Operational Description
P4 Press High Alarm Time	1668	P4 Press Low Alarm Time	1670	Alarm is raised when P4 goes above its high alarm time
P4 Press High Alarm Date	1669	P4 Press Low Alarm Date	1671	Alarm is raised when P4 goes above its high alarm date
P4 High/High Alarm Limit	1672	P4 Low/Low Alarm Limit	1673	Alarm is raised when P4 goes above its high limit
P4 Press High/High Alarm	1674	P4 Press Low/Low Alarm	1677	Alarm is raised when P4 goes above its high alarm
P4 Press High/High Alarm Time	1675	P4 Press Low/Low Alarm Time	1678	Alarm is raised when P4 goes above its high alarm time
P4 Press High/High Alarm Date	1676	P4 Press Low/Low Alarm Date	1679	Alarm is raised when P4 goes above its high alarm date
P4 Transducer Alarm	1680	n/a - internal error	n/a - internal error	Any one of several internal failures of pressure transducer
P4 High Alarm Value	1683	P4 Low Alarm Value	1684	Alarm is raised when P4 goes above its high alarm value
P4 High/High Alarm Value	1685	P4 Low/Low Alarm Value	1686	Alarm is raised when P4 goes above its high alarm value

Report By Exception (RBX)

RBX (Report By Exception) is an alarm mode that is enabled via item 165. RBX controls the behavior of the following alarms.

- Pressure 1 High
- Pressure 1 Low
- Temperature High
- Temperature Low
- Pressure 2 High
- Pressure 2 Low
- Flow Rate High

When enabled, the RBX function automatically clears an instrument alarm after an alarm parameter has returned to its normal operating range, buffered by a user specified deadband (hysteresis). The deadband values are specified in items 166 (Pressure 1), 167 (Temperature), 169 (Flow Rate), and 459 (Pressure 2). When disabled, the alarms remain in their current state until the user manually clears it.

4.5 Logging


- [Audit Trail Logging Configuration](#)
- [Reading Audit Trail from the EC350](#)
- [Event logger](#)
- [Log record integrity verification](#)

4.5.1 Audit Trail Logging Configuration


Using MasterLink Software Application software, an EC350 device can be configured to contain as many as 5 independent logs, each with its own collection of item values and collection (sample) frequency. Each log can be configured to collect values for up to 20 items.

To configure logs:

- Ensure that MasterLink Software Application is linked to the EC350.
- In MasterLink Software Application , select **Instrument, Logging Configuration** and then **EC350**.




- Drag and drop the desired items from the Select Items list over to the log configuration tree.




In order to remove an item from the log configuration tree, highlight it and press the 'Delete' key.

- The order of the items in the Log Configuration list determines the order in which the values are stored and thus the order in which they will later appear in a report. Items in the list can be 'grabbed' and moved up and down to change the order.
- You can save a configuration for future reference to a configuration file (*.cnfg) with the Save setup to file button. It can later be retrieved with the **Read setup form file** button. Only *.cnfg files can be read; item files (*.ie3) are not compatible.
- You can right click on the time interval displayed in the Log Configuration tree, to configure the period at which log records are recorded.



- In the Allocate log memory tab, configure the percentage of available memory allocated to each log.



For each log, you can select the percentage of memory allocated, if fewer than 5 logs are desired the percent of the unused ones must be set to zero.

Note: The sum total of memory allocated for all logs must be equal to 100%.

The smaller a log's allocation, the less data it will be able to store. When the limit is reached, the oldest records will be overwritten with the newer ones. The consequence of a particular allocation setting is reflected in the number of **Days** worth of data as well as the Number of records that can be written before overwriting will occur.

Note: A log's interval setting will impact Days, but not **Numbers**.

- The Enable checkboxes may be used to suspend data collection for one or more logs. A log's existing records will not be affected when the log is disabled. The fact that a log is disabled will be reflected in the Log Configuration window by the presence of a red 'x' at the top of that log's item tree. In addition, the area for that log in the bar graphic will be grayed and marked as 'Disabled'
- Finally, click **Send to Instrument** to push the log configuration to the EC350 Device. A few seconds will be required for the transfer. A window should appear indicating 'Successfully Configured'.

4.5.2 Reading Audit Trail from the EC350

Once audit trail logging is configured and some amount of data has been collected, it may be transferred to the host. The process can be initiated from the Transfer menu or icon  using the Read Audit Trail Data window.

Read Audit Trail Data

Site Name: New Site
Site Id: 00000000 - 00000000

Date Range:

- Since **L**ast Download: 6/18/2015 2:07:00 PM
- Last **N** Days: 3
- Since:(mm/dd/yyyy) 6/26/2015 00:00:00
- From/To: (mm/dd/yyyy) 5/29/2015 06:00:00
5/30/2015 06:00:00

Log Selection:

- Log 1
- Log 2
- Log 3
- Log 4
- Log 5

Check All

Other Options:

- Download Item List

ENRON Conversion File Options:

- Include Conversion File
- New Events Only
- Old Events Only
- All Events

OK
Cancel

You must specify the number of logs to read and the amount of data to transfer. All configured and enabled logs can be checked in the **Log Selection frame**. If a log is not configured it cannot be checked. The amount of data is specified by date/time ranges. The simplest option is **Since Last Download**. The host will examine its database for the most recent record for each log for this instrument and construct a command to the EC350 for all data it has collected since then. Using this option each time will ensure that the host database contains a complete set of audit trail records for each log in each instrument. There are three other options if a specific data range of data is desired.

Note: Reading of audit trail records does not remove them from EC350's memory. They can be read any number of times until they are overwritten, as explained above.

Once MasterLink Software Application finishes reading all data for all logs the user is given the chance to view all the downloaded records. This is a useful practice to ensure that the transfer succeeded and that all the expected records were read.

- [Displaying/Viewing Audit Trail reports](#)

4.5.2.1 Displaying/Viewing Audit Trail reports

Note: This operation only involves the host computer and its database. No connection to an EC350 is necessary.

- In the MasterLink Software Application SQL window, click Reports and select one of the following options:
 - Audit Trail Report (With Summary)
 - Audit Trail Report (Without Summary)
 - Audit Trail Report (Summary Only)
 - Audit Trail Report (Daily Summary)
 - Audit Trail Report (Monthly Summary)

Based on the option selected, a corresponding dialog appears allowing the user to specify the Audit Trail data to view.

- Click the Select Sites button to browse to the desired EC350 unit by SITE ID/ Site name.
- Click on the Date Range tab to bring up a control window to select date range display options for the log report.
- Click Preview to view the Audit Trail report, or click the Print to send the report to a specified printer.

4.5.3 Event logger

The function of the Event Logger is to record configuration changes and significant system events. Each record includes:

- Date
- Time
- User ID
- Sequence Number (starts at 1, wraps from 65535 to 0)
- Before and After for changes made to instrument parameters.

Event Log capacity is 1024 records

See section Metrological Protection Modes for details of Event Log behavior in different item 139 modes.

- [Supported Event Codes](#)
- [Clearing Event Log](#)

4.5.3.1 Supported Event Codes

EVENT TYPE	EVENT
NON CAL ITEM CHANGE	0
CAL ITEM CHANGE	1
INSTR SHUTDOWN	3
DEFAULT BY ITEM 264	8
CLOCK TIME REPAIRED	10
EE MEMORY CORRUPT	11
UNEXPECTED RESETS	13
WATCHDOG RESET	14
CPU RESET	15
POWER CYCLE RESET	16
SYSTEM EVENTS DAILY LIMIT	23
BATTERY LIFE RESET	24
FIRMWARE UPGRADE	25

4.5.3.2 Clearing Event Log

To clear the event log:

Write a value of 19230429 to item 264 using **Setup > Advanced>Raw Instrument Access >Raw Item Access** in **MastgerLinkSQL**.

4.5.4 Log record integrity verification

Audit Trail and Event Log records have a CRC value associated with them to allow verification that they have not been corrupted or modified. CRCs of log records that have been uploaded to a computer using MasterLink Software Application SQL can be compared to log record CRCs displayed on the HMI. Since records cannot be modified in the device, the CRC values shown through the HMI are always correct and so if the CRC values shown in MasterLink Software Application SQL do not match, then the log record on the computer may have been corrupted or otherwise modified.

First view the log records uploaded with MasterLink Software Application SQL. Audit Trail record CRCs can be viewed through the Audit Trail CSD Conversion feature in the File menu. That outputs a Comma Separated Value file that includes the record CRC as transmitted by the device and also as computed by MasterLink Software Application SQL of the record as stored in the MasterLink Software Application SQL database. Event Log record CRCs can be viewed through the Event Log Report. In the report configuration, select the option to view the CRC values.

To view records in the HMI, select the corresponding menu item, select the desired log (Audit Trail 1 through 5, or Event Log), enter a Sequence Number for a record (as seen in MasterLink Software Application SQL). The corresponding record will be shown with the sequence number, the CRC value (in decimal), and the date and time of the record. (Other record values cannot be displayed via the HMI.

Compare the CRC value on the device display with the one in the Audit Trail CSD file or the Event Log report. The UP and DOWN arrow keys can be used to show the previous or next record.

4.6 Battery Life/ Usage Tracking

- **Alkaline Battery**– Item 48 tracks the Battery voltage and Item 49 is the configurable Low Limit for tripping a low Battery Alarm condition. Item 50 is the configurable Low Limit for putting the EC350 in to a low Battery ‘shutdown’ condition – ending most of its operations to greatly conserve the battery power.
- **Lithium Battery** - Items 1001 and 1002 indicate the remaining months and percentage of the Lithium Battery pack based on estimated ‘usage cycles’. Item 59 tracks the battery usage cycles – but only for a limited amount (mainly for testing purposes). Item 60 is the configurable Low Limit for tripping a low Battery Alarm condition based on too high of battery usage cycles. Item 59 value represents micro-Amp-seconds usage of the Battery.

Battery / External Supply Alarms – RBX Mode

- **Non-RBX Mode (Item 165 = 0)**– No automatic clearing of alarm condition. User must clear (acknowledge) the alarm condition of Item 99 or 796 before a new Alarm Log entry or timestamp update can be made for any subsequent Low Voltage Alarm conditions.
- **RBX Mode (Item 165 = 1)**– RBX Mode enabled will allow for automatic clearing of a Low Voltage alarm condition of Item 99 or 796 if the measured voltage reaches a value greater than 0.60 VDC above the Low Limit value in Item 49 or 795 respectively (Battery or External Voltage).

4.7 Display ON/OFF

The EC350 display can be configured to turn on and off at specific times during the day.

You can configure this in the MasterLink Software Application software using the following itemcodes:

Item Code	Name / Description	Default
1056	LCD display ON time	06 00 00
1057	LCD display OFF time	18 00 00

CHAPTER 5

5 User Access

This chapter provides an overview on using a EC350 device. It includes information on how to work with HMI displays and how the connections must be done between EC350 and MasterLink Software Application .

- [Getting started with the keypad](#)
- [Working with HMI](#)
- [Connecting to EC350 via MasterLink Software Application SQL](#)
- [Working with MasterLink Software Application SQL](#)
- [Working with PowerSpring](#)
- [Connecting EC350 with PowerSpring using a Messenger Modem](#)


5.1 Getting started with the keypad


Unlocking the keypad

- [Unlocking the keypad](#)
- [Human Machine Interface \(HMI\)](#)

5.1.1 Unlocking the keypad

Perform the following steps to unlock the keypad.

- Press and hold **ESC** and **UP arrow** ( ) at the same time until the following **Display test** appears.



- Press the **DOWN arrow** to enter Scroll List/ Meter Reader mode or press **OK** to access any one of the HMI keypad modes.

5.1.2 Human Machine Interface (HMI)

It provides access to the information about EC350. You can configure the information using the integral LCD panel and keypad. HMI keypad mode can be classified into the following four sub-levels.

- [Level 0 mode](#)- It is the scroll list mode where the customer-configured list of items appear on the display. No passkey is required to access this mode. After the keypad is active, use the **UP arrow** and **DOWN arrow** to scroll through the items in this mode. The items in this mode are read-only.
- [Level 1 read only mode](#)- It is used for viewing the instrument settings and live parameters. You do not require any passkey to access this mode. In this mode, the instrument functions are categorized into 11 submenus. By scrolling through the 11 submenus, you can view over 60 factory-defined instrument parameters. The items in this mode are read-only.
- [Level 2 mode](#)- It is used for accessing the less sensitive parameters and configuration options of EC350. This mode provides six submenus. You can view and configure the items in this mode by scrolling through the six submenus. A passkey is required to access this mode.

- [Level 3 mode](#)- It is used for accessing all the parameters, configuration, and functions of EC350. This mode provides nine submenus. A passkey is required to access this mode.
- [Level 0 mode](#)
- [Level 1 mode](#)
- [Level 2 mode](#)
- [Level 3 mode](#)

5.1.2.1 Level 0 mode

The level 0 mode is also known as the Scroll List Mode (or Meter Reader Mode). The following table lists the factory-default items that appear on the display when you enter the level 0 mode (in the order in which they appear as you press the **DOWN arrow**). This list is configurable. The *Configurable item* column identifies the item number at which each list item is programmed.

Scroll list	Displayed on LCD	Item description	Item code	Configurable item
1	UNCVOL	Uncorrected volume	002	130
2	CORVOL	Corrected volume	000	131
3	MTR MODEL	Meter model	077	132
4	P1 Pressure			
5	GAS TEMP	Gas temperature	026	76
6	REMAIN BAT	Remaining Battery		
7	PRESS FACT	Pressure factor	044	75
8	TEMP FACT	Temperature factor	045	77
9	TOTAL FACT	Total correction factor	043	78
10	HI RES CV	High resolution corrected volume	113	133
11	HI RES UV	High resolution uncorrected volume	892	134
12	MTR SCALING	Meter scaling	114	79
13	FW VERSION	Firmware version	122	80
14-18	Reserved		255	81-86


Using the UP arrow and DOWN arrow you can scroll through this list of item readings. The list (12 items) is configured using items 130 through 135 and items 075 through 086. All values that are displayed in

this mode are static readings, which means that they are sampled when you enter the level 0 mode and the displayed values will not change while you remain in the scroll list mode. Scroll List mode has a 60-second inactivity time-out. If you do not press any key for 60 consecutive seconds, EC350 exits the level 0 mode and returns to the normal Corrector mode.

Accessing level 0 scroll list mode

To access level 0 scroll list mode:

- Press and hold the **ESC** and **UP arrow** at the same time for about three seconds or until the following **Display Test** appears.



This unlocks the EC350 keypad and EC350 enters the HMI keypad mode.

- Press the **DOWN** arrow.
EC350 enters the level 0 mode.
- Use the **UP** arrow and **DOWN** arrow to scroll through the available menus.

Attention: When one of the arrows on the display disappears, it indicates that you have reached either the bottom or top of the scroll list, and therefore you must scroll the opposite direction..

- Press **ESC** to exit level 0 mode and return to the Corrector mode.

5.1.2.2 Level 1 mode


Level 1 mode provides read-only information on the following:

- Scroll list items
- Alarms
- Instrument
- Meter Info
- Volume
- Energy
- Pressure

- Temperature
- Supercompressibility
- Archives
- Communication Protocol
- Pulse Outputs

The level 1 mode is read-only mode where you can view alarms, firmware, and configuration information. Perform the following steps to enter the level 1 mode.

The following flowchart illustrates the items in level 1 mode.



The following table lists the factory-defined list for level 1 mode.

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.1	Security code	PASSKEY			

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.2	Alarm Information	ALARMS			Displays individual alarms. Press OK , the active alarms appear on the display. The individual alarm items are not displayed in the L1.2 menu, unless that particular alarm is active.
			BAT LO ALM	99	Battery Voltage Lo Alarm
			BAT WC ALM	100	Battery Consumption Hi Alarm
			SW-1 ALARM	102	Input Vol Switch-1 Fault Alarm
			SW-2 ALARM	103	Input Vol Switch-1 Fault Alarm
			SYS ALARM	104	System Error Alarm
			P LO ALARM	143	Gas Pressure Lo Alarm
			P HI ALARM	144	Gas Pressure Hi Alarm
			T LO ALARM	145	Gas Temperature Lo Alarm
			T HI ALARM	146	Gas Temperature Hi Alarm
			FLOW HI ALM	163	Flow Rate Hi Alarm

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
			DLY CV ALM	222	Daily CorVol Exceeded Alarm
			P2 LO ALRM	452	P2 Pressure Low Alarm
			P2 HI ALRM	453	P2 Pressure High Alarm
			EXTERN L AL	796	External Supply Low Voltage Alarm
			P1 XDCR AL	1058	P1 Transducer Alarm
			P2 XDCR AL	1059	P2 Transducer Alarm
			T PROBE AL	1335	T1 Probe Alarm
			SUPR ALAM	1025	Super Compressibility calculation Alarm
			COM LOG FL	1388	Serial Comms Login Failure (count)
			HMI LOG FL	1392	HMI Login Failure (count)
			LR CNFG AL	1035	Metrological Config Changed Alarm
			ALM LOG ER	1409	Alarm Log Record Error (CRC)
			EV LOG ER	1410	Event Log Record Error (CRC)
			AT LOG ER	1411	Audit Trail Record Error (CRC)
			SW-3 ALARM	1424	Input Vol Switch-3 Fault Alarm

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
			SW-4 ALARM	1425	Input Vol Switch-4 Fault Alarm
L1.3	Instrument Information	INSTRUMENT			Displays information about the instrument. Press OK . The following items appear on the display. Use UP arrow and DOWN arrow keys to scroll through the items.
			UNIT S/N	062	Unit Serial Number
			FW VERSION	122	Firmware Version
			SITE ID #1	200	Site Identification #1
			SITE ID #2	201	Site Identification #2
			CONV TYPE	1188	Volume Conversion Type
			DATE	204	Instrument Date
			TIME	203	Instrument Time
			BATT % REM	1002	Battery % Life Remaining
			BATT VOLTS	048	Battery Voltage Reading
			DEF DISPLAY	482	LCD Default Display
			BATT TYPE	1061	Battery Type
EXTERNL PWR	1046	External Supply Voltage			

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.4	Gas Meter Information	METER INFO			Displays information about the meter. Press OK , the following items appear on the display.
			MANUFACTUR	432	Meter Manufacturer
			MTR MODEL	432	Meter Model Number
			MTS S/N	1190	Meter Serial Number
			INPUT VOL	098	Input Volume Value
			MTR SCALNG	114	Meter Scaling Factor

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.5	Volume Information	VOLUME			Displays the gas volume and flow information. Press OK , the following items appear on the display.
			CORVOL	000	Corrected Volume Total
			UNCVOL	002	Uncorrected Volume Total
			DLY CORVOL	223	Daily Corrected Volume
			DLY UNCVOL	224	Daily Uncorrected Volume
			PRV DAY CV	183	Previous Day CorVol
			PRV DAY UV	184	Previous Day UncVol
			I FLOW RATE	209	Instantaneous Flow Rate
			AV FLOW RT	208	Average Flow Rate
			I DAIL RATE	218	Instantaneous Dial Rate
PK DIAL RT	219	Peak Dial Rate			

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.6	Energy Information	ENERGY			Displays the energy and heat information. Press OK , the following items appear on the display.
			ENERGY	140	Energy Total
			ENRGY UNIT	141	Energy Units
			E HEAT VAL	142	Gas Heat Value
			DLY ENERGY	190	Daily Energy
			PRVD ENRGY	191	Previous Day Energy

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.7	Pressure Information	PRESSURE			Displays the pressure information. Press OK , the following items appear on the display.
			GAS PRESS	008	Gas Pressure
			P RNG PSI	025	Press Transducer Range (psi)
			XDUCER TYP	112	Press Transducer Type
			PRESS UNIT	087	Pressure Units
			P-XDCR S/N	138	Press Transducer Serial No.
			PRESS FACT	044	Pressure Factor
			P-FAC CALC	109	Press Factor Calculation Type
			BASE PRESS	013	Base Pressure
			AMT PRESS	014	Atmospheric Pressure

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.8	Temperature Information	TEMPERATURE			Displays the temperature information. Press OK , the following items appear on the display.
			GAS TEMP	026	Gas Temperature
			T-PROB TYP	1185	Temp Probe Type
			T-PROB RNG	1186	Temp Probe Range
			TEMP UNITS	089	Temperature Units
			T-PROB S/N	1187	Temp Probe Serial No.
			TEMP FACT	045	Temp Factor
			T-FAC CALC	111	Temp Factor Calculation Type
			BASE TEMP	034	Base Temperature
			CASE TEMP	031	Case Temperature

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.9	Super-compressibility Information	SUPER INFO			Displays super-compressibility information. Press OK , the following items appear on the display.
			SUPER MTHD	147	Super Method
			SQ SU FACT	116	Squared Super Factor
			UNSQ S FAC	047	Un-squared Super Factor
			SPGR VALUE	053	Specific Gravity Value
			MOL %CO2	055	Mol. %CO2 Value
			MOL %N2	054	Mol. %N2 Value
			MOL %CH	373	MOL %CH Value
			MOL %C2H6	374	MOL %C2H6 Value
			MOL %C3H8	375	MOL %C3H8 Value
			MOL%iC4H10	376	MOL%iC4H10 Value
			MOL%nC4H10	377	MOL%nC4H10 Value
			MOL%iC5H12	378	MOL%iC5H12 Value
			MOL%nC5H12	379	MOL%nC5H12 Value
MOL %C6H14	380	MOL %C6H14 Value			
MOL %C7H16	381	MOL %C7H16 Value			

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
			MOL %C8H18	382	MOL %C8H18 Value
			MOL %C9H20	383	MOL %C9H20 Value
			MOL %H2S	384	MOL %H2S Value
			MOL %H2	385	MOL %H2 Value
			MOL %He	386	MOL %He Value
			MOL %O2	387	MOL %O2 Value
			MOL %CO	388	MOL %CO Value
			MOL %Ar	389	MOL %Ar Value
			MOL %C10H22	390	MOL %C10H22 Value
			MOL %H2O	391	MOL %H2O Value

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.10	Communication Protocol	COM PROTCL			Displays information about the communication protocol. Press OK, USR ACCESS appears on the display.
			USR ACCESS	139	User Access Type
			COMM BAUD	272	User Access Type
			COM FORMAT	995	Serial Comm Format
			COMM TYPE	1220	Serial Comm Type
			HANDSHAKE	1221	Serial Handshake Type
			COMWAKEUP	1219	Serial Wakeup Method
			TIMEOUT 2	172	Timeout Delay 2


Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
L1.11	Pulse Output	PULSE OUT			Displays Pulse Output channels' configuration information.
			CH-A SELCT	93	Pulse Channel A Selection
			CH-B SELCT	94	Pulse Channel B Selection
			CH-C SELCT	95	Pulse Channel C Selection
			CH-A TIME	1014	Pulse Channel A Timing
			CH-B TIME	1015	Pulse Channel B Timing
			CH-C TIME	1024	Pulse Channel C Timing
			CH-A PULSE	5	Pulse Channel A Value
			CH-B PULSE	6	Pulse Channel B Value
			CH-C PULSE	7	Pulse Channel C Value
L1.12	Cloud Link	CLOUD LINK	DEVICE S/N		
			RADIO IME		
			BATT TYPE		
			CHARGE AMT		Charge amount in percentage
			CHARGE TM		Charge amount in time
			BATT VOLTS		
			SCAP VOLTS		
			SSL STATUS		

Level 1 main menu ID number	Level 1 main menu categories	Level 1 main menu as displayed on LCD	Level 1 submenu as displayed on LCD	Item code	Description
			SSL-CERT		
			SIM CARD #		
			CARRIER ID		
			LAST RSSI		
			LAST IP AD		
			LAST IP PT		
			COMM STAT		
			CL CELL FW		
			MODEM TYPE		
			BLE SECURT		
			CL MAIN FW		
			FW CHKSUM		
			PULSE CNT		
			PAIRED DEV		

Accessing level 1 read only mode


To access level 1 read only mode:

- Press and hold the **ESC** and **UP arrow** at the same time for about three seconds or until the following **Display Test** appears.



This unlocks the EC350 keypad and EC350 enters the HMI keypad mode.

- Press **OK** to enter level 1 mode.




- Press the **DOWN arrow** to enter level 1 mode.
- Use the **UP arrow** and **DOWN arrow** to scroll through the main menu items (L1.2 through L1.11) in level 1 mode.
Attention: **L1.1 through L1.11 provides a numeric indicator of the menu item being accessed.**
- Press **OK** to select the necessary main menu item.
- After the main menu item is selected, use the **UP arrow** and **DOWN arrow** to scroll through the list of read-only items.
- Press **ESC** to return to the main menu item.
- From the main menu item, press **ESC** to exit level 1 mode.

5.1.2.3 Level 2 mode

Level 2 mode is the limited-access configuration mode and provides read-only information on the following:

- Passcode
- Alarms
- Clear Alarms
- Configuration
- Verify Pressure
- Verify Temperature
- Meter Prover
- Diagnostics

The following flowchart illustrates the main menus and submenus in the level 2 mode.



After you enter level 2 mode, the items listed in the table appear on the display; by default, **ALARMS** appear. Use the **UP arrow** and **DOWN arrow** to scroll through the items in level 2 mode.

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.1	PASSCODE				

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.2	ALARMS		Displays active alarms. Press OK The active alarms appear on the display.		
L2.3	CLR ALARMS		Allows you to clear the active alarms on the display. If the condition that caused the alarm is still present, a new alarm is activated on the next measurement.		
L2.4	CONFIG		Allows you to configure the Level 2 sub-menu 1 items.		
L2.4.1		ALARMS			
L2.4.1.1			LIMITS		
L2.4.1.1.1				P HI LIMIT	
L2.4.1.1.2				P LO LIMIT	
L2.4.1.1.3				T LO LIMIT	
L2.4.1.1.4				T HI LIMIT	
L2.4.1.1.5				BAT LO LIM	
L2.4.1.1.6				BAT MO LIM	
L2.4.1.1.7				FLOWHI LIM	
L2.4.1.1.8				D CV LIMIT	
L2.4.2		INSTRUMENT			
L2.4.2.1			SITE INFO		
L2.4.2.1.1				UNIT S/N	
L2.4.2.1.2				FW VERSION	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.2.1.3				SITE ID #1	
L2.4.2.1.4				SITE ID #2	
L2.4.2.1.5				CONV TYPE	
L2.4.2.1.6				DATE	
L2.4.2.1.7				TIME	
L2.4.2.1.8				DEF DISPLY	
L2.4.2.2			BATTERY		
L2.4.2.2.1				BAT MO LIM	
L2.4.2.2.2				REMAIN BAT	
L2.4.2.2.3				BATT % REM	
L2.4.2.2.4				BATT VOLTS	
L2.4.3		METER TYPE			
L2.4.3.1			DRESSER		
L2.4.3.1.1				I-D B3	
L2.4.3.1.2				I-D LMMA	
L2.4.3.1.3				ROT B3	
L2.4.3.1.4				ROT LMMA	
L2.4.3.2			ELSTER AMC		
L2.4.3.2.1				ROT RPM	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.3.2.2				I-D DIAPHR	
L2.4.3.2.3				I-D TURBIN	
L2.4.3.2.4				PULSE RABO	
L2.4.3.3			ROMET [®]		
L2.4.3.3.1				ROT RM IMP	
L2.4.3.3.2				ROT RM MET	
L2.4.3.3.3				ROT G MET	
L2.4.3.4			SENSUS		
L2.4.3.4.1				I-D DIAPHR	
L2.4.3.4.2				I-D ROTARY	
L2.4.3.4.3				I-D TURBIN	
L2.4.3.5			OTHER		
L2.4.3.5.1				I-D/PULSE	
L2.4.3.5.2				ROTARY MNT	
L2.4.4		VOLUME			
L2.4.4.1			INPUT TYPE		
L2.4.4.2			CORVOL		
L2.4.4.2.1				CORVOL	
L2.4.4.2.2				CV UNITS	
L2.4.4.2.3				CV DIGITS	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.4.3			UNCVOL		
L2.4.4.3.1				UNCVOL	
L2.4.4.3.2				UV UNITS	
L2.4.4.3.3				UV DIGITS	
L2.4.5		ENERGY			
L2.4.5.1			ENERGY		
L2.4.5.2			ENERGY UNIT		
L2.4.5.3			E HEAT VAL		
L2.4.6		PRESSURE			
L2.4.6.1			GAS PRESS		
L2.4.6.1.1				GAS PRESS	
L2.4.6.1.2				PRESS UNIT	
L2.4.6.1.3				P-DECIMALS	
L2.4.6.1.4				xDUCER TYP	
L2.4.6.1.5				P-RNG USER	
L2.4.6.1.6				P-XDCR S/N	
L2.4.6.1.7				PRESS FACT	
L2.4.6.1.8				P-FAC CALC	
L2.4.6.1.9				FIXED P	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.6.2			BASE PRESS		
L2.4.6.3			ATMS PRESS		
L2.4.7		TEMPERATUR			
L2.4.7.1			GAS TEMP		
L2.4.7.1.1				GAS TEMP	
L2.4.7.1.2				TEMP UNITS	
L2.4.7.1.3				T-PROB TYP	
L2.4.7.1.4				T-PROB RNG	
L2.4.7.1.5				T-PROB S/N	
L2.4.7.1.6				TEMP FACT	
L2.4.7.1.7				T-FAC CALC	
L2.4.7.1.8				FIXED TEMP	
L2.4.7.2			BASE TEMP		
L2.4.7.3			CASE TEMP		
L2.4.8		SUPER INFO			
L2.4.8.1			SUPER TYPE		
L2.4.8.2			SUPER FACT		
L2.4.8.2.1				SQ SU FACT	
L2.4.8.2.2				UNSQ S FAC	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.8.3			PARAMETERS		
L2.4.8.3.1				SPGR VALUE	
L2.4.8.3.2				MOL %N2	
L2.4.8.3.3				MOL %CO2	
L2.4.8.3.4				E HEAT VAL	
L2.4.8.3.5				MOL %H2	
L2.4.9		COM PROTCL			
L2.4.9.1			COM ACCESS		
L2.4.9.2			COM-1		
L2.4.9.2.1				COMM BAUD	
L2.4.9.2.2				COMM FORMAT	
L2.4.9.2.3				COMM TYPE	
L2.4.9.2.4				HANDSHAKE	
L2.4.9.2.5				COMMWAKEUP	
L2.4.9.2.6				TMOUT DEL1	
L2.4.9.2.7				TMOUT DEL2	
L2.4.10		PULSE OUT			
L2.4.10.1			CH-A		
L2.4.10.1.1				CH-A SELCT	

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.4.10.1.2				CH-A VALUE	
L2.4.10.1.3				CH-A TIME	
L2.4.10.2			CH-B		
L2.4.10.2.1				CH-B SELCT	
L2.4.10.2.2				CH-B VALUE	
L2.4.10.2.3				CH-B TIME	
L2.4.10.3			CH-C		
L2.4.10.3.1				CH-C SELCT	
L2.4.10.3.2				CH-C VALUE	
L2.4.10.3.3				CH-C TIME	
L2.4.11		CLOUD LINK			
L2.4.11.1			PULSE CNT		
L2.5	VERIFY P/T		Allows you to validate the accuracy of the pressure/temperature measured by EC350.		
L2.5.1		VALIDATE P	To verify or validate the accuracy of the items (for example, VALIDATE P); after the appropriate item appears on the display, Use the keypad to enter or change the value of pressure/ temperature that EC350 must measure. After you enter the value, press . The EC350 calculates the % ERROR.		
L2.5.2		VALIDATE T	%ERROR is the difference between the pressure/temperature value measured by EC350 and the value (the entered value) that EC350 must measure.		


Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.6	MTR PROVER				Allows you to check the accuracy of the actual volume of gas flowing through a gas meter. Press OK . The following items appears. UC IDIAL RATE - Uncorrected Input Dial Rate. TC IDIAL RATE - stands for Temperature Corrected Input Dial Rate. I FLOW RT - stands for Input Flow Rate.
L2.7	DIAGNOSTIC				Functions as a sensor, and ensures that the pulse inputs provided to EC350 are functioning.
L2.7.1		SENSOR TST			
L2.8	VIEW LOGS				Allows you to view a specified Log Record's Date, Time, and CRC value (in decimal).
L2.8.1		AT-LOG1			Actual Log Item Values are not available. This function is mainly to serve the needs of Compliance verification. Specify a Log Record number to begin and then press the Enter Key to view the actual record's parameters (Date, Time, and CRC).
L2.8.2		AT-LOG2			
L2.8.3		AT-LOG3			
L2.8.4		AT-LOG4			
L2.8.5		AT-LOG5			
L2.8.6		EVENT LOG			
L2.9	MET CONFIG				Special mode to make updates to Legally Relevant (metrological) type items.

Level 2 ID Nr	L2 main menu categories	L2 main menu as displayed on LCD	L2 submenu as displayed on LCD	Item code	Description
L2.10	SHUTDOWN				Special mode to take the unit out of service – i.e. to put in long term storage (shelf mode) Limited functionality is enabled in this mode –just time update. No volume or measurements are performed. HMI is active.
L2.11	BATT CHNG				Enter this mode when replacing the battery – includes resetting battery gauge.
L2.12	RESET BATT				Allows resetting the battery gauge (assumes installing a new battery).
L2.13	RESET COMMS				Resets Serial Comms – generally should not be needed.
L2.14	MODEM CALLS	ALARM CALL			Allows user to force an Alarm Call in to occur – assuming proper configurations
L2.15		SCHED CALL			Allows user to force a Scheduled Call in to occur – assuming proper configurations
L2.16		STOP CALLS			Allows user to cancel both Alarm and Scheduled Call retires – Note: does not disable Call-in
L2.17		BT PAIRING			
			BT PAIRING		
L2.18		FORGET DEV			
			YES /NO		

Accessing level 2 mode

To access level 2 mode:

- Press and hold the **ESC** and **UP arrow** at the same time for about three seconds or until the **Display Test** (all segments on) appears.



This unlocks the EC350 keypad and EC350 enters the HMI keypad mode.

- Press **OK** to enter level 2 mode.
The level 1 mode **PASSCODE** screen appears.



- To access the passkey screen, in level 2 mode press **OK**. The following appears on the display.
0000000
PASSCODE

For firmware versions before 1.0068, you must enter a five digit security code followed by a two digit user ID code to enter level 2 mode. The default value for the level 2 passcode is **20000**. The default value of the last two digit user ID is **00**. Enter a two digit user ID code followed by a five digit

security passcode to enter level 2 or level 3 mode. You can enter any value for the event log user ID. If the unit is configured to log events in an event log, the user ID identifies the user who made the changes in the event log.

For firmware version 1.0068 and later, of the 7 digits entered, the *first two* are the user id and the *last five* are the passcode. By default only user 02 is permitted access to Level 2. The default passcode is 20000, so the value entered would be 0220000. Other users can be granted access to level 2 menus, but a user can only access level 2 if they are **not** granted access to level 3. (A single user can access level 2, level 3, or neither, but cannot access *both* level 2 and level 3. Level 2 functionality is a subset of level 3 functionality.)

- To enter passcode, press the **UP arrow** or the **DOWN arrow** at the current position to change the displayed digit to the required numeral.
- For example, press the **UP arrow** twice at the current position, the value **0000000** changes to **2000000**.
- Press the **RIGHT arrow** to move one position to the right. Using the **UP arrow** or the **DOWN arrow** change the displayed digit to the required numeral.
- For example, press the **RIGHT arrow** until you reach the sixth digit. At the sixth digit press the **UP arrow** twice. The value **2000000** changes to **2000020**.
- Repeat this step until you enter the passcode of the instrument.
- To accept changes after entering the last digit (all seven digits of passcode), press the **RIGHT arrow**. Attention: You can also press **OK** for entering the passkey value.

The **OK** key enters the displayed digit at the current position and advances to the next position.

If the log in was successful, the display indicates that you are in level 2 mode. If the user ID or passcode were invalid, you will be returned to the main level 1 menu.


- Use the **UP arrow** and **DOWN arrow** to scroll through the main menu items (L2.2 through L2.7) in level 2 mode.
- Press **OK** to select the necessary main menu item.
- Use the **UP arrow** and **DOWN arrow** to scroll through the submenu items in level 2 mode.
- Press **OK** to select the necessary submenu.
- Press **ESC** to return to the main menu item.
- From the main menu item, press **ESC** to exit level 2 mode.

5.1.2.4 Level 3 mode

Level 3 mode is the limited-access configuration mode and provides read-only information on the following:

- Passcode
- Alarms
- Clear Alarms
- Configuration
- Advance Configuration
- Verify Pressure
- Verify Temperature
- Calibrate Pressure
- Calibrate Temperature
- Meter Prover
- Diagnostics
- Shutdown

The following flowchart illustrates the items in level 3 mode.



After you enter the level 3 mode, the items listed in the table appear on the display; by default, **ALARMS** appear. Use **UP arrow** and **DOWN arrow** to scroll through the items in the level 3 mode.

Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.1	PASS KEY				
L3.2	ALARMS		Displays active alarms. Press OK. The active alarms appear on the display.		
L3.3	CLR ALARMS		Clears the alarms. Press OK and then press YES to clear the alarms.		

Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.4	CONFIG		Allows you to configure the Level 3 submenu 1 items.		
L3.4.1		ALARMS			
L3.4.1.1			LIMITS		
L3.4.2		INSTRUMENT			
L3.4.2.1			SITE INFO		
L3.4.2.2			BATTERY		
L3.4.3		METER TYPE			
L3.4.3.1			DRESSER		
L3.4.3.1.1				I-D B3	
L3.4.3.1.2				I-D LMMA	
L3.4.3.1.3				ROT B3	
L3.4.3.1.4				ROT LMMA	
L3.4.3.2			ELSTER AMC		
L3.4.3.2.1				ROT RPM	
L3.4.3.2.2				I-D DIAPHR	
L3.4.3.2.3				I-D TURBIN	
L3.4.3.2.3				PULSE RABO	
L3.4.3.3			ROMET [®]		
L3.4.3.3.1				ROT RM IMP	
L3.4.3.3.2				ROT RM MET	
L3.4.3.3.3				ROT G MET	
L3.4.3.4			SENSUS		

Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.4.3.4.1				I-D DIAPHR	
L3.4.3.4.2				I-D ROTARY	
L3.4.3.4.3				I-D TURBIN	
L3.4.3.5			OTHER		
L3.4.3.5.1				I-D/PULSE	
L3.4.3.5.2				ROTARY MNT	
L3.4.4		VOLUME			
L3.4.4.1			INPUT TYPE		
L3.4.4.2			CORVOL		
L3.4.4.3			UNCVOL		
L3.4.5		ENERGY			
L3.4.5.1			ENERGY		
L3.4.5.2			ENERGY UNIT		
L3.4.5.3			E HEAT VAL		
L3.4.6		PRESSURE			
L3.4.6.1			GAS PRESS		
L3.4.6.2			BASE PRESS		
L3.4.6.3			ATMS PRESS		
L3.4.7		TEMPERATUR			
L3.4.7.1			GAS TEMP		
L3.4.7.2			BASE TEMP		
L3.4.7.3			CASE TEMP		
L3.4.8		SUPER INFO			
L3.4.8.1			SUPER TYPE		


Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.4.8.2			SUPER FACT		
L3.4.8.3			PARAMETERS		
L3.4.9		COM PROTCL			
L3.4.10		PULSE OUT			
L3.4.10.1			CH-A		
L3.4.10.2			CH-B		
L3.4.10.3			CH-C		
L3.4.11		CLOUD LINK			
			PULSE CNT		
L3.5	ADV CONFIG		<p>Allows you to enter the item number. Press OK. The following appears.</p> <p>ENTER</p> <p>ITEM NUMBR</p> <p>Using the keypad, you can enter the required item number. After you enter the item number, the respective item appears on the display. You can modify/set the value of the item. For example, if you enter the item number 0000008, GAS PRESS appears on the display.</p>		
L3.6	VERIFY P/T		Allows you to validate the accuracy of the pressure or temperature measured by EC350.		
L3.6.1		VALIDATE P	<p>Select VALIDATE P/VALIDATE T and press OK. Use the keypad to enter or change the value of pressure/ temperature that the EC350 must measure. After you enter the value, press OK. The EC350 calculates the % ERROR. %ERROR is the difference between the pressure/temperature value measured by EC350 and the value (the entered value) that EC350 must measure.</p>		
L3.6.2		VALIDATE T			
L3.7	CALIB P/T		Allows you to calibrate the pressure and temperature measured by EC350.		

Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.7.1		CALIB PRES			Select CALIB PRESS/CALIB TEMP and press OK. Use the keypad and enter the value of pressure/temperature that EC350 must measure. After you enter the value, press OK. The EC350 calculates the % ERROR. %ERROR is the difference between the pressure/temperature value measured by EC350 and the value (the entered value) that EC350 must measure. The calibration allows you to make changes to the instrument to bring the % ERROR to zero.
L3.7.2		CALIB TEMP			
L3.8	MTR PROVER				Allows you to check the accuracy of the actual volume of gas flowing through a gas meter. Press OK. The following items appear.
					UC IDIAL RATE
					TC IDIAL RATE
					I FLOW RT
					UC IDIAL RATE, stands for Uncorrected Input Dial Rate, TC IDIAL RATE stands for Temperature Corrected Input Dial Rate, and I FLOW RT stands for Input Flow Rate.
L3.9	DIAGNOSTIC				Functions as a sensor, and ensures that the pulse inputs provided to EC350 are functioning.
L3.9.1		SENSOR TST			
L3.10	VIEW LOGS				Allows you to view a specified Log Record's Date, Time, and CRC value (in decimal).
					Actual Log Item Values are not available. This function is mainly to serve the needs of Compliance verification. Specify a Log Record number to begin and then press the Enter Key to view the actual record's parameters (Date, Time, and CRC).
L3.10.1		AT-LOG1			
L3.10.2		AT-LOG2			
L3.10.3		AT-LOG3			
L3.10.4		AT-LOG4			
L3.10.5		AT-LOG5			

Level 3 ID Nr	L3 main menu categories	L3 main menu as displayed on LCD	L3 submenu as displayed on LCD	Item code	Description
L3.10.6		EVENT LOG			
L3.11	MET CONFIG				Special mode to make updates to Legally Relevant (metrological) type items.
L3.12	SHUTDOWN				Special mode to take unit out of service – i.e. to put in long term storage (shelf mode). Limited functionality is enabled in this mode – just time update. No volume or measurements are performed. HMI is active.
L3.13	BATT CHNG				Enter this mode when replacing the battery – includes resetting battery gauge.
L3.14	RESET BATT				Allows resetting the battery gauge (assumes installing a new battery)
L3.15	RESET COMMS				Resets Serial Comms – generally should not be needed
L3.16	MODEM CALLS	ALARM CALL			Allows user to force an Alarm Call in to occur – assuming proper configurations
L3.17		SCHED CALL			Allows user to force a Scheduled Call in to occur – assuming proper configurations
L3.18		STOP CALLS			Allows user to cancel both Alarm and Scheduled Call retires – Note: does not disable Call-in
L3.19	BT PAIRING				
		BT PAIRING			
L3.20	FORGET DEV				
		YES /NO			

To access level 3 mode:

- Press and hold the **ESC** and **UP arrow** at the same time for about three seconds or until the following **Display Test** (all segments on) appears.



This unlocks the EC350 keypad and EC350 enters the HMI keypad mode.

- Press **OK** to enter level 3 mode.
The level 3 mode **PASSCODE** screen appears.



- To access the passkey screen, in level 3 mode press **OK**. The following appears on the display.
0000000

PASSCODE appears.

For firmware versions before 1.0068, you must enter a five digit security code followed by a two digit user ID code to enter level 3 mode. The default value for the level 3 passcode is 30000. The default value of the last two digit user ID is 00. Enter a two digit user ID code followed by a five digit security passcode to enter level 2 or level 3 mode. You can enter any value for the event log user ID.

If the unit is configured to log events in an event log, the user ID identifies the user who made the changes in the event log.

For firmware version 1.0068 and later, of the 7 digits entered, the *first two* are the user id and the *last five* are the passcode. By default only user 03 is permitted access to Level 3. The default passcode for user 03 is 30000, so the value entered would be 0330000. Other users can be granted access to level 3 menus, but a user can only access level 2 if they are **not** granted access to level 3. (A single user can access level 2, level 3, or neither, but cannot access *both* level 2 and level 3. Level 2 functionality is a subset of level 3 functionality.)

- To enter the passcode, press the **UP arrow** or the **DOWN arrow** at the current position to change the displayed digit to the required numeral.
- For example, press the **UP arrow** thrice at the current position, the value **0000000** changes to **3000000**.
- Press the **RIGHT arrow** to move one position to the right. Using the **UP arrow** or the **DOWN arrow** change the displayed digit to the required numeral.
- For example, press the **RIGHT arrow** until you reach the sixth digit. At the sixth digit, press the **UP arrow** thrice. The value *3000000* is changed to *3000030*.
- Repeat this step until you enter the passcode of the instrument.
- To accept the changes after entering the last digit (all seven digits of passcode), press the **RIGHT arrow**.

Attention: You can also press **OK** for entering the passkey value.

The **OK** key enters the displayed digit at the current position and advances to the next position.

If the log in was successful, the display indicates that you are in level 3 mode. If the user ID or passcode were invalid, you will be returned to the main level 1 menu.

- Use the **UP arrow** and **DOWN arrow** to scroll through the main menu items (L3.2 through L3.10) in level 3 mode.
- Press **OK** to select the necessary main menu item.
- Use the **UP arrow** and **DOWN arrow** to scroll through the submenu items in level 3 mode.
- Press **OK** to select the required submenu.
- Press **ESC** to return to the main menu item.
- From the main menu item, press **ESC** to exit level 3 mode.

5.2 Working with HMI

Choosing the meter type

- [Choosing the meter type](#)
- [Verifying pressure](#)
- [Verifying temperature](#)
- [Testing the pulse input](#)
- [Entering the site ID](#)
- [Setting the date and time](#)
- [Selecting the unit of measure](#)
- [Single point temperature and pressure calibration](#)

5.2.1 Choosing the meter type

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “[Accessing level 2 mode](#)” for accessing level 2 mode or section “[Access level 3 mode](#)” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options until **METER TYPE** appears.

- Press **OK**.

The following default meter maker appears on the display.


METER TYPE

DRESSER

The following preconfigured types of makers of meters appear. Using the **UP arrow** and **DOWN arrow** scroll through the options.

- DRESSER
 - ELSTER AMC
 - ROMET
 - SENSUS
 - OTHER
- Press **OK** to select the required type of meter maker.
 - Using the **UP arrow** and **DOWN arrow** scroll through the options and press **OK** to select the required type of meter.

The following image illustrates the preconfigured types of meter makers and the meters available under each maker.



5.2.2 Verifying pressure

To verify the pressure:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **VERITY P/T** appears.

- Press **OK**. For example, the following appears on the display.

VERIFY P/T

VALIDATE P

- Press **OK**. The live pressure measurement made by the instrument appears on the display. For example:

51.00

PSI

LIVE PRESS

The pressure value that appears in this step is the value that EC350 reads.

- Press **OK**. For example, the following appears on the display.

50.00

PSI

INPUT REFP

- Enter the reference pressure (the actual/exact pressure being piped to EC350) using the keypad and press

OK.

The percentage difference between the pressure that EC350 reads and the reference pressure appears on the display. For example:

2.00

% ERROR LIVE

PRESS

- Press **OK**. The control returns back to the following:

VERIFY P/T

VALIDATE P

5.2.3 Verifying temperature

To verify the temperature:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **VERIFY P/T** appears.

- Press **OK**. The following appears on the display.

VERIFY P/T

VALIDATE P

- Press the **DOWN arrow**, the following appears on the display.

VERIFY P/T

VALIDATE T

- Press **OK**, the temperature read by EC350 appears on the display.

For example:

75.20

F

LIVE TEMP

Here, **75.20** is the value that EC350 reads and **F** stands for the unit of temperature that is Fahrenheit.

- Press **OK**. The following appears on the display.

75.20

F

INPUT REFT

Here, **REFT** stands for reference temperature.

- Enter the reference temperature (the temperature that EC350 must read) by using the keypad and then press **OK**.

The percentage difference between the temperature that EC350 reads and the reference temperature appears on the display. For example, the following appears.

0.04

% ERROR LIVE

TEMP

- Press **OK**, the control returns back to the following:

VERIFY P/T

VALIDATE T

5.2.4 Testing the pulse input

To test the pulse input:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **DIAGNOSTIC** appears.

- Press **OK**.

By default, the following appears on the display.

DIAGNOSTIC SENSOR TST

- Press **OK**. The following appears on the display.

0 0

ERR CNTS

SENSOR TST

Ensure that the value of **ERR** remains zero +/- one count, whereas the value of **CNTS** must increase with each volume input.

5.2.5 Entering the site ID

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.
- By default, in level 2 mode or level 3 mode the following appears on the display.
MAIN MENU

ALARMS
- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.
- Press **OK**. The following appears on the display.
CONFIG

ALARMS
- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **INSTRUMENT** appears.
- Press **OK**.
The following appears on the display.
INSTRUMENT

SITE INFO
- Press **OK**, the following appears on the display.
UNIT S/N
- Using the **UP arrow** and **DOWN arrow** scroll through the options until **SITE ID #1** appears.
- To change the **SITE ID #1**, press **OK** and then using the keypad enter the eight-digit **SITE ID**.
- **SITE ID** is in addition to the **UNIT S/N**. Follow the site-specific rules for configuring the site ID number.
- Once you enter all the eight digits, press **OK**.

5.2.6 Setting the date and time

- [Setting the date](#)
- [Setting the time](#)

5.2.6.1 Setting the date

To set the date:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “[Accessing level 2 mode](#)” for accessing level 2 mode or section “[Access level 3 mode](#)” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **INSTRUMENT** appears.

- Press **OK**.

The following appears on the display.

INSTRUMENT

SITE INFO

- Press **OK**, the following appears on the display.

UNIT S/N

- Using the **UP arrow** and **DOWN arrow** scroll through the options until **DATE** appears.

- Press **OK**.

- Using the keypad set the **DATE** and press **OK**.

5.2.6.2 Setting the time

To set the time:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **INSTRUMENT** appears.

- Press **OK**.

The following appears on the display.

INSTRUMENT

SITE INFO

- Press **OK**, the following appears on the display.

UNIT S/N

- Using the **UP arrow** and **DOWN arrow** scroll through the options until **TIME** appears.

- Press **OK**.

- Using the keypad set the **TIME** and press **OK**.

5.2.6.3 Auto set date and time

At regular intervals, the date and time information for the EC350 device is logged in audit logs. Whenever there is a power reboot, the device retains the date and time from the last saved audit log.

If the device retains the date and time from the audit log, the HMI display shows as **FIX Date and TIME**.

- Click **FIX Date and TIME** to sync the date and time manually through the Masterlink. (or)
- The device automatically syncs with the server on the next successful **Call In**.

5.2.7 Selecting the unit of measure

Using EC350 you can select the unit of measurement for volume (corrected and uncorrected volume), energy, pressure, and temperature.

- [Selecting the unit of measurement for volume](#)
- [Selecting the unit of measurement for energy](#)
- [Selecting the unit of measurement for pressure](#)
- [Selecting the unit of measurement for temperature](#)

5.2.7.1 Selecting the unit of measurement for volume

To select the unit of measurement for volume:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **VOLUME** appears.

- Press **OK**.

By default, following appears on the display.

VOLUME

INPUT TYPE

- Press the **DOWN arrow** key.

The following appears on the display.

VOLUME

CORVOL

- For corrected volume, press **OK**.

By default, the following appears on the display.

00000000

CCF CORVOL

- To select the unit for corrected volume, press the **DOWN arrow** key.

The following appears on the display.

5

CCF

CV UNITS

- Press **OK** and then using the **UP arrow** and **DOWN arrow** increase or decrease the value of Code.

The corresponding unit associated with the code appears. For example, **Code 0** represents **CF**.

Following are the codes and the corresponding units of measurement for **VOLUME**.

Code	Units
Code 0	CF
Code 1	CFX10
Code 2	CFX100
Code 3	CFX1K
Code 4	CFX10K
Code 5	CCF
Code 6	MCF
Code 7	M3X0.1
Code 8	M3
Code 9	M3X10
Code 10	M3X100
Code 11	M3X1K

- Press **OK** to select the required unit.
For example, if you press **OK** at Code 0, CF is selected as the unit of corrected volume.
- Repeat step 6 through step 10 for selecting the unit for uncorrected volume. Selecting the unit of measurement for energy

5.2.7.2 Selecting the unit of measurement for energy

To select the unit of measurement for energy:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Level 2 mode](#) ” for accessing level 2 mode or section “ [Level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **ENERGY** appears.

- Press **OK**.

By default, the following appears on the display.

00000000

THERMS

ENERGY

- Press the **DOWN arrow** key.

The following appears on the display.

THERMS

ENERGY UNIT

- Press **OK** and then using the **UP arrow** and **DOWN arrow** increase or decrease the value of **Code**. The corresponding unit associated with the code appears. For example, **Code 0** represents **THERMS** .

Following are the codes and the corresponding units of measurement for **ENERGY**.

Code	Units
Code 0	THERMS
Code 1	DECATHERMS
Code 2	MEGAJOULES
Code 3	GIGAJOULES
Code 4	KILOCALS
Code 5	K-WATT HRS

- Press **OK** to select the required unit.
For example, if you press **OK** at Code 0, THERMS is selected as the unit of **ENERGY**.

5.2.7.3 Selecting the unit of measurement for pressure

To select the unit of measurement for pressure:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **PRESSURE** appears.

- Press **OK**.

By default, the following appears on the display.

PRESSURE

GAS PRESS

- Press **OK**.

By default, the following appears on the display.

0

PSI

GAS PRESS

- Press the **DOWN arrow** key.

The following appears on the display.

0

PSI

PRESS UNIT

- Press **OK** and then using the **UP arrow** and **DOWN arrow** increase or decrease the value of **Code**. The corresponding unit associated with the code appears. For example, **Code 0** represents **PSI**.

Following are the codes and the corresponding units of measurement for **PRESSURE**.

Code	Units
Code 0	PSI
Code 1	kPa
Code 2	mPa
Code 3	Bar
Code 4	bar
Code 5	KGcm2
Code 6	In WC
Code 7	In HG
Code 8	mm HG

- Press **OK** to select the required unit.
For example, if you press **OK** at Code 0, PSI is selected as the unit of **PRESSURE**.

5.2.7.4 Selecting the unit of measurement for temperature

To select the unit of measurement for temperature:

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, in level 2 mode or level 3 mode the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **CONFIG** appears.

- Press **OK**. The following appears on the display.

CONFIG

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options until **TEMPERATURE** appears.

- Press **OK**.

By default, the following appears on the display.

TEMPERATURE

GAS TEMP

- Press **OK**.

By default, the following appears on the display.

60.00

F

GAS TEMP

- Press the **DOWN arrow** key.

The following appears on the display.

F

TEMP UNITS

- Press **OK** and then using the **UP arrow** and **DOWN arrow** increase or decrease the value of **Code**. The corresponding unit associated with the code appears. For example, **Code 0** represents **F**.

Following are the codes and the corresponding units of measurement for **PRESSURE**.

Code	Units
Code 0	F
Code 1	C
Code 2	R
Code 3	K

- Press **OK** to select the required unit.

For example, if you press **OK** at Code 0, F is selected as the unit of **TEMPERATURE** .

5.2.8 Single point temperature and pressure calibration

- [Calibrating temperature](#)
- [Calibrating pressure](#)

5.2.8.1 Calibrating temperature

To calibrate temperature:

- Unlock the keypad and type the **PASSCODE** to enter level 3 mode. Refer to the section “ [Access level 3 mode](#) ” for accessing level 3 mode.

- By default, the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 3 mode until **CALIB P/T** appears.

- Press **OK**. The following appears on the display.

CALIB P/T

CALIB PRES

- Press the **DOWN arrow**, the following appears on the display.

CALIB P/T

CALIB TEMP

Press **OK**, the temperature read by EC350 appears on the display.

For example:

75.20

F

LIVE TEMP

Here, **75.20** is the value that EC350 reads and **F** stands for the unit of temperature that is Fahrenheit.

- Press **OK**. The following appears on the display.

75.20

F

INPUT REFT

Here, **REFT** stands for reference temperature.

- Enter the reference temperature (the temperature that EC350 must read) by using the keypad and then press **OK**.

The percentage difference between the temperature that EC350 reads and the reference temperature appears on the display. For example, the following appears.

0.04

% ERROR LIVE TEMP

- Press **OK**, the control returns back to the following:

CALIB P/T

CALIB TEMP

5.2.8.2 Calibrating pressure

To calibrate pressure:

- Unlock the keypad and type the **PASSCODE** to enter level 3 mode. Refer to the section "Accessing level 3 mode " for accessing level 3 mode.
- By default, the following appears on the display.

MAIN MENU

ALARMS

- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 3 mode until **CALIB P/T** appears.
- Press **OK**. The following appears on the display.

CALIB P/T

CALIB PRES

- Press **OK**, the pressure read by EC350 appears on the display.

51.00

PSI

LIVE PRESS

The pressure value that appears in this step is the value that EC350 reads.

- Press **OK**. The following appears on the display.

50.00

PSI

INPUT REFP

- Enter the reference pressure (the actual/exact pressure being piped to EC350) using the keypad and press **OK**.

The percentage difference between the pressure that EC350 reads and the reference pressure appears on the display. For example:

2.00

% ERROR

LIVE PRESS

- Press **OK**, the control returns back to the following:

CALIB P/T

CALIB TEMP

5.3 Connecting to EC350 via MasterLink Software Application SQL

- [About MasterLink Software Application SQL software](#)
- [Connecting the IrDA communication USB dongle to the computer](#)
- [Connecting the IrDA communication USB dongle to EC350](#)
- [Signing on to the EC350](#)
- [Updating EC350 firmware](#)

5.3.1 About MasterLink Software Application SQL software

MasterLink Software Application SQL is a communication software package that enables interaction with EC350. Using MasterLink Software Application SQL you can:

- Configure EC350 to meet particular needs.
- Calibrate EC350.
- Read the collected data such as volumes, pressures, temperature, and alarms.
- Generate reports for the collected data.
- Provide computer to instrument communication. Computer to instrument communication can be through the IrDA (infrared) port on the front panel, an optional direct serial link (RS-232/485), modem (CNI2 for cellular or Messenger for land line).

5.3.2 Connecting the IrDA communication USB dongle to the computer

To connect the IrDA communication USB dongle to the computer, insert the IrDA USB dongle in the USB port of the computer.

If the IrDA USB dongle is connected properly, a small LED on the dongle flashes intermittently, which indicates that the computer can communicate with the IrDA USB dongle. Using the MasterLink Software Application SQL communications configuration menu, confirm that the IrDA interface has been configured properly.

5.3.3 Connecting the IrDA communication USB dongle to EC350

To connect the IrDA communication USB dongle to EC350

- Insert the dongle into the magnetic pipe boot. Ensure that the cable passes through the hook provided in the magnetic pipe boot to prevent the dongle from displacing.
- Place the boot on EC350. Ensure that the leg of the boot is above the eyebrow.

The following image illustrates the IrDA communication USB dongle connected to EC350.



5.3.4 Signing on to the EC350

Open MasterLink Software Application SQL and fill in any fields in the opening screen. You can connect to a specific site through the Site List (this is required for remote connections through a modem), or, for local connections you can simply request some operation and MasterLink Software Application SQL will initiate the connection automatically.

If requested, enter a user ID and passcode. Your organization should provide you with this information. User ID can be any value from 0 to 99. By default only users 0 through 3 are activated. Passcode can be any value 0 to 99999. Given below are the default passcodes for users 0 to 3.

Table 1.

User	Default passcode
User 0 and 1	33333
User 2	20000
User 3	30000

Default users 2 and 3 are primarily intended for HMI access (levels 2 and 3 respectively) but serial access with MasterLink Software Application SQL through those users is also possible with those passcodes.

5.3.5 Updating EC350 firmware

EC350 is provided with a built-in firmware loader that allows new versions of firmware to be installed easily. Firmware can be upgraded using the Firmware Upgrader option available in the MasterLink Software Application SQL software. When you select this option, the MasterLink Software Application SQL software works with the built-in loader of EC350 and provides a very robust system for upgrading the EC350 firmware.

The firmware upgrade is performed through the IrDA serial interface that is used by the MasterLink Software Application SQL software. The IrDA serial interface provides an electrically isolated interface and requires no additional hardware or software beyond what is already needed to utilize the MasterLink


Software Application SQL software. (Firmware upgrades can also be performed over the RS-232 port but not the RS-485 port.)

CAUTION:


It is important that you read all items and logs (audit trail logs, event log, alarm log) before performing a firmware upgrade because most items will be set to default values and the audit trail logs will be erased.

Running Firmware Upgrader

- In the MasterLink Software Application SQL window, click **Instrument > Firmware Upgrader**.



The **Firmware Upgrader** dialog box appears.




- To select the firmware file, click **Browse** and navigate to the path where the EC350 firmware file is saved.


- From the **Serial Port** list, select **USB IrDA**.
Ensure to select the proper serial port for communicating with EC350.
- Select the **Set instrument's date and time** check box.
- Click **Start Upgrade**.
The program begins to read the current item file from EC350. The **WARNING** dialog box appears.



- Click **OK** only if you have saved ALL (Calibration and non-Calibration) items in EC350.
The program begins to load the new firmware and then validates its integrity. Once the firmware is validated, the firmware is sent to the MasterLink Software Application SQL software, as illustrated in the following image.
- Click **OK** only if you have saved ALL (Calibration and non-Calibration) items in EC350.
The program begins to load the new firmware and then validates its integrity. Once the firmware is validated, the firmware is sent to the MasterLink Software Application SQL software, as illustrated in the following image.



- After the upgrade is complete, **Upgrade was successful** (in green) appears at the lower left corner of the main **Firmware Upgrader** dialog box.



- Click **Exit** to close the **Firmware Upgrader** dialog box.

5.3.6 Force schedule Call-In Time After FW Update

If the device date and time are not set within the configured time after updating the firmware, the device initiates **Force Schedule Call-In Time Aft FW Update (i1694)** with the server to load the previous or backup item values.

5.4 Working with MasterLink Software Application SQL


- [Items by function](#)
- [Setting time and date](#)
- [Item files](#)
- [Calibrating pressure](#)
- [Calibrating PLog pressure](#)
- [Calibrating temperature](#)
- [Configuring the Meter reader list](#)
- [Configuring Call in feature](#)

5.4.1 Items by function

To select items (for viewing and modifying) by their functional categories:

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the MasterLink Software Application SQL window, click **Display > Items by Function**.

The **Display/Change Items By Function** dialog box appears.



You can select and configure all the items that are displayed in the **Display/Change Items By Function** dialog box.

For example, if you want to configure **Volume & Energy**, perform the following:

- Select **Volume & Energy** and click **OK**. The **Volume & Energy** dialog box appears.
- Select Corr Volume Units and click **Change**. The **Change Item** dialog box appears.
- From the list, select the required unit for volume and then click **Save**.

Similarly you can select and configure all the items in the **Volume & Energy** dialog box.

Attention: Follow the same procedure to change other functions.

5.4.2 Setting time and date

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the MasterLink Software Application SQL window, click on **Instrument > Set Instrument Date and Time via Computer** to update EC350 with the current PC's date and time. A dialog appears allowing the user to accept the date and time update.
- Click the **Yes** button to proceed with the Date/Time update. MasterLink Software Application SQL will always re-read the PC's clock date and time just before sending the data packet over to EC350.

5.4.3 Item files

- [Reading/Creating item files](#)
- [Displaying/Viewing item files](#)

5.4.3.1 Reading/Creating item files

To read or create item files:

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the MasterLink Software Application SQL window, click the ITEM  icon. The **Select Destination for Item File** dialog box appears.
- Select a location and enter the name of the file. MasterLink Software Application SQL will automatically name the file if one is not entered.
- Click **Save**.
MasterLink Software Application SQL proceeds to read all of the items values from the connected EC350 unit.

5.4.3.2 Displaying/Viewing item files

To display or view item files:


- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the MasterLink Software Application SQL window, click on **Reports > Items Report** to view any item file previously read from EC350.
The **Item Report** dialog box appears.
- Click **Select** and browse to the file you want to view
- Click **Preview** to view the item report, or click the **Print** to send the item file report out to a specified printer

5.4.4 Calibrating pressure

Attention: Check the sensors before calibrating pressure.

To calibrate pressure:

- In the **MasterLink Software Application SQL** window, click **Calibrate > Pressure** .
The **Pressure 1** dialog box appears.



- Apply a zero reference pressure (0.00 PSI) to the P1 pressure transducer of EC350. Wait for the pressure reading displayed on the **Pressure 1** dialog box to stabilize.
- After the reading stabilizes, click **Average Pressure Now** .
MasterLink Software Application SQL averages the reading and displays the average pressure.

- Click **Change**.

The **Change Pressure Calibration Value** dialog box appears.

- Change the value to accurately match the zero reference pressure applied to the pressure transducer.
- Click **OK**.
- Click **Span Calib**.

The **Pressure 1 Span Calibration** page appears.

Num	Description	Value	Units
087	Pressure Units	PSI	
137	Pressure Range User	30.00	PSI
014	Atmospheric Pressure	14.7300	PSI
013	Base Pressure	14.7301	PSI
112	P Transducer Type	Gauge	
017	Pressure Cal Zero	0.0000	PSI
018	Prev1 Pressure Cal Zero	0.0000	PSI
020	Pressure Cal Span	1.0000	
120	Pressure Cal Date	01-01-01	

Apply a pressure reference that exceeds the zero reference by at least 50 % and wait for the readings to stabilize.

Average Pressure: 0.000

Buttons: Change, Average Pressure Now, Zero Calib, OK

- Apply a high pressure such that the pressure applied is at least 50% more than the zero reference pressure.

Wait for the pressure reading displayed on the **Pressure 1** dialog box to exceed the zero reference pressure by 50%. For example, if the zero reference pressure on a 100 PSI transducer equals 0.00 PSI, then the span reference pressure must be between 50.00 and 100.00 PSI. If the zero reference pressure on a 600 PSI transducer equals 0.00 PSI, then the span reference pressure must be between 300.00 and 600.00 PSI.

- After the pressure stabilizes, click **Average Pressure Now**.
MasterLink Software Application SQL averages the reading and displays the average pressure.
- Click **Change**.
The **Change Pressure Calibration Value** dialog box appears.
- Change the value to accurately match the high reference pressure applied to the pressure transducer.
- Click **OK**.
The **Restore Line Pressure** dialog box appears.

- Restore the normal pressure line to EC350 and click **Done** to exit the calibration.


5.4.5 Calibrating PLog pressure

To calibrate PLog pressure or P2:

- In the **MasterLink Software Application SQL** window, click **Calibrate**> **Resure**. The **Calibration Options** dialog box appears. Select **PLog**.



- The **Pressure 2** dialog box appears.



- Apply a zero reference pressure (0.00 PSI) to the pressure transducer of EC350. Wait for the pressure reading displayed on the Pressure 2 dialog box to stabilize.
- After the reading stabilizes, click **Average Pressure Now**. MasterLink Software Application SQL averages the reading and displays the average pressure.
- Click **Change**. The **Change PressureCalibration Value** dialog box appears.

- Change the value to accurately match the zero reference pressure applied to the pressure transducer.
- Click **OK**.
- Click **Span Calib**.

The **Pressure 1 Span Calibration** page appears.

Num	Description	Value	Units
408	P2 Pressure Units	PSI	
419	P2 Press Range User	0.00	PSI
014	Atmospheric Pressure	14.7300	PSI
013	Base Pressure	14.7300	PSI
407	P2 Transducer Type	None	
414	Calibration P2-Zero	0.0000	PSI
415	Cal Prev-1 P2-Zero	0.0000	PSI
417	Calibration P2-Span	1.0000	

Apply a pressure reference that exceeds the zero reference by at least 50 % and wait for the readings to stabilize.

Average Pressure:


- Apply a high pressure such that the pressure applied is at least 50% more than the zero reference pressure.
Wait for the pressure reading displayed on the **Pressure2** dialog box to exceed the zero reference pressure by 50%. For example, if the zero reference pressure on a 100 PSI transducer equals 0.00 PSI, then the span reference pressure must be between 50.00 and 100.00 PSI. If the zero reference pressure on a 600 PSI transducer equals 0.00 PSI, then the span reference pressure must be between 300.00 and 600.00 PSI.
- After the pressure stabilizes, click **Average Pressure Now**.
MasterLink Software Application SQL averages the reading and displays the average pressure.
- Click **Change**.
The **Change Pressure Calibration Value** dialog box appears.
- Change the value to accurately match the high reference pressure applied to the pressure transducer.
- Click **OK**.
The **Restore Line Pressure** dialog box appears.
- Restore the normal pressure line to EC350 and click **Done** to exit the calibration.

5.4.6 Calibrating temperature

Attention: Check the sensors before calibrating temperature.

To calibrate temperature:

- In the MasterLink Software Application SQL window, click **Calibrate > Temperature** .
The **Temperature Calibration** dialog box appears.



- Insert the temperature probe of EC350, along with an accurately calibrated thermometer calibrated thermometer into a low temperature bath or dry well, which provides the temperature zero reference.
Wait for the temperature reading displayed on the **Temperature Calibration** dialog box to be stabilized.
- After the reading stabilizes, click **Average Temperature Now** .
MasterLink Software Application SQL averages the reading and displays the average temperature.
- Click **Change**.
The **Change Temperature Calibration Value** dialog box appears.
- Change the value to accurately match the temperature measured by the calibrated thermometer placed in the low temperature bath.
- Click **OK**.

- Click **Span Calib.**

The **Temperature Span Calibration** page appears.

Num	Description	Value	Units
089	Temperature Units	F	
034	Base Temperature	60.00	F
031	Case Temperature	69.57	F
035	Temperature Cal Zero	-2.1200	F
036	1 Prev Temp Cal Zero	-2.1200	F
038	Temperature Cal Span	1.0000	

Set the temperature input to exceed the zero reference temperature by at least 15% of the rated temperature range and wait for the readings to stabilize.

Average Temperature: 74.92

Buttons: Change, Average Temperature Now, Zero Calib, OK


- Insert the temperature probe of EC350 and the calibrated thermometer into a high temperature bath, which provides the temperature span reference.
The temperature reading displayed on the **Temperature Calibration** dialog box must exceed the zero reference temperature by at least 15% to proceed with span calibration.
- After the reading stabilizes, click **Average Temperature Now** .
MasterLink Software Application SQL averages the reading and displays the average temperature.
- Click **Change**.
The **Change Temperature Calibration Value** dialog box appears.
- Change the value to accurately match the temperature measured by the calibrated thermometer placed in the high calibration bath.
- Click **OK** .

5.4.7 Configuring the Meter reader list

When you access the Meter reader mode of EC350, 12 default items are available on the LCD display. Press the down arrow to sequentially scroll through items. Refer to the section “ Level 0 mode ” for the 12 default items. You can configure the Meter reader list to display the items of your choice, in the order of your choice.


To configure the Meter reader list

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User’s Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Find Item by Number**  icon. The **Find Item** dialog box appears.
- Type **130** and click **OK**. The **Scroll List** dialog box appears. By default, Uncorrected Volume (item 002) is configured to appear first in the list (item 130, which is the scroll list) that appears on the LCD display.



- Click **Change**. The **Change Item** dialog box appears.
- Type the item number of your choice that must be listed first in the Meter reader list and then click **Save**. For example, if you want *Battery usage alarm (item 100)* to appear first in the Meter reader list, then type item number **100** and then click **Save**.

The **Scroll List** dialog box appears and the item 130 (first list in Meter reader list) is configured to *Battery usage alarm (item 100)*.




- Perform step 3 through step 5 sequentially to change items 130 through 135 and 75 through 86, if you want to change all the 12 default items.


5.4.8 Configuring Call in feature

To configure the Call in feature


- Launch **MasterLink Software Application** . From the **Display** tab select and click the **Item by Function** option. The **Display/Change Items By Function** dialog box appears.
- Double click the **Site Information** option and enter the site ID.




- The site ID must be identical to the one configured in PowerSpring during the EC350 product addition. It is a six digit, hexadecimal number.
- Click **OK** to close the **Site Information** window.
- Double click the **Audit Trail Log Configuration** option from the **Display/Change Items By Function** dialog box. The EC350 audit log appears.





- Specify the log interval size (this should match the interval size specified in the **Input** field definition in PowerSpring). Configure the **Audit Trail** items of EC350 from the left pane. The sequence and number of Audit Trail items must match the inputs provided for **RUID Inputs** on **Definiton** page in PowerSpring.
- Click **OK** to close the **Configuration** window.
- Double click the **Call-In Config** option from the **Display/Change Items By Function** dialog box. The **Call-In Config** dialog box appears.



- Type the information as shown, items: 1230, 333 (you may choose some other item numbers as well, 491, 492, 494, 495, 496, upto last). Critical items are, 339 & 493, where the Host machine's IP Address for MERCURYSERVER and TCP Port (50467) should be correctly specified. The remaining fields can be defined by the user.



Note: The Corrected Volume # of digits is defined for item-90, 97 and the Uncorrected Volume # of digits is defined for item-92, 97 These values must match the **No. of Dials** field in the **Unit Configuration** tab in PowerSpring.



5.5 Working with PowerSpring


Once the EC350 is added to PowerSpring, the configuration can be done based on your requirement.

- [Adding EC350 to PowerSpring](#)


5.5.1 Adding EC350 to PowerSpring

To add EC350 to PowerSpring

- Go to the PowerSpring Dashboard, select and click **Remote Units** listed under **Configuration**.




- The **Remote Units** page appears. Click **Add New**.
- In the selection pane, select **EC350** from the **Product Type** selection list.



- Specify the device configuration details.

Note: Remote Unit ID (RUID) and FirmWare version must be the same as specified in EC350. The Instrument Type must be selected as MERCURY EC350.



5.6 Connecting EC350 with PowerSpring using a Messenger Modem

Follow the steps below to connect a EC350 device with PowerSpring using a Messenger Modem:

- [Configure EC350 using MasterLink Software Application](#)
- [Configure EC350 in PowerSpring](#)


5.6.1 Configure EC350 using MasterLink Software Application

Launch MasterLink Software Application , and go to **DISPLAY** tab in tool bar and click on *Item by Function* option.


Inside the **Display/Change Items By Function** window double click the *Site Information* option.

Configure the following parameters:


- **SITE INFORMATION:** The site ID should be identical to (six digit, hexadecimal) the one configured in **PowerSpring** during the EC350 product addition.



PowerSpring can use Site ID 1 or Site ID 2, that is setup in **System Configuration -> Data Collection settings**. The default is Site ID 2.





- Inside the **Display/Change Items By Function** sub-window, double click on **Audit Trail Log configuration** option. This will open the audit trail configuration window. Specify the information marked in red window, i.e. LOG INTERVAL size (this should match with the interval size given in **Input** definition of the PowerSpring.) Configure the AUDIT TRAIL items of EC350, from left pane with the sequence & number of Audit Trail items equal to PowerSpring **RUID Inputs** Definition page.





- Call-In Configuration: Inside the **Display/Change Items By Function** sub-window, double click on **Call-In Config** option. Enter the information as shown in the region marked in red. i.e. items 1230, 333, 491, 492, 494, 495, 496, upto last – depending on how the user wants the Call-in to happen.

Critical items are- 339 & 493, where the HOST machine IP Address for MERCURY SERVER and TCP Port (50467) should be correctly specified. The rest items are user dependent.




- Corrected Volume # of digits: item-90, 97
Uncorrected Volume # of digits: item-92, 97
These values should be match with the “No. of Dials field”, in UNIT configuration in PowerSpring input configuration.



5.6.2 Configure EC350 in PowerSpring

- Go to the PowerSpring dashboard and inside the **Configuration** list, click on the **Remote Units**.



Click on **ADD NEW** button.

PowerSpring Time Remaining : 44:57

[DASHBOARD](#)
[CONFIGURATION](#)
[REPORTING](#)
[SCHEDULER](#)
[UTILITIES](#)
[SETUP](#)
[DATA VIEWER](#)
ADMINISTRATOR

Home » Configuration

Remote Units
Accounts
Lists
Call Profiles
Multi-members
Connectors
Special Factors
Multi-Member Connector
5000/6000 Multi-Member

Showing 20 Of Total 919 Remote Units [Add New](#)

Search: for

page 1

Remote Unit ID	Information	Address & Phone	Type	Active
\$\$\$\$ER Mercury ER Default Installed On: 7/8/1995 3:52:30 AM installer name	Site ID: Mercury ER Default Call Profile: OneHour SupplyPoint ID: 0	, FL , 45942 , Ph:	ER	●
\$\$\$\$CA2 Default Name Installed On: 7/8/1995 3:52:30 AM installer name	Site ID: Default Site Id Call Profile: Default Call Profile SupplyPoint ID: 0	Default Address 1 , Default Address 1 , Default City ,FL ,Default County , 45942 , Ph: Default phone numbe r	CA2	●
\$\$\$\$IMU Default Name Installed On: 7/8/1995 3:41:30 AM installer name	Site ID: Default Site ID Call Profile: Default Call Profile SupplyPoint ID: 0	Default Address 1 , Default Address 1 , Default City ,FL ,Default County , 45942 , Ph: Default phone numbe r	IMU	●
\$\$\$\$d0 Elec Connector Installed On: 7/8/1995 3:52:30 AM	Site ID: 1 pts/MCF Call Profile: LeadResearch	, , OH	CA2	●

8051/PowerSpring/System/Configuration/System/ConfigAllProcesses.aspx?page=c1:TOPMENU

Customer Logo **Honeywell**

- In the **Product type** dropdown, select the EC350 product type.

The screenshot shows the PowerSpring configuration interface. The top navigation bar includes Dashboard, Configuration, Reporting, Scheduler, Utilities, Setup, and Data Viewer. The user is logged in as Administrator. The main content area is titled 'Showing 20 Of Total 25 Remote Units'. A search bar is present for RU ID. The 'Product Type' dropdown is set to 'EC350'. The 'New Configuration' tab is active, showing fields for Instrument Type, FirmWare Version, Call Profile, and Battery Type. Below this is a table of existing remote units.

Remote Unit ID	Information	Address & Phone	Type	Active
\$\$\$ER	Mercury ER Default Installed On: 07/08/1996 3:52:00 installer name	Site ID: Mercury ER Default Call Profile: Default Call Profile SupplyPoint ID: 0	ER	●
\$\$\$CA1	Default Name Installed On: 07/08/1996 3:38:00 installer name	Site ID: Default Site ID Call Profile: Default Call Profile SupplyPoint ID: 0	CA1	●
\$\$\$CA2	Default Name Installed On: 07/08/1996 3:52:00 installer name	Site ID: Default Site Id Call Profile: Default Call Profile SupplyPoint ID: 0	CA2	●

Enter the device configuration details.

Note: Remote Unit ID (entered in New Remote Unit ID), FirmWare version, should be same as is specified in EC350 corrector and the Instrument Type must be selected as MERCURY EC350.

- Click on **ADD** Button in left bottom.

PowerSpring Time Remaining : 30:13

[DASHBOARD](#)
[CONFIGURATION](#)
[REPORTING](#)
[SCHEDULER](#)
[UTILITIES](#)
[SETUP](#)
[DATA VIEWER](#)
ADMINISTRATOR

Home > Configuration

Remote Units

Showing 20 Of Total 25 Remote Units [Add New](#) Search for

Product Type: EC350

New Remote Unit ID: CB6666 *

Remote Unit Name: EC350_Test

A default account will be created for this remote unit with same id and name

IP Enabled: Active No Yes

[Add](#) [Cancel](#)

Remote Unit ID	Information	Address & Phone	Type	Active
\$\$\$\$ER Mercury ER Default Installed On: 07/09/1996 3:52:00 installer name	Site ID: Mercury ER Default Call Profile: Default Call Profile SupplyPoint ID: 0	, ,FL, , Ph:	ER	●
\$\$\$\$CA1 Default Name Installed On: 07/09/1996 3:38:00 installer name	Site ID: Default Site ID Call Profile: Default Call Profile SupplyPoint ID: 0	Default Address 1 , Default Address 1 , Default City ,FL ,Default County , ????? , Ph:Default phone number	CA1	●
\$\$\$\$CA2 Default Name Installed On: 07/09/1996 3:52:00 installer name	Site ID: Default Site ID Call Profile: Default Call Profile SupplyPoint ID: 0	Default Address 1 , Default Address 1 , Default City ,FL ,Default County , ????? , Ph:Default phone number	CA2	●

Customer Logo **Honeywell**

- In the **General** tab enter all the applicable information and enable the device **ACTIVE** check box.

The screenshot shows the PowerSpring web interface for configuring a remote unit. The breadcrumb trail is: Home > Configuration > All Remote Units > RU Device Information. The unit ID is CB6666 and it is currently Active. The 'General' tab is selected, and the 'Active' checkbox is checked. The configuration fields are as follows:

Field	Value
Remote Unit ID	CB6666
Remote Unit Name	EC350_Test
Call Profile	EC350_15min
Installer Name	installer name
Product Desc	EC350
Supply Point	
Remote Unit Product Type	EC350
Available HW Inputs	400
Instrument Type	MERCURY EC350
Instrument Firmware Version	0100
Battery Type	Lead Acid
Battery Install Date	03/26/2015 14:27:45
AC Powered	No
Atmospheric Pressure	14.73
Contact Pressure	14.4
Standard Command Control	Send Latest
Access Code	33333
Password	vq99

The 'Other Information' section includes fields for Atmospheric Pressure (14.73) and Contact Pressure (14.4). The 'Standard Command Control' dropdown is set to 'Send Latest'. The 'Accessibility' section contains fields for Access Code (33333) and Password (vq99). The 'Audit Trail Date & Time Format' is set to MM/DD/YY. The 'Alarm Logging' option is unchecked, with a note explaining that unchecking it will cause an alarm record to be written to the database for every audit trail record in the device that has an active alarm state.

- In the **Call** tab, in the **Other Information** sub-window, specify the type of communication i.e. IP Enabled or Not.

PowerSpring Time Remaining : 44:33

[DASHBOARD](#)
[CONFIGURATION](#)
[REPORTING](#)
[SCHEDULER](#)
[UTILITIES](#)
[SETUP](#)
[DATA VIEWER](#)
ADMINISTRATOR

Home > Configuration > All Remote Units > Call Information

All Remote Units

Active

Remote Unit ID
CB6666

Remote Unit Name
EC350_Test

Call Profile
EC350_15min

Installer Name
installer name

Product Desc
EC350

Supply Point

✖ Delete this Unit

CB6666

View Summary Edit General **Call** Inputs Alarms Site Install Discard Save

Dial Out Information

Prefix
(Max 25 Characters)

Suffix
(Max 25 Characters)

IP Address : Port
 192.123.100.11

Long Distance Capability
 Yes No

Host Information

Host IP
 10.78.63.126

Calls

Called In

Last Call Date
01/01/1990 00:00:00

Next Call Date
 03/26/2015 14:27:45

Calling Time

Call Profile
EC350_15min

Field Modem Types

Standard Mercury A Mercury C

Metrotek Mercury B Mercury D

Other Information

IP Enabled
 Yes No

Invisi-Connect Device
 Yes No

Set Transparent
 Yes No NA

Slave Device

[View SIP CB cellular parameters](#)

- The sequence and number of inputs inside the INPUTS tab must be identical to *EC350 Audit Trail Log1*.

Honeywell 2022

189

PowerSpring Time Remaining : 42:45

DASHBOARD CONFIGURATION REPORTING SCHEDULER UTILITIES SETUP DATA VIEWER ADMINISTRATOR

Home > Configuration > All Remote Units > Input Configuration

CB6666 Discard Save

View Summary Edit General Call **Inputs** Alarms Site Install

4 Inputs Available/ Synchronized 4 [Add New](#)
[Set as Default Configuration for all Inputs](#)

Input Number	Description	Date & Time	Factor & operator	Synchronized	Current Reading
1	0 Corrected Volume Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1 , Operator 1: + Factor 2: 0 , Operator 2: +	✓	0 Field Unit: Default U nit
2	2 Uncorrected Volume Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1 , Operator 1: + Factor 2: 0 , Operator 2: +	✓	0 Field Unit: Default U nit
3	206 Average Pressure Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1 , Operator 1: + Factor 2: 0 , Operator 2: +	✓	0 Field Unit: Default U nit
4	207 Average Temperature Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1 , Operator 1: + Factor 2: 0 , Operator 2: +	✓	0 Field Unit: Default U nit

Customer Logo **Honeywell**

Click on **EDIT** tab on the Input to be edited.

PowerSpring Time Remaining : 44:51

DASHBOARD CONFIGURATION REPORTING SCHEDULER UTILITIES SETUP DATA VIEWER ADMINISTRATOR

Home > Configuration > All Remote Units > Input Configuration

All Remote Units Active

Remote Unit ID: **CB6666**

Remote Unit Name: EC350_Test

Call Profile: EC350_15min

Installer Name: installer name

Product Desc: EC350

Supply Point:

[Delete this Unit](#)

CB6666

View Summary Edit General Call **Inputs** Alarms Site Install Discard Save

4 Inputs Available/ Synchronized 4 [Add New](#)

[Set as Default Configuration for all Inputs](#)

Input Number	Description	Date & Time	Factor & operator	Synchronized	Current Reading
1	0 Corrected Volume Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1, Operator 1: + Factor 2: 0, Operator 2: +	✓	0 Field Unit: Default U nit
2	2 Uncorrected Volume Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1, Operator 1: + Factor 2: 0, Operator 2: +	✓	0 Field Unit: Default U nit
3	206 Average Pressure Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1, Operator 1: + Factor 2: 0, Operator 2: +	✓	0 Field Unit: Default U nit
4	207 Average Temperature Dial Count: 8	01/01/2000 12:00 A M	Factor 1: 1, Operator 1: + Factor 2: 0, Operator 2: +	✓	0 Field Unit: Default U nit

Customer Logo **Honeywell**

In **EDIT Input window > Input Definition**, enter the following critical parameters:

- Input description
- Input Interval
- Enable the Billable option
- Save Data (enable checkboxes to store the Interval, Time of Call, Daily Reading)
- Daily Read Hour (specify the hour at which the Remote Unit performs a read on the selected input. Type the hour, (0 to 23), minute and second). Profile 1, Profile 2, Profile 3 and Profile 4: To define four profiles for CAO and CA1 Remote Units that enable you to set up more than one Daily Readings, that is, define four profiles at which the Remote Unit performs a read on the selected input. Type the Hour, Minute, and Second for each Profile. One Profile must match the Daily Read Hour.

The screenshot shows the PowerSpring web interface for configuring a remote unit (CB6666). The 'Central Data Alarms' tab is active. The configuration area is divided into several sections:

- Data Description:** Includes 'Input Type Filters' (All, Interval, Time Of Call), 'Input Type' (0 Corrected Volume), 'Input Description' (0 Corrected Volume), 'Serial Number' (Input 1 Serial Numbe), 'Interval Size' (15), and 'Input Is Billable' (checked).
- Daily Read Definition:** Includes 'Daily Read Hour' (8) and four profiles (Profile 1-4) with time ranges (00:00:00).
- Time Of Call Information:** Includes 'Last Call' (01/01/2000 0:00:00), 'Value(Encoded) as of Last Call' (0), 'Write Value to Item' (empty), 'Synchronized' (checked), and 'Type' (Actual).
- Save Data:** Includes 'Save Data As Follows' (Interval, Time of Call, Daily Reading checked) and 'Profile' and 'Peak' checkboxes.

INPUTS>Central Data Alarms tab:

Use this tab to define automatic central limit checking. PowerSpring allows you to set up a simple, yet extremely effective, Central Interval Level Checking scheme that enables you to report on intervals outside user-configured boundaries. You can configure this tri-level checking scheme for both High and Low Intervals; however, you are not required to use both. Let's assume you have a customer that is "interruptible" (curtailed). Of course, you cannot completely shut the gas off because the customer has a large number of pilot lights that must remain operative; therefore, a very small consumption is expected. You could set up the following tri-level central interval high checking scheme:

- Central Interval 1 High - Set this to the lowest level of severity. If consumption rises above this level, monitor this customer more closely.
- Central Interval 2 High - Set this to the middle level of severity. If consumption rises above this level, call the customer.

- Central Interval 3 High - Set his to the highest level of severity. If consumption rises above this level, you know that the customer is using gas Inside the Edit Input (Corrected Volume) window, go to the UNITS tab.

Inside the Edit Input (Corrected Volume) window, go to the UNITS tab.


The screenshot shows the PowerSpring web interface for unit 555333. The 'Input Configuration' window is open, and the 'Units' tab is selected. The 'Interval High Alarms' section is visible, with three alarm descriptions. The 'Limits' field for 'Interval High Alarm Description 3' is highlighted with a red box and set to 0. The 'Alarm Properties' section is also highlighted with a red box and shows 'Save', 'Log', and 'Alert' options checked. The background shows a table of units with columns for Dial Count, Date, Factor, Operator, and Field Unit.

INPUT > UNITS tab:

This sub-window can be used to:

- Add edit, and delete field unit conversions. You use these conversions to convert your raw data to a scaled format before it is saved in the database.
- Add, edit, and delete report unit conversions. You can apply these conversions to your data, using the Custom Report and Data Viewer applications, and view the data in a new format. Most important information, the latest ADDED field or REPORT units will be used to save the data, since when they are created. Previous existing units shall still show the history in the respective units.

Click on the EDIT icon for editing a FIELD UNIT.



Also user can add customized UNITS with Operator and Factors for calculation and display in Data viewer, as desired. Similarly add the REPORT UNITS for calculating and loading the data in Data Viewer application, shown below. Go to the REPORT UNIT radio button and click on the ADD NEW tab (shown below).

PowerSpring Time Remaining :44:25

DASHBOARD CONFIGURATION REPORTING SCHEDULER UTILITIES SETUP DATA VIEWER ADMINISTRATOR

Home > Configuration > All Remote Units > Input Configuration

All Remote Units **555333** Discard Save

Active View Summary Edit General Call **Inputs** Alarms Site Install

Remote Unit ID **555333** **5 Inputs Available/ Synchronized 5** [Add New](#)

Remote Unit Name [Set as Default Configuration for all Inputs](#)

0 Corrected Volume Discard Save

Input Definitions Remote Data Alarms Central Data Alarms **Units**

Field Units Report Units [Add New Unit](#)


Effective Date & Time	Units	Description	Operator1	Factor1	Operator2	Factor2	
<input type="text"/>	COMMON	<input type="text"/>	Multiply	1	Add(+)	0	Add

5	31 Case Temperature Dial Count: 0	03/26/2016 10:15 P M	Factor 1: 1, Operator 1: * Factor 2: 0, Operator 2: +	✔	24.3500 Field Unit: Default Unit
---	---	-------------------------	---	---	-------------------------------------


Customer Logo **Honeywell**

The screenshot shows the PowerSpring web interface. At the top, there is a navigation bar with tabs for DASHBOARD, CONFIGURATION, REPORTING, SCHEDULER, UTILITIES, SETUP, and DATA VIEWER. The user is logged in as ADMINISTRATOR. The main content area is titled 'Input Configuration' for remote unit 555333. It shows a summary of 5 inputs available and synchronized. A modal window titled '0 Corrected Volume' is open, displaying a table for 'Input Definitions'. The table has the following columns: UnitDescription, DefaultFactor1, DefaultFactor2, DefaultOperator1, DefaultOperator2, and UnitType. A new row is being added with the following values: UnitDescription: SCM, DefaultFactor1: 10, DefaultFactor2: 1, DefaultOperator1: Multiply(*), and DefaultOperator2: Multiply(*). An 'Add' button is located to the right of the new row. Below the table, there is a '31 Case Temperature' entry with a dial count of 0 and a timestamp of 03/25/2015 10:15 P M. The interface also shows a 'Honeywell' logo at the bottom right.

Once user clicks on ADD button, the entered unit and factors should be added and publish in the dropdown list of available UNITS.



SAVE the changes and reopen the UNITS window for selected input. The added REPORT UNIT should be listed in the REPORT units dropdown as shown below:



Specify the date from when this report unit will be applicable for data calculation. Also define the description of this report unit for easy identification as is shown in below screenshot:

PowerSpring

Time Remaining : 40:07

DASHBOARD CONFIGURATION REPORTING SCHEDULER UTILITIES SETUP DATA VIEWER ADMINISTRATOR

Home > Configuration > All Remote Units > Input Configuration

All Remote Units 555333

Active

Remote Unit ID: 555333

Remote Unit Name: 5 Inputs Available/ Synchronized 5

Discard Save

0 Corrected Volume

Discard Save


Input Definitions Remote Data Alarms Central Data Alarms Units

Field Units Report Units Add New Unit

Effective Date & Time	Units	Description	Operator1	Factor1	Operator2	Factor2	
03/19/2015 00:00:00	SCM		Multiply	10	Multiply	1	Add

5 31 Case Temperature 03/25/2015 10:15 P M Factor 1: 1, Operator 1: + Factor 2: 0, Operator 2: + 24.3500 Field Unit: Default Unit

Customer Logo Honeywell



Click on **SAVE** button.

Once the new report unit is available in dropdown, now user can associate this report unit to any inputs existing in the database. To validate this UNIT is available for calculation; verify it in DATA VIEWER application, shown below:

The screenshot displays the PowerSpring software interface. At the top, there is a navigation bar with the following tabs: DASHBOARD, CONFIGURATION, REPORTING, SCHEDULER, UTILITIES, SETUP, and DATA VIEWER. The user is logged in as ADMINISTRATOR, and the time remaining is 44:53. The main area contains three data viewer windows:

- Load New Readings::1:** Shows a table with 5520 rows. The 'Units' dropdown is set to 'SCM'. The table columns are Time, Value, Unit, and Status. The 'Value' column contains values like 16181.0000.
- Load New Readings::2:** Shows a table with 255 rows. The 'Units' dropdown is set to 'Field Ur'. The table columns are Time, Value, Unit, and Status. The 'Value' column contains values like 3364.
- Load New Readings::3:** Shows configuration options for data loading. The 'Data Type' is set to 'Interval Data'. The 'Synchronize Scrolling' checkbox is checked. A 'Load Readings Now' button is visible.

The Honeywell logo is located at the bottom right of the interface.

Note: The Operator and Factors given for the REPORT or FIELD UNITS should be used correctly in DATA VIEWER. In the below screenshot user can see the SCM report unit contains the Operator1=* and Factor1=10. It means the multiplication by 10 should be done in data viewer, if user displays the data in data-viewer application for report unit selected as SCM .

PowerSpring Time Remaining : 44:56

[DASHBOARD](#) [CONFIGURATION](#) [REPORTING](#) [SCHEDULER](#) [UTILITIES](#) [SETUP](#) [DATA VIEWER](#) ADMINISTRATOR

Load New Readings::1

Input Number: 1 5520 Rows Units: SCM

RU ID: 555333 Data Type: Interval Data

[View Graph](#) [Resync](#) [Bulk Change](#) [Save](#) [Delete](#)

Time	Value	Unit	Status
03/06/2015 09:30:00 PM	1616.00	SCM	
03/06/2015 09:35:00 PM	1616.00	SCM	
03/06/2015 09:40:00 PM	1616.00	SCM	
03/06/2015 09:45:00 PM	1616.00	SCM	
03/06/2015 09:50:00 PM	1616.00	SCM	
03/06/2015 09:55:00 PM	1616.00	SCM	
03/06/2015 10:00:00 PM	1616.00	SCM	
03/06/2015 10:05:00 PM	1616.00	SCM	
03/06/2015 10:10:00 PM	1616.00	SCM	
03/06/2015 10:15:00 PM	1616.00	SCM	
03/06/2015 10:20:00 PM	1616.00	SCM	
03/06/2015 10:25:00 PM	1616.00	SCM	
03/06/2015 10:30:00 PM	1616.00	SCM	
03/06/2015 10:35:00 PM	1616.00	SCM	
03/06/2015 10:40:00 PM	1616.00	SCM	
03/06/2015 10:45:00 PM	1616.00	SCM	
03/06/2015 10:50:00 PM	1616.00	SCM	
03/06/2015 10:55:00 PM	1616.00	SCM	
03/06/2015 11:00:00 PM	1616.00	SCM	

Load New Readings::2

Input Number: 2 255 Rows Units: Field Ur

RU ID: 555333 Data Type: Time Of Call

[View Graph](#) [Resync](#) [Bulk Change](#) [Save](#) [Delete](#)

Time	Value	Unit	Status
03/06/2015 09:34:11 PM	3364	Default Unit	
03/06/2015 09:49:21 PM	3364	Default Unit	
03/06/2015 10:04:12 PM	3364	Default Unit	
03/06/2015 10:06:13 PM	3364	Default Unit	
03/06/2015 10:19:12 PM	3364	Default Unit	
03/06/2015 10:34:12 PM	3364	Default Unit	
03/06/2015 10:36:13 PM	3364	Default Unit	
03/06/2015 10:49:11 PM	3364	Default Unit	
03/06/2015 11:04:12 PM	3364	Default Unit	
03/06/2015 11:06:15 PM	3364	Default Unit	
03/06/2015 11:19:11 PM	3364	Default Unit	
03/06/2015 11:34:13 PM	3364	Default Unit	
03/06/2015 11:36:14 PM	3364	Default Unit	
03/06/2015 11:49:11 PM	3364	Default Unit	
03/07/2015 12:04:13 AM	3364	Default Unit	
03/07/2015 12:20:14 AM	3364	Default Unit	
03/07/2015 12:34:12 AM	3364	Default Unit	
03/07/2015 12:49:12 AM	3364	Default Unit	
03/07/2015 12:51:12 AM	3364	Default Unit	

Load New Readings::3

Account ID: 555333 [Browse](#)

Members: 1,555333,0 Corrected Volume

5K/6K Data: --Select--

ANSI Data: --Select--

Data Type: Interval Data

From: 03/01/2015 07:00

To: 03/27/2015 07:00

Show Last:

Synchronize Scrolling

[Load Readings Now](#)

Customer Logo **Honeywell**

• Alarms tab for Remote Unit

The screenshot shows the PowerSpring web interface. At the top, there is a navigation bar with tabs: DASHBOARD, CONFIGURATION, REPORTING, SCHEDULER, UTILITIES, SETUP, and DATA VIEWER. The user is logged in as ADMINISTRATOR. The breadcrumb trail is: Home > Configuration > All Remote Units > Alarms Information.

The main content area is titled "555333" and has tabs for: View Summary, Edit, General, Call, Inputs, Alarms (selected), Site, and Install. There are "Discard" and "Save" buttons.

On the left sidebar, under "All Remote Units", the unit is shown as "Active". Details include: Remote Unit ID: 555333, Remote Unit Name: EC350_CIN, Call Profile: EC350_15min, Installer Name: installer name, Product Desc: EC350, and Supply Point: 0. A red link "Delete this Unit" is visible.

The main section is titled "25 Hardware Alarms / Product Type EC350". It contains a table with the following columns: Alarm Num, Description, Nuisance Limit, Notify Immediately, and Properties. The first row is highlighted with a red box.

Alarm Num	Description	Nuisance Limit	Notify Immediately	Properties
1	Battery Low Alarm	0	No	Save; Log;
2	Battery Cycles Alarm	0	No	Save; Log;
3	Vol Sensor-1 Alarm	0	No	Save; Log;
4	Vol Sensor-2 Alarm	0	No	Save; Log;
5	System Alarm	0	No	Save; Log;
6	Master Alarm Status	0	No	Save; Log;
7	P1 Press Low Alarm	0	Yes	Save; Log;
8	Temperature Low Alarm	0	Yes	Save; Log;
9	P1 Press High Alarm	0	Yes	Save; Log;
10	Temperature High Alarm	0	No	Save; Log;

At the bottom right of the interface, there is a "Customer Logo" and the "Honeywell" logo.

Navigate to ALARMS tab as and configure the ALARMS for EC350 device, user can configure the alarms thathe wants to display in PowerSpring Alarm/System Monitor application. As shown below user has to EDIT the existing alarm.

The screenshot shows the PowerSpring interface for configuring a Remote Unit (555333). The 'Alarms' tab is selected, showing a list of 25 Hardware Alarms for Product Type EC350. A modal window titled 'Battery Low Alarm' is open, allowing configuration of the alarm. The modal includes fields for 'User Description' (set to 'Battery Low Alarm'), 'Alert Mode' (checked 'Clear Alarm'), 'New Alarm Description' (set to 'Flow High'), and 'Properties' (checked 'Save', 'Log', and 'Alert'). The background table shows various alarms with columns for Alarm Num, Description, Nuisance Limit, Notify Immediately, and Properties.

Alarm Num	Description	Nuisance Limit	Notify Immediately	Properties
1				Save; Log;
2				Save; Log;
3				Save; Log;
4				Save; Log;
5				Save; Log;
6				Save; Log;
7				Save; Log;
8	Temperature Low Alarm	0	Yes	Save; Log;
9	P1 Press High Alarm	0	Yes	Save; Log;
10	Temperature High Alarm	0	No	Save; Log;

Use this tab to edit the Remote Unit Hardware Alarms' information. However, there are certain hardware alarms that are "non-maskable," that is, the hardware alarms are always active and you are only permitted to customize the name (user description). When you select one of these hardware alarm types, (from the Hardware alarm list), the Immediate alarm notification check box and Nuisance limit box, (under Alarm Specification), appear dimmed and are unavailable for modification.

Note: Alert Mode: Select the Notify Immediately check box to enable the Remote Unit to call immediately when the selected hardware alarm is detected. Another critical purpose of CLEAR ALARMS checkbox is that, it will clear the hardware alarms in the device (i.e. EC350) once the call is successful in PowerSpring.

Nuisance Limit: Specifies the number of times that the selected alarm can occur prior to being disabled. Type a number and if the "Nuisance limit" is met, the alarm notifies the selected Remote Unit to repeat the alarm. Properties: You can save, log, or select to alert an alarm.

Save - Saves the selected Hardware alarm occurrence to the database (Alarm Data File).

Log - Logs the selected Hardware alarm occurrence to your alarm logging device. This logging device, usually a printer, is specified in the Alarm Maintenance application.

Alert - an alarm (beep) is sounded by the printer when the selected Hardware alarm is detected. Site Information tab for Remote Unit:

Site Information tab for Remote Unit:

The screenshot displays the PowerSpring web interface. At the top, there is a navigation bar with tabs: DASHBOARD, CONFIGURATION, REPORTING, SCHEDULER, UTILITIES, SETUP, and DATA VIEWER. The user is logged in as ADMINISTRATOR. The breadcrumb trail is: Home > Configuration > All Remote Units > Site Information.

The main content area is titled "All Remote Units" and shows a list of units. The selected unit is "555333", which is marked as "Active". The unit details in the sidebar include: Remote Unit ID (555333), Remote Unit Name (EC350_CIN), Call Profile (EC350_15min), Installer Name (installer name), Product Desc (EC350), and Supply Point (0). There is a "Delete this Unit" link.

The "Site Information" tab is active, showing a form with the following fields:

Site Information	
Site ID	Name
Default Site ID EC350_CIN (Max 25 Characters)	EC350_CIN (Max 25 Characters)
Address1	Address2
Default Address 1 (Max 25 Characters)	Default Address 2 (Max 25 Characters)
Site Phone	Wall location code
Default phone number (Max 25 Characters)	A01 (Max 25 Characters)
Extension number	Timezone
### (Max 25 Characters)	GMT
Country	State
Default Country (Max 25 Characters)	WA
City	ZIP
Default City (Max 30 Characters)	329- (Max 12 Characters)

At the bottom right of the interface, there is a "Customer Logo" and the Honeywell logo.

Install tab for Remote Unit:

The screenshot displays the PowerSpring web application interface. At the top, there is a navigation bar with the following menu items: DASHBOARD, CONFIGURATION, REPORTING, SCHEDULER, UTILITIES, SETUP, and DATA VIEWER. The user is logged in as ADMINISTRATOR, and the time remaining is 44:52. The breadcrumb trail indicates the current location: Home > Configuration > All Remote Units > Install Information.

The main content area is divided into two sections. On the left is a sidebar for 'All Remote Units' showing details for unit 555333, which is currently 'Active'. The details include: Remote Unit ID (555333), Remote Unit Name (EC350_CIN), Call Profile (EC350_15min), Installer Name (installer name), Product Desc (EC350), and Supply Point (0). A red link labeled 'Delete this Unit' is visible at the bottom of the sidebar.

The right section is titled '555333' and contains a 'View Summary' button and tabs for 'General', 'Call', 'Inputs', 'Alarms', 'Site', and 'Install'. The 'Install' tab is selected. Below the tabs is the 'Install Information' form, which includes the following fields:

- Installer ID:** A text input field containing 'TEST'. A red asterisk indicates a validation error. Below the field is the text '(Max 25 Characters)'.
- Installation Date & Time:** A date and time input field containing '03/06/2015 21:18:11'.
- Initialization Date & Time:** A date and time input field containing '03/06/2015 21:18:11'.
- Account Notes:** A text area for notes, currently empty. Below the field is the text '(Max 255 Characters)'.

At the bottom right of the main content area, there are 'Discard' and 'Save' buttons. The footer of the page contains the text 'Customer Logo' followed by the Honeywell logo.

CHAPTER 6

6 Remote Communications

This chapter describes the different communication mechanisms featured in a EC350 device.

- [Use of RS232/ 485](#)
- [Call in and call out](#)
- [Modbus Host Communication](#)


6.1 Use of RS232/ 485

Application

EC350 is capable of communicating with a number of types of external devices, such as cellular or landline modems, and RTUs. EC350 supports the following protocols: MI Protocol, Modbus RTU, Modbus ASCII. The description of those protocols is beyond the scope of this manual, although a basic discussion of Modbus operation is presented later in this chapter. This section describes the physical connections and instrument configuration parameters that are required.

Connections

Wiring connections are made to TB4, see below:



For RS-232, only 3-wire communications is supported: pin 1 TXD (Transmit Data), pin 2 RXD (Receive Data), and pin 5 GND (Ground). (The TB4 RTS/CTS connections are not used.) TXD and RXD are labelled as a DTE device (EC350 transmits on TXD).

For RS-485, use TB4 pin 1 (TXD) as line A, pin 2 (RXD) as line B, and pin 5 (GND) as Ground.


The RS-232 and RS-485 standard specifications should be consulted for the proper wire type, maximum cable length, etc.

Jumpers

In addition to wiring, jumpers on JP1 and JP2 must be properly positioned. For RS-232, both jumpers must be set to B and C as shown in the picture above. They must be placed on A and B for RS-485.

Configuration Parameters

EC350 items in the 'Communications' group in MasterLink Software Application may need to be modified to accommodate a particular external device.



Number	Description	Value	Units
170	Protocol Code A	No Errors	
172	Wait for SN Timeout	25	Second(s)
272	Serial Baud Rate	9600	
995	Serial Comms Format	8/N/1	
1220	Serial Port Type	RS-232	

Items 170 and 172 are primarily associated with the behavior of MI Protocol. These should normally left as default (shown here). The remainder will vary depending on the external devices. See also Modbus section below for settings relevant to the Modbus protocol.

6.2 Call in and call out

- [Call in](#)
- [Call out](#)

6.2.1 Call in

EC350 has the capability to initiate a modem to modem telephone call. This is called call in and can happen under two circumstances.

- Alarm Call-In
- Scheduled Call-In.

6.2.1.1 Call in

When connected to either a cellular or landline modem the EC350 can be configured to autonomously dial and connect to a host computer. It can do this according to a preset schedule or in the event of an alarm condition. Previous Mercury Instruments products have incorporated similar features, but the EC350 is unique in its support of four phone numbers (or IP addresses); two for scheduled calls and two for alarms. This provides the ability to communicate with four different hosts. In turn, this feature leads to some differences in the retry algorithm. Call in configuration items are:

Call-In Config

Filter:

Number	Description	Value	Units
1230	Call In Sequence	Priority	
333	Call-In Trigger Type	Alarm and Schedule...	
491	Modem Init String	ATE0V0	
492	Modem Dial String	ATDT	
494	Modem Hangup String	ATH0	
495	Modem Retry-A Interval	5	Minute(s)
496	Modem Retry-B Interval	1440	Minute(s)
336	Call-In Retry By:	Host	
497	Modem Retry-A Count	0	
821	Modem Init Delay	50	Second(s)
405	Call-In Dialing Delay	5	Second(s)
493	Alarm Call-In Number-1	198.198.198.1	
785	Alarm Call-In Number 2	198.198.198.2	
339	Sched Call-In Number-1	198.198.100.1	
1030	Sched Call-In Number-2	198.198.100.2	
334	Sched Call-In Date	07-14-15	
335	Sched Call-In Time	15 33 00	
338	Sched Call Unprocessed	No	
337	Last Mdm Call-In Result	No Call Attempted	
487	Call-In Keep Alive Time	5	Minute(s)

Change
Print
Find
Close

Modem items are shared between the scheduled and alarm call in features. If the modem requires an initialization string it must be set into item 491 along with an Init Delay (Item 821). The initialization delay is applied so that the modem, having just been powered up, has a chance to stabilize before being sent the initialization string. A dial prefix must be configured in item 492 and a hangup string in 494. The Dialing Delay will take place following the issuance of the initialization string. Call in sequence, Trigger Type and retry parameters are also shared between scheduled and alarm calls. Those will be discussed later.

6.2.1.2 Scheduled Call In

The EC350 can initiate a call at a preset time. The time may have been manually specified, but on an ongoing basis the host(s) is responsible for the schedule. At the end of each call the host is must set item values that determine when the next call is to take place. That time will always be contained in items 334 and 335. Items 338 and 337 indicate the result of the latest call (or call attempt). If only one host exists, its phone number is set in item 339. If a second host exists, its number is set in item 1030. To enable

scheduled call in, at least phone number must be configured and item 333 must be set to either Alarm and Scheduled Call In or Scheduled Call In Only.

6.2.1.3 Alarm Call In

If alarm call in is configured and enabled, a call will be initiated whenever a new alarm occurs or, if in RBX mode, an alarm condition clears. This requires a phone number in item 493 (and optionally in 785) and item 333 must be set to either Alarm and Scheduled Call In or Alarm Call In Only.

6.2.1.4 Force schedule Call

If the **Force Schedule Call** (i1693) is configured and enabled, and the device does not attempt **Schedule Call In** (i1693) in configured time for various reasons, the **Force Schedule Call** initiates **Call In** with the server.

Note: By default, the **Force Schedule Call** is configured for 36 hours (2160 minutes).

Note: If the user wants to disable the **Force Schedule Call** feature, set the item i1693 value to 0.

6.2.1.5 Management of Multiple Phone Numbers

If multiple phone numbers are configured, item 1230 determines (along with the retry strategy) when and if the second number is called. The setting will affect the behavior of scheduled and alarm calls identically.

Call In Sequence = BOTH:

When a call is triggered, the EC350 will dial the first number first. Regardless of whether that call succeeds or fails, the second number will also be called. The BOTH algorithm ensures that both hosts will (eventually) receive notification. If a call to a host fails, it will be retried as many times as necessary until the call succeeds. The two numbers are independent – whatever happens on phone number 1 will not affect phone number 2 and vice-versa.

Call In Sequence = PRIORITY:

This algorithm ensures that someone will (eventually) receive notification, and it will be whoever succeeds first. As soon as either one succeeds the process is complete. Some possible sequences are:

1 S. Done.

1 F, 2 S. Done.

1 F, 2 F, 1 S. Done.

1 F, 2 F, 1 F, 2 S. Done.

(where 1 and 2 represent the first and second phone numbers, S denotes success, F denotes failure)

6.2.1.6 Retry Timing

Not all call failures are resolved with 'retries'. 'Retries' is defined as the termination of the current attempt and the scheduling of another attempt some minutes or hours hence. In some cases the EC350 may try to resolve the failure immediately. If, for instance, an initialization string is sent to the modem but no positive response is received within several seconds, it will simply send it again. If several initialization attempts fail, then it will be deemed hopeless (for now) and a future retry will be scheduled. The same is true if a dial string goes unanswered. But after a certain point another immediate attempt would be futile and a future retry is scheduled.

There are three retry timing parameters – two delays (A and B) and a counter. For any given trigger (schedule or alarm) the first retry will be scheduled to take place Retry A minutes in the future. Retry A will be used for subsequent retries until Modem Retry A count is exhausted. The next (and subsequent) failures will be scheduled at intervals of Retry B minutes. Once the call finally succeeds (or another trigger occurs) the counter, and thus the retry sequence, will be reset.

6.2.1.7 LCD indications

When a call is triggered, the information on the 2nd and 3rd lines of the LCD will be replaced with messages indicating the progression of the call, such as 'INIT MODEM', 'DIALING #', 'DIAL FAILED', 'CONNECTED', 'WAIT FOR CONN RESPONSE', 'CONNECTED', 'WAITING +--+CLRALMS', and 'HOST SYSTEM CONNECTED'.

6.2.1.8 Forcing a Test Call

During initial commissioning as well as subsequent troubleshooting, it is useful to be able to manually evoke a call. This can be done by writing the proper value to item 264: 20139796 will trigger a scheduled call; 20139813 will force an alarm call. The same can be done using the HMI. See the HMI section for details.

6.2.2 Call out

The Call Out window (COW) allows EC350 to accept remote communications during one or two blocks of time during the day.

When used with a CNI2 cellular modem, the CNI2 will be set to “server mode” during the call out window (s) so it can accept calls from a host system during those times. The CNI2 consumes more power in server mode, regardless of whether communication occurs.

EC350 can also be kept “awake” during the call out window(s) such that even the initial characters of a communication session are accepted. Otherwise, the initial characters “wake up” the EC350. The MI Protocol includes such wake up characters in its protocol so that this feature is not required for MI Protocol communication. But the Modbus protocol includes no wake-up characters, so this feature can be used so that the EC350 processes the first Modbus packet. Without it, the first packet is not processed and the Modbus host system must send a “retry” packet. More power is consumed during the call out window in this mode, regardless of whether communication occurs or not. To use this mode, in addition to specifying a call out window, set item 1236 (Port Active During COW) to enabled. This mode consumes more battery power but reduces retries on Modbus activity.

There are items for specifying the start and stop times for two call out windows. Set the start and stop times equal to disable a call out window. (Do so for both if they have no call out window.) Times are specified in 24-hour format. The maximum value is “23 59 00”. Seconds other than “00” are ignored. The resolution for the times is one minute. No single call out window can be longer than 18 hours, but greater than 18 hours can be achieved by scheduling two call out windows “back to back” (e.g. 00 00 00 - 12 00 00, 12 00 00 - 23 59 00 would effectively give you a call out window for the entire day except one minute before midnight).

The modem will stay active until a stop time is reached or when the current call (if after the stop time) has ended. EC350 goes back to sleep if there is no call out.


- [Set Call Out time](#)
- [Set a call out stop time](#)

6.2.2.1 Set Call Out time

To set a call out start time:

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User’s Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Find Item by Number**  icon. The **Find Item** dialog box appears.

- Type **1231** and click **OK**.
The Call Out Times dialog box appears.




- Click **Change**.
The **Change Item** dialog box appears.
- Enter the desired start time and click **Save**.
- Repeat steps 2 to 5 if you want to change item 1233.

6.2.2.2 Set a call out stop time

To set a call out stop time

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Find Item by Number**  icon.
The **Find Item** dialog box appears.
- Type **1232** and click **OK**.
The **Call Out Times** dialog box appears.




- Click **Change**.
The **Change Item** dialog box appears.
- Enter the desired stop time and click **Save**.
- Repeat steps 2 to 5 if you want to change item 1234.

6.3 Modbus Communication

Modbus is a common industrial communication protocol. The EC350 supports the Modbus protocol (as a slave device) on the TB4 RS-232/485 port as well as the front panel IrDA port. Through the RS-232/485 port it can also be used with modems including Messenger, CNI2, and Cloud Link. Function codes 01, 02, 03, 04, 05, 06, 15 and 16 are supported, in both RTU and ASCII modes.

The Modbus protocol standard defines the format of the data and the techniques used to control the flow of data. It supports one master device and up to 247 slave devices on one bus (although a maximum of 32 slave devices are permitted on an RS-485 network, due to physical layer limitations). The master always initiates a communication exchange. Each slave on a Modbus network has its own unique address (1...247) so that it can be addressed independently from other slaves. This address is sent by the master as part of every message. All slaves on the network see the message, but only the slave with the matching address will respond to the message. A message sent to a slave from the master is called a request, the answer sent back to the master is called a response. Request and response messages are also called packets or frames. The master can also broadcast a message to all slave devices, using a slave address of 0. In that case there is no response.


Modbus configuration items are found in the 'Modbus Protocol' and 'Modbus Map Registers' function groups of MasterLink Software Application :



Number	Description	Value	Units
985	Modbus Enable	0	
994	Modbus Protocol Type	RTU	
990	Modbus Device Address	1	
991	Modbus Register Format	32-Bit MSB First	
993	Registers Offset By One	No	
992	Modbus Read-Only Mode	No	

If the external device communicates via Modbus protocol, item 985 must be set to 1. Item 994 will need to be set to the proper Modbus variation, either RTU or ASCII. The correct setting for all of these items will be determined by the external device used.

Modbus registers can be 'mapped' to items in the EC350 via the items in the following group. For example, pressure can be mapped to register 7003 by enabling Float mapping in item 935 and setting item 943 to '8'.



The image shows a software window titled "Modbus Map Registers". At the top left, there is a "Filter:" label followed by an empty text input field. Below this is a table with four columns: "Number", "Description", "Value", and "Units". The table contains several rows of data. To the right of the table is a vertical scrollbar. Further to the right, there are four buttons stacked vertically: "Change", "Print", "Find", and "Close".

Number	Description	Value	Units
935	Modbus Float Mapping	No	
936	Modbus Boolean Mapping	No	
1228	Modbus Integer Mapping	No	
1229	Modbus Long Mapping	No	
940	Modbus Float 7000 Item	255	
941	Modbus Float 7001 Item	255	
942	Modbus Float 7002 Item	255	
943	Modbus Float 7003 Item	255	
944	Modbus Float 7004 Item	255	
945	Modbus Float 7005 Item	255	

CHAPTER 7

7 Maintenance

This chapter lists out the temperature and transducer related kits. It also includes information on how to remove the HF cover.

- [Temperature Probe Measurement Kits](#)
- [Transducer Replacement Kits](#)
- [Redundant Uncorrected Switch](#)
- [Installing Measurement Canada \(MC\) Sealing Cover](#)
- [Removing and Re-Installing Human Factor \(HF\) Cover](#)

7.1 Temperature Probe Measurement Kits

40-5814-KIT	Internal (Rotary ONLY)
40-6008-1-KIT	6" Armored 6' Cable
40-6008-2-KIT	9" Armored 6' Cable
40-6008-3-KIT	9" Armored 30' Cable
40-6007-KIT	3" Pete's Plug Armored
40-6005-1-KIT	2-1/8" Pete's Plug Teflon
40-6005-2-KIT	3" Pete's Plug Teflon 3' Cable
40-6005-3-KIT	3" Pete's Plug Teflon 10' Cable
40-6002-KIT	External Teflon
40-6003-KIT	3/16" Sheath Teflon
40-6004-KIT	6" Sheath 6' Teflon Cable




7.2 Transducer Replacement Kits

22-2950-1-KIT	6 psig
22-2950-2-KIT	30 psig
22-2950-3-KIT	60 psig
22-2950-4-KIT	100 psig
22-2950-5-KIT	300 psig
22-2950-6-KIT	600 psig
22-2950-7-KIT	1000 psig
22-2950-8-KIT	1500 psig
22-2950-9-KIT	15 psig
22-2950-10-KIT	150 psig
22-2950-11-KIT	200 psig
22-2950-12-KIT	30 psia
22-2950-13-KIT	60 psia
22-2950-14-KIT	100 psia
22-2950-15-KIT	300 psia



22-2950-16-KIT	600 psia
22-2950-17-KIT	1000 psia
22-2950-18-KIT	1500 psia
22-2950-19-KIT	150 psia
22-2950-20-KIT	200 psia



7.3 Redundant Uncorrected Switch




NC	Normally Closed
NO	Normally Open
COM	Common



7.4 Metrological Sealing Cover (MC)


- The following figure shows MC Cover installed with 3 Cross-Drilled security screws at locations indicated by arrows.



- Using sealing wire and lead seal, seal cover at these locations. Run wire through the screw head, and then through the MC cover sealing features.




- Re-install Human Factor cover tightening the screws to 9 +/- 1 in-lbs of torque at these locations. Ensure power cable is routed in the orientation shown for battery connection.



7.5 Removing and Re-Installing Human Factor (HF) Cover

1



Loosen screws in 3 positions

2



Remove HF Cover

3a



Route cables in the orientations as shown, before re-assembling HF cover

3b



4



Tighten screws to 8-10 in-lbs

7.6 Replacing the Battery Pack

If your EC350 displays **REPLACE BATTERY**, it indicates that EC350 has gone into a power conservation mode due to low battery voltage.

- [Replacing the battery in a hazardous DIV-1/ZONE-0 environment](#)
- [Replacing the battery in a non-hazardous environment](#)

7.6.1 Replacing the battery in a hazardous DIV-1/ZONE-0 environment

A special operating mode is provided to allow changing of a battery pack in a hazardous location. (If the location is known to be non-hazardous, for example, if the location has been tested for the presence of gas and it has been determined that gas is not present, this section can be skipped. Go to the [Replacing the battery in a non-hazardous environment](#) section). The special operating mode puts the corrector in a standby condition in which volume continues to be accumulated and event logging and alarms are still active, but all other functions are stopped to ensure very low power drain. This allows a low power (Swap out) battery (40-6054) to be plugged in while the main battery pack (40-6048) is changed, and then removed after the new battery back is plugged in.

To replace the battery in a hazardous DIV-1/ZONE-0 environment, perform the following steps:

- Enter **HMI** and set the EC350 to **Battery Change** mode. You can use the L2.11 or L3.13 HMI menus.
- The **BATT CHNG** message is displayed on the LCD screen. Press the **Enter** key.
- Select **Yes** and press **Enter**. The unit is now ready for a battery change out. **CHNG BATT THEN ESC** is displayed on the LCD screen.
- Plug the *Low Power (Swap out) Battery* (part no. 40-6054) into the open connector on the battery Y cable.
- Unplug the old battery.
- Plug in the fresh battery (part no. 40-6048) where the old battery was plugged in.
- Remove the *Low Power (Swap out) Battery*
- Press the **ESC** key twice to exit the battery change mode. When the **ESC** key is pressed, all the battery life items are automatically set to 100% new values and the battery usage cycle is set to zero.

7.6.2 Replacing the battery in a non-hazardous environment

To replace the battery in a non-hazardous environment, perform the following steps:

- Plug in the fresh battery into the open connector on the battery Y cable.
- Unplug the old battery.
- Reset Battery Life Items to defaults (100% new) by following steps shown below:

- Unlock the keypad and type the PASSCODE to enter level 2 or level 3 menus. Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.
- Scroll down in to HMI menu to **L2.12** or **L3.12** where it displays: “**RESET BATT**” on LCD and then press the Enter key.
- Press **YES** key to confirm (see note below).
- EC350 resets the battery usage Items to factory default values: (Item 59 = 0, Item 1001 = 60 mo, Item 1002 = 100%).
- Press **ESC** until you have exited the HMI.

7.7 Low battery/ External Power shutdown mode

EC350 automatically enters a low battery shutdown mode when the battery voltage measurement falls below the value of Item 50 (Battery Shutdown Limit) for three (3) consecutive times.

Note: Item 50 Shutdown Limit applies to both Battery Voltage and External Supply Voltages.

While in low power shutdown mode, the LCD displays the following (except if user enters HMI mode):

“REPLACE”

“BATTERY”

To **exit** Low Power Shutdown, the Battery voltage must be above the Item 50 limit value and the user must enter HMI mode. User enters HMI and menu down arrow to the screen showing: **SHUTDOWN** - HMI menus: L2.10 or L3.12. Next, the User presses Enter key and display will show: ‘ENTER MODE’ as first selection. Arrow down to ‘EXIT MODE’ selection. User again presses the Enter key to confirm – the unit leave (exit) Shutdown/Shelf mode. When the User exits the HMI menus – the LCD will then return to normal default screen.

Refer to the table below to see which functionality is limited or blocked in low battery shutdown mode.

Functionality	What Happens
Pressure measurement	Stopped
Temperature measurement	Stopped
Supercompressibility calculations	Stopped
Battery measurements	Stopped
External Supply measurements	Stopped
Volume	Calculates volume input using PTZ factors from before entering Shutdown mode
Pulse Outputs	No output pulses sent. Items 5 to7 continue to update per new volume input and will be sent only after exiting Shutdown mode
Alarm Output	No Alarm output signal is sent. If pending, it will be sent only after exiting Shutdown mode
IrDA communications	Stopped
RS-232/485 communications	Stopped

Functionality	What Happens
Scheduled / Alarm Call-in	Stopped
Date and Time	Continues to update as normal
Audit Trail logging	Stopped

Refer to the table below to see which functionality is not blocked in shutdown mode.

Functionality	What Happens
Alarm logging	Runs as normal. However it is unlikely to have any alarms
Event logging	Runs as normal
HMI Menus and Scroll List	Active- No live readings are taken

7.8 User Shelf/ Shutdown mode

The EC350 can be placed in to a User Shelf / Shutdown mode to take it out of service for extended periods of time. This mode is useful to conserve battery life when the instrument is not in use. In this mode **EC350** conserves battery energy by limiting most of its normal functionality while preserving data and keeping time.

You can enter user shutdown mode using:

- HMI menu levels 2 or 3
- MasterLink Software Application SQL
- [To enter user shutdown mode using HMI mode 2 or 3](#)
- [To enter user shutdown mode using MasterLink Software Application SQL](#)

7.8.1 To enter user shutdown mode using HMI mode 2 or 3

- Unlock the keypad and type the **PASSCODE** to enter level 2 mode or level 3 mode Refer to the section “ [Accessing level 2 mode](#) ” for accessing level 2 mode or section “ [Access level 3 mode](#) ” for accessing level 3 mode.
- By default, the following appears on the display.
MAIN MENU

ALARMS
- Using the **UP arrow** and **DOWN arrow** scroll through the options in level 2 mode or level 3 mode until **SHUTDOWN** appears.
- Press **OK**. The following appears on the display.
ENTER MODE
- Press **OK** to confirm.
EC350 enters shutdown/shelf mode.
- Press **ESC** to exit HMI mode 2 or 3.

7.8.2 To enter user shutdown mode using MasterLink Software Application SQL

- Establish a serial communication between EC350 and MasterLink Software Application SQL. Refer to the *MasterLink Software Application SQL User's Guide* for information about establishing a serial connection between EC350 and MasterLink Software Application SQL.
- In the **MasterLink Software Application SQL** window, click **Instrument > Shutdown**.
- Click **Yes**.

Functionality	What Happens
Pressure measurement	Stopped
Temperature measurement	Stopped
Supercompressibility calculations	Stopped
Battery measurements	Stopped
External Supply measurements	Stopped
Volume	Volume input fully disabled
Pulse Outputs	Output pulses disabled
Alarm Output	NoAlarm output signal is sent. If pending, it will be sent only after exiting Shutdown mode
IrDA communications	Stopped
RS-232/485 communications	Stopped
Scheduled / Alarm Call-in	Stopped
Date and Time	Continues to update as normal
Audit Trail logging	Stopped

Refer to the table below to see which functionality is not blocked in User Shelf mode.

Functionality	What Happens
Alarm logging	Runs as normal. However it is unlikely to have any alarms
Event logging	Runs as normal

Functionality	What Happens
HMI Menus and Scroll List	Active- No live readings are taken