
Operating Procedures for Test Plug Lifting Fixture








PROCEDURES FOR USE

Use these procedures to attach the Lifting Fixture to your Test Plug and safely insert it into the pipe to be tested.



reattachment after use of the Lifting Fixture.

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Haffield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est-info@curtisswright.com Europe / Middle East / Africa EST Group B.V. Hoorn 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849

est-emea@curtisswright.com

China P +86.400.636.5077 est-china@curtisswright.cr

Singapore P +65.3158.5052 est-asia@curtisswright.com


EST Group

DC2590 04/14 REV 8 12/19

Step/Action

Additional Action/Information/Result

2. Prepare the Lifting Fixture for attachment to the Test Plug. Inspect the arm, brackets, and hardware for signs of excessive wear or other damage (cracks or bends).



- Remove the Retention Plates from the Standoff Brackets. Put aside Retention Plates and hardware for installation. Take care not to lose the two screws set into each of the Standoff Brackets. These are required to attach the Standoff Brackets to the Test Plug.
- Remove Fixture Arm from the brackets. Set aside.
- Remove the Shoulder Bolt and Sleeve Bushings from the Fixture Arm by unscrewing the Wingnut. Set the Shoulder Bolt and its hardware aside for later use.
- Attach the Standoff Brackets to the Test Plug by aligning Standoff Brackets with the Hoist Ring holes.
 SET SCREW
 SOCKET HEAD
 CAP SCREW
 Attach the Standoff Brackets to the Test Plug using the standoff Brackets to the Test Plug
 - Attach the Standoff Brackets to the Test Plug using the Socket Head Cap Screws supplied. Torque to 5-8 FT-lbs. (7-10 N-m)

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Haffield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est-linf0@curdfisswright.com

Europe / Middle East / Africa

EST Group B.V. Hoom 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849 est-emea@curtisswright.com P +86.400.636.5077 est-china@curtisswright.c

Singapore P +65.3158.5052 est-asia@curtisswright.com

EST Group


DC2590 04/14 REV 8 12/19

Page 3 of 8


Step/Action

Additional Action/Information/Result

4. Attach the Retention Plates to the Standoff Brackets.



- Align both Retention Plates onto their respective bolts on the Standoff Brackets.
- Attach the Retention Plates to the Standoff Brackets using the supplied Wing Nuts and Washers.
- 5. Slip the Fixture Arm through the Standoff Brackets and install the Shoulder Bolt assembly.



- Install the Shoulder Bolt, Sleeve Bushings, and Wingnut. One Sleeve Bushing goes on either side of the Fixture Arm, and the Shoulder Bolt passes through all three parts.
- Securely tighten the Wingnut onto the Shoulder Bolt.

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Haffield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est-linf0@curdfisswright.com

Europe / Middle East / Africa

EST Group B.V. Hoom 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849 est-enea@curlisswright.com P +86.400.636.5077 est-china@curtisswright.cl

Singapore P +65.3158.5052 est-asia@curtisswright.com

EST Group

DC2590 04/14 REV 8 12/19

Step/Action		Additional Action/Information/Result
6.	Position the Lifting Ring to be above the center of gravity of the Test Plug. Generally, for GripTight Test Plugs, the approximate center of gravity is located at the far end of the Grippers.	EYEBOLT FLAT WASHER
	 & Isolation Plugs, the approximate center of gravity is located about the Between the Seals Fill Port. For GripTight Isolation Plugs, the approximate center of gravity is located at the center of the bottom seal. For the Test Plug to properly hang horizontal horizontally, the Eyebolt must be adjusted to location. Remove the Nut, Split Lock Washer, and Flat Remove the Eyebolt from its hole. Make sure 	 For the Test Plug to properly hang horizontally, or nearly horizontally, the Eyebolt must be adjusted to the correct location. Remove the Nut, Split Lock Washer, and Flat Washer. Remove the Eyebolt from its hole. Make sure the second Flat
See	See page 7 for additional information.	Washer is kept with it.
7.	Install the Eyebolt into its position.	• Replace the lower Flat Washer, Lock Washer and Nut. Tighten the Eyebolt Nut and torque to 45-50 FT-lbs. (61-68 N-m)
8.	Connect the lifting mechanism (hoist, lift, crane, etc.) to the Eyebolt.	 Carefully begin to raise the Test Plug and Lifting Fixture assembly. Use caution while lifting the assembly, using best rigging and lifting practices. Always lift slowly and in a gradually increasing manner. If the Lifting Fixture was attached to the Test Plug while it was lying on its bottom (in a vertical / shipping orientation), it will be necessary to stabilize the plug as it leaves the ground and orients to a horizontal position. Keep personnel clear of any shifting plug and extremities from any potential pinch points.
9.	Position the Test Plug inside the pipe to be tested.	 Carefully maneuver the Test Plug into the pipe to be tested. Gentle use of a lever arm or crowbar in the rear of the horizontal portion of the fixture arm may aid in positioning. Fully push the Test Plug into pipe. GripTight Test Plugs shall be inserted until the Tabs on the Top Washer contact pipe end. Double Block and Bleed and GripTight Isolation and Test Plugs should be fully inserted into the pipe. Slowly lower the Lifting Fixture and Test Plug until the Test Plug rests inside the pipe. Use caution to not allow GripTight Test Plugs to move once they are seated within pipe. Allow the Fixture Arm to slip down low enough to rest on the pipe.

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Hatfield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est_info/@utisswrinkt.com est-info@ swright.com curi

Europe / Middle East / Africa

EST Group B.V. Hoom 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +33.172.418849 est-eme affectiefecti est-emea@curtisswright.com

China P +86.400.636.5077 est-china@curtisswrid ht.cn

Singap P +65.3158.5052 est-asia@curtisswright.com

Step/Action	Additional Action/Information/Result
10. Remove Lifting Fixture from plug.	 Remove the Shoulder Bolt and its associated hardware from the Lifting Fixture Arm and put aside. Remove the Lifting Fixture Arm from the Standoff Brackets. If the Standoff Brackets interfere with plug installation: Remove the Retention Plates from the Standoff Brackets. Remove the Standoff Brackets from the Test Plug. Put Standoff Brackets, Retaining Plates, and all associated hardware aside.
	NOTE: Depending on installation depth, reinstalling the Hoist Rings may aid in removing Double Block & Bleed Isolation and Test Plugs and GripTight Isolation Plugs.
11. Install Test Plug.	• Install Test Plug. Carefully follow installation instructions supplied with each Test Plug.
12. After test is complete, reinstall Standoff Brackets, Retaining Plates, and Fixture Arm. Once installed, the Test Plug can be removed from the open pipe end.	 Uninstall the Test Plug following its supplied instructions. Install Standoff Brackets, Retention Plates, Fixture Arm, and Shoulder Bolt hardware. Carefully lift Test Plug to slide out of pipe. Care must be taken to not apply excessive lifting force while the Test Plug is still within the open pipe end. This can apply excessive force to the Test Plug and Lifting Fixture.
13. After the Test Plug has been removed and stored in accordance with the Test Plugs operating procedures, the Lifting Fixture can be removed from the Test Plug.	• Reverse the installation steps given above.

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Hatfield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est_info/@utisswrinkt.com est-info@curt sswright.com

Europe / Middle East / Africa

EST Group B.V. Hoom 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31,172,418841 F: +33,172,418849 est-emea@cutieswinht.com est-emea@curtisswright.com

China P +86.400.636.5077 est-china@curtisswrid <u>ht.cn</u>

Singapore P +65.3158.5052 est-asia@curtisswright.com

DC2590 04/14 REV 8 12/19

Page 6 of 8

EST Group

Step/Action	Additional Action/Information/Result
14. Inspect all Lifting Fixture components for damage. If any damage is found, do not continue to use the Lifting Fixture. Contact EST Group Customer Service for replacement parts. Store the Lifting Fixture assembled to prevent loss of parts.	TP-LIFT-1024 Replacement Parts: • Arm and Hardware: TP-LIFT-1024-ARM
	• Bracket, Tools, and Hardware: TP-LIFT-1024-BRACKET

Questions? Contact EST Group Customer Service at any of the following locations.



www.cw-estgroup.com


North, Central & South America EST Group Corporate Office 2701 Township Line Road Hatfield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est_info/@utisswrinkt.com est-info@cur swright.com

Europe / Middle East / Africa

Europe / Middle East / Amca EST Group B.V. Hoorn 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849 est-emea@curtisswright.com

China P +86.400.636.5077 est-china@curtisswrid ht.cn

Singap P +65.3158.5052 est-asia@curtisswright.com



BETWEEN THE SEALS FILL PORT




Figure 2: Approximate Center of Gravity for Double Block & Bleed Isolation Plugs




Figure 3: Approximate Center of Gravity for GripTight Isolation Plugs

Questions? Contact EST Group Customer Service at any of the following locations.



EST Group

www.cw-estgroup.com

North, Central & South America EST Group Corporate Office 2701 Township Line Road Hatfield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.355.7044 F: +1.215.721.1101 est-info@curitiswright.com Europe / Middle East / Africa

EST Group B.V. Hoorn 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849 est-emea@curfisswright.com China P +86.400.636.5077 est-china@curtisswright.cn

Singapore P +65.3158.5052 est-asia@curtisswright.com



EST Group Oil & Gas Division 2701 Township Line Road Hatfield, Pennsylvania 19440 USA T: +1 215.721.1100 | F: +1 215.721.1101 USA Toll Free: 800.355.7044 www.estgroup.cwfc.com

August 5, 2014

CERTIFICATION

Part #: TP-LIFT-1024 Description: Test Plug Lifting Fixture manufactured by EST Group, Hatfield, PA USA

EST certifies that the TP-LIFT-1024, Test Plug Lifting Fixture manufactured by EST Group, when properly used meets or exceeds a design safety factor of 2 to 1 based on a 1,500 lbs. (680 kg) maximum working load rating. Strict adherence to the operating procedures provided by EST Group with the lifting fixture, as well as adherence to industry standards best lifting practices including, but not limited to, OSHA 29 CFR 1926.251 and/or ASME B30.20 is required.

The TP-LIFT-1024 is manufactured from ASTM A108 grade 1018 bar, formed tubing that conforms to ASTM A500 Grade B or C, and utilizes standard commercially available hardware. The material properties and quality provide assurance that when used in the correct configuration and in accordance with EST Group operating procedures it meets or exceeds the Test Plug Lifting Fixture design safety factor.

The TP-LIFT-1024 is manufactured under EST Group's certified ISO 9001-2008 Quality Assurance Program.

The user is reminded that, in spite of the design safety factor, the maximum work load rating should never be exceeded, and the TP-LIFT-1024 should only be used in accordance with the operating procedures to lift EST Group approved test plugs.

Mall -

Alex Kotlyar Engineering Manager - EST Group

Contact EST Group Customer Service at any of the following locations with questions:

- In USA and Canada: tel: 800-355-7044, 215-721-1100; e-mail: est-info@curtisswright.com
- In Europe, Middle East, and Africa: tel: +31-172-418841; e-mail: <u>est-emea@curtisswright.com</u>
- In Asia: tel: +65-6745-8560; e-mail: <u>est-asia@curtisswright.com</u>
- In China: tel: +86-10-65058966; e-mail: <u>est-china@curtisswright.cn</u>
- On the Internet: <u>http://estgroup.cwfc.com</u>

EST Group provides a complete range of repair products, services, and replacement parts covering the life cycle of heat exchangers and condensers; additionally EST Group provides products and services to facilitate pressure testing pipe, piping systems, pressure vessels, and their components. Visit EST Group on the Internet at http://estgroup.cwfc.com.

Questions? Contact EST Group Customer Service at any of the following locations.



EST Group www.cw-estgroup.com North, Central & South America EST Group Corporate Office 2701 Township Line Road Hatfield, PA 19440-1770 USA P: +1.215.721.1100 +1.800.335.7044 F: +1.215.721.1101 est-linf0@curitisswright.com

Europe / Middle East / Africa

EST Group B.V. Hoorn 312a 2404 HL Alphen aan den Rijn The Netherlands P: +31.172.418841 F: +31.172.418849 est-enea@curlisswright.com P +86.400.636.5077 est-china@curtisswright.c

Singapore P +65.3158.5052 est-asia@curtisswright.com