

## How to Install a Carsonite Test Station

**CAUTION:** Always wear proper safety equipment. Read instructions completely before installation.

### For New or Existing Posts

1. Install the Hardware Kits.
2. Pull the wire through the post and test the station.
3. Install the post and connect its wiring as appropriate.
4. Slide the Test Station's base over the end of the post. *See Figures 1, 2.*
5. Drill through the post, using the Test Station's guide holes, with a 3/16" drill bit.
6. Push the thumb rivet through the Test Station and the post, as shown. *See Figure 2.*
7. Repeat drill and thumb rivet on opposite side.
8. Place the Test Station's cap over its base and rotate it clockwise to lock it in place. *See Figure 3.*

